Weather Indicator List

• Indicators and categories are subject to change without notice.

Weather		
₩	Clear (day)	
3)	Clear (night)	
8	Cloudy	
7	Rain	
3 -	Snow	
4	Thunderstorm	
0 % - 100%	Chance of Precipitation 0%-100%	
\triangleright	Later	
0	Occasionally	

Pollen Level	
4	Low
Æ.	Moderate
	High
	Very High

Cherry Blossom		
	Blossoms Opening	
	Near Full Bloom	
(Peak Bloom	
8	Past Peak	

Fall Foliage	
*	No Color
*	Moderate Color
*	Peak Color
	Past Peak
ESP.	T dot T can

UV Level	
	Low
孌	Moderate
*	High
*	Very High

Typhoon	
45	Formed
	Approaching
95	Severe

Other Information	
	Heavy Rain
	Storm Winds
4	Notifications

Up to 1000 items/approx. 31 MB (Including pre-installed data)

 Shared with Notepad/S! Appli List (One S! Appli corresponds to three to six items.)

Schedule Events	Up to 100 items	
Phone Book	Up to 1000 items	

| Messaging (SMS and S! | Drafts/ | Sent Messages/ | Up to 1000 items/approx. 5 MB | Up to 1000 items/approx. 5 MB | Up to 500 items/approx.

Unsent Messages

		[Yahoo! Keitai]
	Saved Pages	Up to 20 items/750 KB
		[PC Site Browser]
		Up to 20 items/1150 KB
	Bookmarks	[Yahoo! Keitai]
		Up to 100 items
		(Including pre-installed data)
		[PC Site Browser]
Yahoo!		Up to 100 items
Keitai	URL History	[Yahoo! Keitai]
Keitai		URL Entry: Up to 20 items
		URL Access: Up to 100 items*
		[PC Site Browser]
		URL Entry: Up to 20 items
		URL Access: Up to 100 items*
	Cache	[Yahoo! Keitai]
		750 KB
		[PC Site Browser]
		1150 KB

^{*} The number of savable items varies depending on URL length.

17 Appendix

Specifications

841P

		·
Weight (including battery)		120 g*
Dimensions (closed)		50 x 108 x 17.9 mm*
Chandles Time	3G	430 hours*
Standby Time	GSM	340 hours*
Talk Time	3G	230 minutes*
	Video Call	100 minutes*
	GSM	250 minutes*
TV Reception Time		4 hours*
Charging Time	AC Charger	150 minutes*
	In-Car Charger	150 minutes*
Maximum	3G	0.25 W
Output	GSM	2.0 W

^{*} Approximate value

- \bullet Values above were calculated with battery installed.
- Talk Time is an average measured with a new, fully charged battery, with stable signals.
- Standby Time is an average measured with a new, fully charged battery, with handset closed without calls or operations, in Standby with stable signals.
- TV-Reception Time is an average measured using earphone/microphone, with stable signals.
- Talk Time and Standby Time may vary by environment (battery status, temperature, etc.).
- Talk Time and Standby Time may decrease when an S! Appli is active.

Battery

Voltage	3.7 V
Battery Type	Lithium-ion
Capacity	920 mAh
Dimensions	45 x 5.4 x 37 mm*

- * Approximate value
- Specifications subject to change without notice.

Index

Numerics

3D Pictograms	12-1
Settings	15-1
3G	2

AC Charger 1-13
Access History
PC Site13-5
Yahoo! Keitai13-4
Account Details 1-24, 4-14
After-Sales Service 16-29
Alarms 11-6
All Reset 10-9
Alternative Picture 2-5, 15-14
Answer Phone 2-12
Answer Time (Answer Phone)2-13
Answering Calls
Video Calls 2-6
Voice Calls 2-4
Any Key Answer 15-11
Attachment Auto-play 15-19
Attachments
Adding/deleting 12-9
Opening/saving 12-15
Audio Player 7-4
Authentication Code 9-4
Auto Answer 15-11
Auto Delete (Messages) 12-3, 15-18
Auto Focus Lock5-6
Auto Save (Camera) 15-15, 15-16
Auto Suspend Timer (S! Appli) 15-23
Available Memory (Camera) 15-15, 15-16

Background Music	7-5
Backlight	
Display	15-6
Keys	15-6
S! Appli	
Video Calls	
Backup	
Memory Card	8-15
S! Address Back-up	
Bar Code Reader	
Basic Operations (Internet)	13-6
Battery	1-10
Battery Strength Indicator	
Bookmarks	13-8
Books folder	8-2
BookSurfing®	
Brightness	
Camera	5-3
Display	15-6
Video Camera	
Browser (Initializing)	

C
Cache Memory13-
Calculator 11-
Calendar 11-
Call Barring2-19
Call Barring Password1-2
Call Cost 15-10
Call Forwarding 2-14
Call Log2-10
Call Operations2-9
Call Settings 15-
Call Time 15-10
Call Waiting2-1
Caller ID2-2, 2-2
Camera [Section Contents]5-
Center Access Code 1-2
Certificate Retention 15-2
Change View
Data Folder8-4
Memory 8-4
Phone Book 15-13
Character Code List 16-14
Input Options 3-4
Charging Time 1-10
Clamshell Control 15-11, 15-18
Clock/Calendar Display 15-4
Close-to-End Call 15-1
Content Key 8-
Continuous Shooting5-
Conversion Candidates3-
Conversion Methods3-

Cookies	
Deleting 15-2	22
Settings 15-2	
Copy Protected Files8	
Count Down Timer11	
Country/Area Number List2	
Customer Service	
D	
Data Folder8	
Date & Time Settings 15	-8
Deleting	
Folders/files 8-1	2
Messages 12-2	24
Phone Book 4-1	0
S! Appli 14	-4
Schedule 11-	-5
Delivery Report 12-1	1
Display 1-	
Display Indicators1	-8
Display Pattern (Date & Time) 15	
Settings 15	-4
Download	
From web pages13-1	1
Music/Video files 7-	
S! Appli14	
Templates 12-1	
Download Dictionary3	
Drafts 12-10, 12-1	

E	
e-Book Viewer	6-6
Earpiece Volume	
Video Calls	2-6
Voice Calls	2-4
Effect (Camera)	5-3, 5-4
Emergency Calls (110, 119, 118)	2-3
Emergency Positioning Request	2-3
Emission OFF Mode	1-16
Emoticons	3-4
Expiry (SMS)	15-21

F	H	K
Feeling Mail Creating	Handset Menus	Key Assignments 16-1 Key Backlight Time 15-1 Key Operation List 15-1 Video Camera 15-1 Key Settings 15-1 Key Tone 15-1 Keyguard 10-1 L L Language 15-1 Learning from Received Message 15-1 Letter Narrow Input 3-1
Mail & Call Log	Image Size (Camera)	License Information (S! Appli)

Internet [Section Contents] 13-1

GSM 2-9

17 Appendix

5	T
	-
	~
	æ
	=
	_
	_

IVI	
Magnifying Loupe	5-8
Mail Delivery Rule	12-19
Mail Group	12-21
Mail Log	12-15
Mail Security Setting	10-8
Main Menu	1-16
Main Menu Icons	15-5
Making Calls	
International Calls	2-7, 2-8
Video Calls	2-6
Voice Calls	2-2
Manner Mode	1-15
Setting	
Manufacture Number	15-22
Media Player [Section Contents]	
Memory Card	8-13
Backup	
Check Memory Card	8-18
Formatting	
Synchronizing	15-23
Memory List	
Memory Manager (Internet)	15-22
Memory Status	
Calendar	
Data Folder	8-3
Messages	
Phone Book	4-11
Menu Numbers	1-17
Menu Theme	1-16

Messaging [Section Contents]	12-1
Messaging Lock	10-6
Missed Call Notification	2-16
Multi Selector	ix
Multi Shot	5-3
Music folder	8-2
Music Search	7-3
Mute Voice	2-10
My Number	1-24
My Pictograms	12-7

N
Network Information 1-14
Network Mode2-9
Network S! Appli 14-2
New Messages
Retrieving 12-17
Viewing 12-12
Night Mode 5-3
Normal Mode
Manner Mode Settings 15-7
Simple Mode Menu 1-2
Notepad11-8
Notification Light Settings 15-12
Trouncation Eight Settings
0
O One Touch Guide11-12
One Touch Guide
One Touch Guide
O 11-12 One Touch Guide
One Touch Guide
One Touch Guide
One Touch Guide
O One Touch Guide 11-12 One Touch Key 4-8 Open-to-Answer Call 15-12 Open-to-Display Missed Call 15-13 Operator Operator Name 15-6 Selecting 15-6 Optional Services 2-14
One Touch Guide

_	_
1	1
7	?
5	Ś
Ë	Ś
₹	₹

P	
Password Lock10-4	1
Passwords1-23	3
Passwords (Changing)	
Call Barring Password2-19	9
Center Access Code 1-23	3
Phone Password 10-2	2
PC Site Browser 13-2	2
Access13-!	5
Display Settings 15-2	1
Memory Manager & Settings 15-22	2
Reset 15-23	3
Security Settings 15-22	2
Phone Book [Section Contents]4-	
Phone Book Lock 10-0	6
Phone Password 1-23	3
Phone Password (Changing)10-2	2
Pictographs3-:	3
Picture Size 5-3	3
Pictures folder 8-2	2
Pictures (Still Images)	
Capturing 5-!	5
Editing8-1	1
PIN/PIN2 1-3	3
Changing 10-3	
PIN Certification10-2	2
PIN Lock & Cancellation	
(PUK/PUK2)10-3	
Playback Method8-	5
Playback Mode7-	7
Playback Mode Indicators 7-4	1

Playback Position7	/-5
Playlist7	/-8
Predictive Conversion3	3-5
Preview Window	
Camera 5	i-3
Video Camera5	-4
Private Menu1-	20
PUK/PUK2 1-3, 10)-3

Q
QR Code
Quick Phone Book Search4-7, 4-8
R
Recipients (Adding/editing/deleting) 12-9
Referer Information 15-22
Reject Incoming Calls 10-5

Recipients (Adding/editing/deleting) 12-9
Referer Information 15-22
Reject Incoming Calls 10-5
Reject List 10-5
Remaining Cost 15-10
Reset
All Reset 10-9
Browser Settings15-23
Camera Settings 15-15, 15-16
Group Settings 4-6
Key Settings 15-6
Main Menu Icons 15-5
Settings 10-9
Restoring
Memory Card 8-16
S! Addressbook Back-up 4-12
Ring Songs·Tones folder 8-2
Ringer Volume 15-2
Ringtone Duration 15-2
Ringtone Settings 8-9, 15-2
Roaming 2-8
Root Certificates 15-22

S	
S! Addressbook Back-up	4-1
S! Appli [Section Contents]	14-
S! Information Channel	
S! Mail	12-
Creating/sending	12-
S! Mail Notice	
Settings	15-1
Universal Settings	15-1
S! Quick News	
Save Location	
Phone Book	15-1
Still Images	5-
Videos	5-
Saved Pages	13-
Saving	
Notepad	
Phone Book	
Reject List	10-
Schedules	11-
Shortcuts	1-2
User's Dictionary	3-
Schedules (Schedule Events)	11-
Script	15-2
Scroll Unit	
Secret Data Only	10-
Secret Mail Display	10-
Secret Mode	
Secure Remote Lock	
Security Functions	
Security Level (S! Appli)	14-

Security Settings (Internet)	15-22
Self-Timer 5-:	3, 5-4, 5-6
Server Mail	12-17
Settings [Section Contents]	
Shortcuts	
Shutter Sound	15-15
Simple Mode	1-21
SMC files	7-5
SMS	12-2
Creating/sending	
Settings	15-21
Universal Settings	15-18
Snooze	
SoftBank Utility Software	
Softkeys	ix
Software Update	16-10
Sort (Messages)12-	-18, 12-23
Spam Filter	12-20
Speaker	
Video Calls	2-10
Voice Calls	
Speed Dial	4-8
SSL	13-3
Standby Display	
Standby Window	1-19
Still Images (Pictures)	
Capturing	5-5
Editing	8-11
Streaming	
Symbols	3-3
Symbol List	
System Message	12-17

Т	
[ext Entry [Section Contents]	3-1
Text Predict	15-13
Themes	15-4
Time Correction	15-8
rLS	13-3
Total Call Charge	15-10
Total Call Time	15-10
II	

V	W
Vibration 15-2 Incoming Alert	Wallpaper
Voice Mail	Y Yahoo! Keitai
	Z Zoom (Camera) 5-3, 5-

Warranty & Service

Warranty

Warranty is provided when you purchase a 841P.

- Check name of distributor and date of purchase.
- Read through contents and keep in a safe place.
- The warranty term is described in the warranty.

SoftBank is not liable for any damage resulting from use of this product.

After-Sales Service

See "Troubleshooting" (\$\subseteq\$ P.16-8) before contacting SoftBank for service or repairs. If you cannot find solutions or solve problems, contact SoftBank Mobile Customer Center, Customer Assistance (\$\subseteq\$ P.16-30) in your subscription area and provide a detailed description of the problem.

- Repairs within warranty are performed under terms and conditions described.
- Out of warranty, any repairs are performed upon request at subscriber's expense.

Customer Service

If you have questions about SoftBank handsets or services, please call General Information. For repairs, please call Customer Assistance. Check phone number before you dial.

SoftBank Mobile Customer Center

From a SoftBank handset, dial toll free at 157 for General Information or 113 for Customer Assistance SoftBank Mobile Global Call Center

From outside Japan, dial +81-3-5351-3491 (Please take care to dial the correct number. International charges will apply to this call.)

Call these numbers toll free from landlines.

Subscription Area	Service Center	Toll Free Number
Hokkaido, Aomori, Akita, Iwate, Yamagata, Miyagi, Fukushima, Niigata, Tokyo, Kanagawa, Chiba, Saitama, Ibaraki, Tochigi, Gunma, Yamanashi, Nagano, Toyama, Ishikawa, Fukui	General Information	0088-240-157
	Customer Assistance	0088-240-113
Aichi, Gifu, Mie, Shizuoka	General Information	0088-241-157
	Customer Assistance	0088-241-113
Osaka, Hyogo, Kyoto, Nara, Shiga, Wakayama	General Information	0088-242-157
	Customer Assistance	0088-242-113
Hiroshima, Okayama, Yamaguchi, Tottori, Shimane, Tokushima, Kagawa, Ehime, Kochi, Fukuoka, Saga, Nagasaki,	General Information	0088-250-157
Oita, Kumamoto, Miyazaki, Kagoshima, Okinawa	Customer Assistance	0088-250-113

SoftBank 841P User Guide

February 2010, First Edition

SOFTBANK MOBILE Corp.

For additional information, please visit a SoftBank shop.

Model: SoftBank 841P

Manufacturer: Panasonic Mobile Communications Co., Ltd.



Please help the mobile industry maintain high environmental standards. Recycle your old handsets, batteries and charger units (all manufacturers and brands). Before you recycle, please remember these important points:

- Handsets, batteries and chargers submitted for recycling cannot be returned.
- Always erase all data recorded on old handsets (Phone Book entries, call records, mail, etc.) before recycling.