## M-1200B

## Adjustment Procedure

- 1. Adjust the DC power supply so that 3V is obtained at the battery terminals.
- 2. Turn the microphone ,checking first whole machine work electric current whether normal(<100 mA)
- 3. Confirm that dummy load and coumunication tester(HP8920A) are prepared.
- 4. use the HP8920A to measure the frequency.if the frequency error margin out +/-4 PPMs, If there is variable electric capacity in VC3 in modulator to adjust the frequency error.
- 5. Change different channel. Repeat the test., It will change the frequency to 762.5MHz,775MHz and 787.45MHz.

## M-1200B BOM

	M-1200B BOM					
Serial n	Specification	Specification	Single			
1	A	10UF	30			
2	0603C	104	28			
3	0603C	470P	1			
4	0603C	100P	4			
5	0603C	103	13			
6	0603C	273	1			
7	0603C	303	1			
8	0603C	102	6			
9	В	47UF	6			
10	С	100UF	2			
11	A	15UF	2			
12	0603C	27P	3			
13	0603C	47P	2			
14	0603C	10P	2 2			
15	0603C	3P	1			
16	0603C	4P7	2			
17	0603R	0R	1			
18	0603C	1P5	1			
19	0603C	15P	2			
20	0603C	473	1			
21	A	4U7	1			
22	0805C	222J	2			
23	0603C	200P	1			
24	0603C	33P	2			
25	A	1UF	1			
26	0603C	330P	3			
27	A	0.47UF	1			
28	SOT-23	BAT54C	1			
29	SOT-23	BAV99W	2			
30	ML34	RB051L	1			
31	0805L	100N	3			
32	0603L	220N	1			
33	0603L	82N	4			
34	0603L	22N	6			
35	6.5*6.5 inductance	47UH	2			
36	0603L	7N5	3			
37	SOT-23	2S2412K	5			
38	SOT-23	DTC363TK	1			
39	SOT-143	BFG520/X	3			
40	SOT-23	2SA1037AK	2			

41	SOT-23	XR151	1 1
42	SOT-23	2SK208	2
43	SOT-89	162	1
44	0603R	2K2	17
45	0603R	100R	4
46	0603R	47K	5
47	0603R	220K	1
48	0603R	100K	9
49	0603R	33K	1
50	0603R	10K	18
51	0603R	270R	1
52	0603R	1K	4
53	0603R	6K8	2
54	0603R	4K7	8
55	0603R	22K	9
56	0603R	22R	2
57	0603R	470K	1
58	0603R	10R	4
59	0603R	15K	6
60	0603R	470R	2
61	0603R	150K	3
62	0603R	12K	3
63	0603R	1K2	1
64	0603R	3K9	2
65	0603R	18K	1
66	0603R	1M	1
67	0603R	270K	1
68	0603R	1K5	1
69	0603R	330R	1
70	0603R	220R	2
71	0603R	47R	2
72	0603R	560K	2
73	SOL-48	HT1621	1
74	SOT-25	HT7150-1	1
75	SOL-48	HT46R23	1
76	SOL-20	SZX575	1
77	SOT-25	2107	1
78	SOL-8	4580(0.65)	1
79	SOT-25	LMV321	3
80	SOL-16	E03SL	1
81	SOT-25	XC6367B	1
82	SOT-25	BU4S66	2
83	SOL-8	24C02A	1

84 SOT-25 HT17130 85 SOT-25 HT7150-1	1
85 SOT-25 HT7150-1	
<u> </u>	2
86 3*4(VR) 10K	2
87 3*4(VR) 1K	1
88 SMD 4MHz	1
89 DIP 4MHz	1
90 DIP 32768	1
91 <u>AVS-775WM10.1</u>	1
92 SOT-23 3V	1
93 PCB U-960-P01B 17.78*3.11	1
94 U-960-P02B 17.78*3.11	1
95 U-960-P01B 17.78*3.11	1
96 U-960-P02B 17.78*3.11	1
97 switch SK-12D07-G3NS	2
98 battery 780 #	1
99	
100	
101	
102 case 780 #	1
103 frequency cover 886#	1
104 rubber SC00080418-2	2
105 pin 2P ( 2.5 41*40P )	2
106 switch KFC-A04-1H1.5	3
107 780 handheld	1
108 wire 0.8*5CM	2
109 display M10245	1
780 handheld	
110 780A 780A#	1
111	
104 780 handheld	1
105 780 handheld 780 hand MIC battery a PC	1
106 781 handheld 780 hand inside the MIC	1
107 782 handheld 780 hand MIC tail an inside	1
109 783 handheld 780 inside segment	1
110 windscreen	1
111 rubber ring	1
112 ball	1
113 capsule 0K-33-250	1