INSTRUCTION MANUAL

STEP 1:

Insert one 9v or "SLR61" battery into the stadium-like controller. It requires total two batteries for two controllers. And then turn the switch to "On", where is located on the top of the batteries socket.





STEP 2:

Insert two 1.5v "AA" batteries into one shoe. It requires total four batteries for two shoes.



STEP 3:

Install the shoe kick in the front of the shoe.



STEP 4:

Open the controller's cover, and then turn the switch to "On" position. The left small joystick is for advancing and backing off. The right joystick is to control left and right movement.





Now you are ready to kick the ball around and win your championship.

Warning: Choking hazard of small part, not for children under 3.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

Modifications not authorized by the manufacturer may void users authority to operate this device.