

Search Device Function is Completed - When no device is

found

3 Device List



Found Devices in the Bluetooth Device List






29

3) Display Settings



① Brightness



Level 1 : The darkest Level 9 : The brightest


② Rotation





30


3 Backlight



- In case 10 Second is set up :

If there is not any Key input, Backlight will be fade out getting darker to Brightness Level1

4 Dim Backlight



- Off: When Backlight Time out turns Backlight Off
- On : When Backlight Time out changes to Backlight Level 1

4) <u>FM</u>



1 Preset Add



② Preset Delete




* You can check if currently stored channel is properly operating by moving to the actual frequency after you change Preset channel by Up Down key.

3 Auto Scan



- * if you enter Auto Scanning Mode, you will enter FM Mode from Menu Mode.
- * Current Frequency status of Frequency Bar is on going and increased Preset channel status is marked.
- * Once Scanning is completed, make Preset Channel 1 move to Default Frequency if there is not Preset Channel you are looking for.

4 Stereo



5) Information








6) Recording



1 Encoder



2 Quality



* WMA

Highest: 44.1KHz, 128Kbps High: 44.1KHz, 96Kbps Medium: 44.1KHz, 80Kbps Low: 44.1KHz, 64Kbps

* PCM

Highest: 48KHz, 1536Kbps High: 44.1KHz, 1410Kbps Medium: 32KHz, 1024Kbps Low: 22KHz, 704Kbps


7) System




1 Language




2 Erase Internal Memory



3 Erase External Memory



4 Initialize



8)Time



1 Auto Power Off



* Auto Power Off : Automatically Power Off when there is no key pressing on Idle(pause) Mode



14. Warring & Error Message

(1) USB Connect



File & Folder Sync



File & Folder Sync



(2) Sync Notice

1) Sync Notice



Next: Pink Spiders / Little Razorblad



Next: Pink Spiders / Little Razorblad

* A-B Repeat

- If you press ▼ Minus Key during music play, A-B Repeat Mode starts.
- 1) ⁶ A-B Repeat Start) When you press ▼ key once, icon of side picture will be shown...
- 2) [■]A-B Repeat Repeat) If you press ▼ key once again, it will repeat playing the section between A and B.
- 3) If you press ▼ key once again, A-B Repeat mode is over and back to Repeat Icon as it was.

(3) Etc

1) Key Lock



Next: Pink Spiders / Little Razorblad

2) Booting Logo





3) Charging indicator

- While charging, battery icon is scrolled as white color.



- After completion of charging, battery icon is filled with light green color.



4) Power Off



Next : Pink Spiders / Little Razorblad

Scroll Bar processing time is within 2 seconds.

5) Bluetooth Status Icon

: Bluetooth Disable – Power Save & Bluetooth Off

3 : Bluetooth Enable – Bluetooth Device Not Connected

: Bluetooth Enable – Bluetooth Device Connected

<<NOTICE>>

Labeling requirements

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Information to user

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

* IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

FCC ID UQ5NSDVBXG

CE0197

< Notice for Class B digital device >

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the equipment and receiver.
- --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.