Certification

RF Exposure

This device complies with RF exposure requirement.

For European Community Users

We have included this bulletin to comply with Directive 2012/19/EU OF THE EURPOEAN PARLIAMENT AND OF THE COUNCIL of 4 July 2012 on Waste Electrical and Electronic Equipment (WEEE)

This product has required the extraction and use of natural resources for its production. It may contain hazardous substances that could impact health and the environment, If not, properly disposed.

In order to avoid the dissemination of those substances in our environment and diminish the pressure on the natural resources, we encourage you to use the appropriate take-back systems for product disposal.
Those systems will reuse or recycle most of the materials of the product you are disposing in a sound way.

The crossed out wheeled bin symbol inform you that the product should not be disposed of along with municipal waste and invites you to use the appropriate separate take-back systems for product disposal.

If you need more information on the collection, reuse, and recycling system, please contact your local or regional waste administration.

You can also contact your supplier for more information on the environmental performances of this product.

CE Compliance (for EU only)

This product is labeled with the CE mark in accordance with the provisions of the applicable RoHS Directive 2011/65/EU for this product and the electric accessories.

Contents

UHF RFID Sled

AC/DC Adapter (5V2A)   US Plug

Handstrap   USB Type-C Cable

Hardware Overview

1. UHF RFID Antenna
2. Trigger
3. Power Key
4. Mode Change Key
5. USB Type-C Connector
6. LED Indicator

JANAM

UHF RFID Sled for XT2/XT2+
Quick Start Guide

Technology at Work.®

Hand Strap

Charging the UHF RFID Sled

The UHF RFID Sled and XT2/XT2+ are charged individually. Charge the UHF RFID Sled by inserting the USB Type-C cable to the connector. The UHF RFID Sled is fully charged when the charging LED turns solid green.

<Caution>

Use only Janam batteries and recharge batteries using only Janam approved charging accessories. Follow all usage, charging and maintenance guidelines in the Product User Guide. If you have questions, contact Janam.

LED Indicator

| 1. Charging LED	Solid Red	Battery is charging
	Solid Green	Battery is charged
2. Power LED	Solid Red	Power is On
	Blinking Red	Power is low
	Solid Green	BT is connected
	Blinking Green	BT is connected and power is low
	Solid Orange	USB connected to PC
	Blinking Orange	USB connected to PC and battery is low
3. Mode LED	Red	BT SPP connected
	Green	BT HID connected
	Orange	Connected to BT pairing app or USB connected
4. Status LED	Red	UHF RFID ready
	Green	Barcode scan ready

Demo App Installation

1. Search 'UHF RFID Sled' from the Google Play Store
2. Install Demo App

Specifications

Item	Specifications
Frequency	UHF 900MHz
Protocol	ISO 18000-63(18000-6C) / EPC global Class 1 Gen 2
Output	Max. 30 dBm(1Watt), 1dBm unit
USB	USB Type C / USB to Serial Communication
Bluetooth	Bluetooth v4.1(Classic + Low Energy) / SSP Profile
HID	HID support
LED	LED(Charge / Power / Sync / Status)
Button	Power, Mode
Buzzer	Max, Min, Mute
Configurations	RFID only or RFID with 2D scanner(Optional)
Size	70 x 139 x 115.8mm(W x H x D)
Battery	3,350 mA, 3.6V Li-ion
Battery Charge Time	AC : About 4H(5V/1.4A) PC USB : About 8H(USB 2.0, 5V/500mA)
Drop	1.5M
Adaptor	5V / 2A
Weight	350g

Bluetooth Pairing

1. Pair the UHF RFID Sled with the XT2 or XT2+ using Bluetooth.
2. Launch the UHF RFID Sled Demo App.

RFID Tag Decoding

1. Aim the device at the RFID tag.
2. Press the trigger to read the RFID tag.

www.janam.com

Technology at Work.®