User manual 1/2

CAP sensor

The cap sensor is mounted to the end of the valve stem in place of the valve stem cap.

Feature:

- Easy to install The replaceable battery
- Battery life time is 2years
- Water proof
- Anti-theft housing needs the special designed wrench to remove the cape sensor



Specification

Frequency	433.92MHz
Operating temperature	-40°C ~ 80°C (-40 to 176 F)
Operating pressure	100kPa~1500kPa (0 ~ 15 bar)
Battery life	2 years in normal condition
Size	27 mm (D) / 23 mm (H)
Weight	15.4g

User manual 2/2

Confidential _ Seetron

FCC Warning Statement

FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complies with FCC Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with a minimum distance of 10cm between the radiator and your body.

FCC ID: UVNTP2-TRUCKER-CS