Installation Guide

Part List

Quick Installation Guide P10 Printrer



3.Install paper roll with paper pointing up. Insert the shaft into the paper roll. 1. Open the lid. Light guide

Power Key Funtion Key -

Feed Key





4.Pull out a small amount of paper, close lid.

Paper

LED Error Code

LED Status Code

Bluetooth

An error has occurred (see Error Code) Bluetooth module Charging finished Data transaction Via Bluetooth normal status Power on available Charging Constantly lit Constantly lit Constantly lit together -lashing Flahsing ij O

Mode Key - Press Mode Key to make discoverable for 90 seconds

1st Connect - Discoverable until 1st connection

is established

Always - Always discoverable

Discovery Modes (factory set)

Device name and PIN label can be found under

Device name and PIN

the paper roll

- Do not disassemble the Printer, battery Only qualified technicians may service the device.
 Do not use Printer near water.

Charge printer

Load Paper

- Use desk and mobile PC USB port connect into
 - micro USB of the printer

 2. When charging the LED will be red, when the battery is fully charged, the LED will turn off. Note: Don't provide AC adapter for P10



Insert plug here



0

FCC/CE Statement

FCC Compliance Statement

Indicator

Remedy

description

pattern

- This device complies with part 15 of the FCC Rules. (1) This device may not cause harmful interference, Operation is subject to the following two conditions: and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are This equipment generates uses and can radiate radio frequency energy and, if not installed and used in interference to radio communications. However, there which can be determined by turning the equipment off NOTE: This equipment has been tested and found to accordance with the instructions, may cause harmful the party responsible for compliance could void the harmful interference to radio or television reception, is no guarantee that interference will not occur in a particular installation. If this equipment does cause and on, the user is encouraged to try to correct the designed to provide reasonable protection against harmful interference in a residential installation. user's authority to operate the equipment.

Recharge the battery

Battery voltage is too low

Blue LED will flash when connecting / disconnecting from Apple devices

Supports iOS 4.0 and higher

Press Mode Key twice to disconnect and press

twice again to reconnect Using with Apple devices

Wait untill the print head

cools down

overheated Print head

Check the tansmission

A transmission error occurred

status

Add paper

Out of paper

interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and

0

(

9



FCC Compliance Statement

Increase the separation between the equipment and receiver.

different from that to which the receiver is connected. Connect the equipment into an outlet on a circuit Consult the dealer or an experienced radio/TV

RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in technician for help.

EU Regulatory Conformance

portable exposure condition without restriction.

essential requirement and other relevant provision of Directive 1999/5/EC OF THE EUROPEAN 1999 on radio equipment and telecommunication terminal equipment and the mutual recognition of declares that this equipment complies with the PARLIAMENT AND THE COUNCIL of March 9, Compliance Statement Hereby, Blue Bamboo Europe-R&TTE

their conformity(R&TTE).
CE NB Mark: C €2200

For warranty period, repair and service issues, please contant your distributor: