
MC95XX Series
Quick Start Guide







FEATURES

- 4 Microphone
- 5 Power Button

Note 1: To warm boot the MC95XX, press and hold the Power button To cold boot the MC95XX, press and hold the 1, 9 and Power button.

9 Scan/Decode LED

11 Charging/Battery

12 Radio Status LED

Status LED

for five (5) seconds.

(with screen protector)

22 Battery Release Button

KEYPADS







Calculator Numeric



1 Insert the Battery

GETTING STARTED










2 Charge the MC95XX






Slow Blinking Amber = Charging Solid Green = Fully Charged Fast Blinking Amber = Charging error Solid Red = Un-healthy battery

It is recommended that this product be charged for 24 hours before the first use to ensure that the internal battery is fully charged.

Charge the Battery

4-Slot Battery Charger

1-Slot Spare Battery Charger



Enter Your PIN


After installing the SIM card activate your

3. Enter the PIN from your service provider.



PHONE SETUP

- 1. Remove battery pack.
- 2. Remove SIM cover using flathead screwdriver.
- 3. Slide SIM card holder to the left. 4. Lift card holder.
- 5. Insert SIM card into SIM holder.




- 6. Lower the SIM card holder down.
- 7. Slide SIM card holder to the right to lock into place.
- 8. Reinstall SIM cover and secure screw.




mobile service connection. In most cases, SIM cards are preset with a PIN (Personal Identity Number), provided by your service provider.

- 1. Press the Power button to turn on the
- 2. Tap Start > Phone.
- 4. Tap Enter.







COMMUNICATION



3 Install ActiveSync®








Follow the on-screen ActiveSync instructions to

establish a connection between the MC95XX and the host computer.





Charging/Battery Status:

- Slow blinking amber: Battery charging
- Solid green: Fully charged
- Fast blinking amber: Charging error


· Red: Scanning active

8 C- D- E/



Flashing blue: RF activity







Press the Battery Status button.

Charge Level Indicator display

approximete battery level.

Charge Level Indicator

Battery Indications











SUPPORT INFORMATION

ACCESSORIES

More Information on the MC95XX

Visit the Motorola Web site at http://www.motorola.com/mc9500

Setting up, using and troubleshooting the MC95XX

MC95XX User Guide MC95XX Integrator Guide Available at: http://www.motorola.com/mc9500

Additional Software

Check Motorola web site for approved applications. http://www.motorola.com/mc9500

Connecting and synchronizing with the host compute

ActiveSync® Help on the host computer. To view help, start ActiveSync® Click Help - Microsoft ActiveSvnc Help.

Information on using programs on the MC95XX

Tap Start - Help within the specific program.

MOTOROLA and the Stylized M Logo and Symbol and the Symbol logo are registered in the U.S. Patent and Trademark Office. All other product or service names are the property of their respective owners.




microSD Card Installation

- 1. Remove battery pack
- 2. Remove SIM cover using flathead screwdriver.
- 3. Slide microSD card holder to the left.
- 4. Lift card holder.
- 5. Insert microSD card into holder.

The proper position of the microSD card the card connector (i.e., gold area) should be facing outward with the bevelled corner facing away.

- 6. Lower the microSD card holder down.
- 7. Slide card holder to the right to lock into
- 8. Reinstall SIM cover and secure screw.
- 9. Reinstall battery pack




Screen Protector


Motorola recommends the use of a screen protector to minimize wear and tear. Screen protectors enhance the usability and durability of touch screen

- Protection from scratches and gouges Durable writing and touch surface with tactile feel Abrasion and chemical resistance
 - Glare reduction
 - Not using a screen protector can affect your warranty coverage.

An initial screen protector is already applied to your MC95XX Contact your local account manager or Motorola, Inc. for more information and purchasing details. Part number: KT-67525-01R Screen Protector 3/pk.


















Four Slot Charge Only Cradle

CABLE CONNECTION




One Slot Battery Charger




Four Slot Battery Charger

Magnetic Stripe Reader



DATA CAPTURE OPTIONS



GPS Information

When using the GPS feature of the MC95XX:

- Acquiring satellite signals may take a few minutes. It is best to be outside and have a clear, unobstructed view of the sky.
- Without a clear view, acquisition takes much longer and could result in the MC95XX being unable to compute the initial position quickly.
- Obtain a satellite fix before moving.
- Shutdown GPS application when not in use.

Scanning/Imaging



OPTIMUM SCANNING AND IMAGING

Laser Scanning














Camera Decode





- . Launch a bar code reading application


- target over the bar code. When the MC95XX decodes the bar code the target turns green.







- Videos > Camera.
- Point the MC95XX at an object.
- Press the Enter button
- Hold MC95XX still until "Shutter Sound" is heard,



ERGONOMIC CONSIDERATIONS



Taking breaks and task rotation recommended



MOTOROLA





