N-4Q 27MHz Radio Control RF Board

COMPONENT	DESCRIPTION	FORMAT
C28	0	0805 SMD
C31	0	0805 SMD
JP2	0	0805 SMD
R1	0	0805 SMD
R7	0	0805 SMD
R9	0	0805 SMD
R18	0	0805 SMD
R53	0	0805 SMD
R27	1.2K	0805 SMD
R16	1K	0805 SMD
R40	1K	0805 SMD
R24	3.3K	0805 SMD
R14	4.7K	0805 SMD
R15	4.7K	0805 SMD
R43	5.1	0805 SMD
R44	5.1	0805 SMD
R13	10	0805 SMD
R29	10K	0805 SMD
R30	10K	0805 SMD
R31	10K	0805 SMD
R10	12K	0805 SMD
R25	15	0805 SMD
R36	18K	0805 SMD
R11	33	0805 SMD
R28	33K	0805 SMD
R41	47	0805 SMD
R21	330	0805 SMD
R26	560	0805 SMD
R2	680	0805 SMD
R37	820	0805 SMD
VR1	10K	5*5MM Manual
VR2	10K	5*5MM Manual
C16	5p	0805 SMD
C30	10p	0805 SMD
C51	27p	0805 SMD
C15	33p	0805 SMD
C17	33p	0805 SMD
C23	•	0805 SMD
C23	33p 120p	0805 SMD
C53	•	0805 SMD
C52	150p	0805 SMD
	180p	
C29	10n 10n	0805 SMD
C49		0805 SMD
C50	10n	0805 SMD
C11	10n	0805 SMD

C1	100n	0805 SMD	
C2	100n	0805 SMD	
C3	100n	0805 SMD	
C4	100n	0805 SMD	
C5	100n	0805 SMD	
C7	100n	0805 SMD	
C8	100n	0805 SMD	
C9	100n	0805 SMD	
C10	100n	0805 SMD	
C12	100n	0805 SMD	
C13	100n	0805 SMD	
C14	100n	0805 SMD	
R8	10uF	0805 SMD	
C35	330p	0805 SMD	
C36	330p	0805 SMD	
C32	B182J/50V	5MM Manual	
C54	B470P	0805 SMD	
Y1	27MHz	XTAL1 Manual	
L5	4309	Manua I	
L1	4310	Manua I	
L2	4310	Manua I	
L8	4310	Manua I	
L4	3.3uH	CECL-3R3K Manual	
Q1	2SC2712-GR	SOT-23 SMD	
Q5	2SC2712-GR	SOT-23 SMD	
Q6	2SC2712-GR	SOT-23 SMD	
Q2	2SC2859Y	SOT-23 SMD	
Q3	2SC2859Y	SOT-23 SMD	
Q4	2SC4735F	FLP	
D1	02DZ6.8V	SOD-323 SMD	
D2	1SV231	SOD-323 SMD	
RP1	3PIN WIRE	Manua I	
L6	110	Manua I	
L7	10MM JUMP WIRE	Manua I	