873-080X00A-03




Fixing of the optional safetybelts

- Turn the backside of the mirror to you.
- Push the belts in the four adaptors near the holder, the part with the buckle must be on the upper side of the mirror.
 - Adjust the length of the belts at the part with the latch, according to the size
 - of your original rearviewmirror. Put the Vossor on your mirror and push the latch in the buckle.
- To unbuckle it again, just push at the middle of the latch and pull it apart.

Montage der optionalen Sicherungsbänder

- Drehen Sie den Spiegel mit der Rückseite zu sich.
- Schieben Sie die Halter der Sicherungsbänder in die vier Aufnahmen neben dem Halter, der Gurt mit der Schnalle muß auf der Oberseite montiert werden.
- Stellen Sie die Länge der Bänder entsprechend der Größe Ihres Originalspiegels ein.
- Befestigen Sie den Vossor auf Ihrem Rückspiegel und schieben Sie die Lasche in die Schnalle.
 - Um die Verriegelung zu lösen, drücken Sie auf den mittleren Teil der Schnalle




Fijación de las correas de seguridad opcionales

- Gire el espejo hacia usted por la parte posterior.
- Haga presión sobre las correas en los cuatro adaptadores cercanos al soporte, la
- parte con la hebilla debe estar en la parte superior del espejo. Ajuste la medida de las correas con el pestillo , de acuerdo con la medida de su retrovisor original.
 - · Coloque el VOSSOR en su retrovisor y presione el pestillo en la hebilla
- Para desabrochar de nuevo, simplemente presione en medio de la hebilla y retirelo

Monteren van de spiegel met de bijgeleverde riempjes

- Draai de spiegel met de rugzijde naar u toe.
- Plaats de metalen stripjes aan de uiteinden van de riempjes in de daarvoor
 - bestemde 4 openingen.
- De 2 sluttingen moet aan de bovenzijde geplaatst worden. Stel de lengte van de riempjes in op de grootte van de originele binnenspiegel. Bevestig de VOSSOR Plus aan de originele binnenspiegel en sluit de sluttingen van
 - de riempjes.
- Om de sluitingen van de riempjes weer te openen drukt u op de vergrendeling van de sluiting waarna deze losgaan.



Supports handsfree & headset profile Vossor Plus can be used as a handsfree unit or a headset as the situation demands.

Excellent voice tone


You can have a conversation without noise and feedback

You can identify the Caller ID of an incoming call. Caller ID display



Speaker Volume control /Microphone gain adjust ··············8 Ending/Rejecting a Call Ttransferring audio Call Waiting9 Button functions and LED status Basic Use Power on Features..... Charging battery with Cigar lighter adapter················5 Setting up VOSSOR PLUS Options for power supply Pairing with a Bluetooth mobile phone How to use

Part Description



Included Acessories



Battery Rechargeable Li-Ion



Cigarette lighter adaptor

Manual

Trouble Shooting10

Precautions Specifications12 ผ

Button functions and LED status

ile	Headset	>	>	>-	>	z	>	z	z	z	z	>	>	;
Support Profile	Handsfree Hea	>	>	>	>	>	>	>	>	>	>	>	>-	;
	How to use button	Press and Hold	Press	Press and Hold	Press	Press	Press	Press	Press @	Press	Press	Press	Press	Press
VOSSOR	Status	BT not Connected	BT not Connected		Ringing	Ringing	Talking	Talking	Talking		Talking			Talking
;	Functions	Pairing mode	Searching	Voice dialing (Only when user's mobile phone supports this function.)	Answering a Call	Rejecting A call	Ending a Call	Transferring audio(Mirror to Handset)	Transferring audio(Handset to Mirror)	Last number Called	Call waiting	Volume Increase	Volume decrease	Microphone

>	Υ
>	Υ
ON OFF	ON OFF
Switch	Switch
Power ON	Power Off

LED Status

LED	Status	VOSSOR Status
Blue LED	Flashing	Searching Paired devices
Blue LED	Light on	Bluetooth connected
Red LED	Flashing	Low battery
Blue+Red LED	Flashing Alternately	Paring mode

က

Options for power supply

Option1 VOSSOR PLUS+Battery(inside)

The battery is not charged when it is first delivered to the user. Charge the battery with the provided charger before using VOSSOR PLUS.

Basic Use

Charging the battery with Cigar lighter adapter







1.Connect the Cigar lighter adapter to a power outlet.

Option2 VOSSOR PLUS+Battery+Cigar lighter



2.Connect the Cigar lighter adapter to DC power Jack of Vossor Plus.



- Tips * It takes about 4 hours to fully charge the battery.

Setting up VOSSOR PLUS

First, place the upper holder of VOSSOR PLUS to the top side of the rear-view mirror in your car.Push MHF83 closely to the mirror and place the lower holder of VOSSOR PLUS to fit completely.





Place VOSSOR PLUS in the center of the rear-view mirror in your car. If not, the sound could be diminished.

Pairing with a Bluetooth mobile phone

After pairing the Bluetooth mobile phone with VOSSOR PLUS, you can use it as a handsfree unit.

1. Power on, turn on the Power switch




2. Press the END button for more than 2 seconds When Blue LED flashing slowly (every 4 seconds). *The blue LED and red LED will flash alternately.



3. From the handset, search for and register the name "SEECODE" of VOSSOR

*Please refer to the user's manual of the handset.

*Enter "0000" when a pincode(or passcode) is requested.
*when the pairing is completed, the VOSSOR PLUS will display "CONN".



- Tips Pairing can be done with up to a maximum of 8 handsets.

VOSSOR PLUS stores up to 8 different phones in memory. * Keep in mind that the latest phone number removes the earliest one when the memory is full.

* Priority is given to the most recently connected handset.
* If you want to change the handset priority, try to connect VOSSOR PLUS from the

<u>.s</u> * If the latest connected handset supports handsfree profile, VOSSOR PLUS connected automatically to the handset when the power is on. If your mobil phone doesn't support the automatic reconnect, just switch off the vossor+ and switch it on again, it will then connect with the paired mobile

_

Call Functions

Turn on the Power switch.

Power on





Turn off the Power switch.

Power off





*During call press volume up for more than 2s will set to High. *During call press volume up for more than 2s will set

*For higher volume, press *button. *For lower volume, press ▼button.

Microphone gain adjust

Speaker Volume control



Press SEND and Audio Transfer button Simultaneously.

Microphone mute

to Low.



Last number/Voice dialing

Press SEND button.

*You can re-dial the latest number by pressing this (In the case of some handsets, voice dialing initiates) *You can activate the voice dialing by holding this

ω

Answering a call

Press SEND button to answer a call. *You can have a conversation through VOSSOR PLUS.



Ending/Rejecting a call

Press END button to end/reject a call.



Transferring audio

VOSSOR PLUS To Handset: Press Audio Transfer button of VOSSOR PLUS while you are talking. *It can be transferred to the handset without ending a call.

Handset To VOSSOR PLUS: Press Audio Transfer button of VOSSOR PLUS while you are talking. *It can be transferred to VOSSOR PLUS without ending a



Call Waiting

To receive a second call while answering the first call, press Send Button of the VOSSOR PLUS.
*To get back to the first call, just press Send Button again.

Troubleshooting

VOSSOR PLUS does not turn on.

Check Whether the battery of VOSSOR PLUS is fully **P** Charge the battery. Check Whether the Power cable is P Insert cable again. inserted properly. charged.

Whether the Power switch is **P** Turn on Power switch. turned on. Check

Can not have a conversation through VOSSOR PLUS.

P In order to have a conversation through VOSSOR PLUS, a Bluetooth handset that supports handsfree profile is required. Check Whether the handset supports handsfree profile.

Check Whether the battery of **P** Charge the battery. Vossor Plus is low.

Can not pair VOSSOR PLUS with the Bluetooth device.

Check Whether the VOSSOR Press and Hold End button PLUS is in pairing mode. **P** to enter pairing mode.

No Sound from the speaker.

Gheck Whether the volume status is ▶ Press the Volume up button. at lower level.

6

Precautions

Do not drop the unit from high places.



Do not modify, repair nor take apart at discretion. Do not expose directly to the water, alcohol, benzene, etc. for

Do not expose directly to flammables.



Do not place nor keep the unit near the flammables. *It may cause an explosion.

Do not disassemble the battery. *It may cause an explosion.



Do not place heavy objects on the device.

Keep the device away from humidity & dust.







Keep away from high heat.





*Changes or modifications not expressly approved by the party responsible for compliance could void the

user's authority to operate the equipment.
*The device may explode if the battery is replaced incorrectly.
*Dispose of batteries according to local regulations. Do not dispose as household waste.

FCC RF Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any an uncontrolled environment. End users must follow the specific other antenna or transmitter.

12

Specifications

Function	Description
Battery	3.7V, 1700mAH Li-lon
Speaker	8 Ω/1W(Normal)
MIC	-62 +/- 2dB
Power Consumption	Max 250mA
Cigar Lighter Jack OUT:	5V/650mA
Frequency range	2400MHz to 2483.5MHz
Modulation Method	GFSK, 1Mbps, 0.5BT Gaussian
Transmission Power	Typ. 1.0dBm
-	1600 hops/sec
guiddon	1MHz channel space
RX. Sensitivity	Typ83.0dBm
Built in Memory	Flash memory(8MBit)
Operating Temperature	2°02~01-
Storage Temperature	-20~10°C
Noise suppression	Yes
Echo Cancellation	Yes
Supported Profile	Headset and Handsfree
Standby Time	280 hours
Talking Time	15 hours

Disclaimer

®Bluetooth is a trademark owned by Bluetooth SIG. All brand names are the property of their respective owners.

<u>გ</u>

English

Memo

Limited Warranty

- 1. This product was produced under strict quality management and inspection.
- All defective units within the applicable Warranty period/s will be repaired or replaced, in the case those faulty goods were handled normally.
- To get Warranty service, return the unit to the outlet from which the unit was purchased.
 - 4. Fill in this Warranty card and keep it.
- 5. Free of charge Warranty shall not apply to:
- *Defects or damage resulting from use of the unit in other than its normal and intended manner, eg, in excess of their maximum specifications or operating instructions.
 - *Defects or damage from misuse, accident, neglect, improper testing, installation, alteration or modification of any kind, or spillage of food or liquid.

Products name:

Model number:

Purchased date: Warranty period :2 years

Outlet the unit was purchased:

Tel :

Customer Address:

Name:

Tel :

Notes

Several studies have shown that cell phone usage while driving creates a distraction to the driver which may increase the likelihood of an accident. This distraction potential is not aliminated by the use of a handsfree kit, handsfree kits have not been shown to be safer than hand-held phones with respect to driver distraction. When using the phone while driving keep conversations short and resist any temptation to make notes or read documents. Before answering calls consider your circumstances. Pull off the road and park before making or answering calls when driving conditions require (e.g., bad weather, high traffic density, presence of children in the car, difficult junctions or manoeuvres.)

Abide by local laws.

Above by local raws.

The state and local laws where you live restrict the use of mobile phones while driving. It is the owner's responsibility to use this product in compliance with the laws of the place where you live.