24 in

Digital Cordless Phone_

DECT

- Expandable
- Speakerphone
- Lighted Display

User Guide
VV3800-2-BK

In the box

Handset   Base

Line Cord   Bracket

Rechargeable   AC   User
Battery   Adapter   Guide

Getting started

Installing the battery
1. Open the battery cover.
2. Insert the battery as shown.
3. Close the battery Cover.
4. Place the handset on the base to charge.

i Before using for the first time, charge the handset for 12-16 hours

CAUTION
Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
USE ONLY WITH HUIZHOU SHENZHOU SUPER POWER TECHNOLOGY CO LTD., TYPE NO. AAA600MAH 2.4V RECHARGEABLE BATTERY.

Installing the bracket
1. Before installing the bracket, connect the line cord and AC adaptor to the back of the base (see "Connecting").
2. Snap the bracket to the back of the base as shown below.
3. Place the base on a flat surface.

Connecting
1. Plug one end of the line cord into the jack at the back of the phone's base, and the other end into a modular phone jack.

line cord — modular phone jack
insert here
Jack   AC adapter   AC Outlet

2. Connect the AC adaptor as shown above, and plug into a standard AC outlet.
3. The handset will display "Searching", wait until "Handset 1" is displayed.
4. Press [talk] on the handset and confirm you hear the dial tone.

Wall Mounting
To mount your telephone on a wall plate (not included), follow the instructions below:
1. Plug the line cord into a modular phone jack.
2. Align the holes on the base with the mounting studs on the wall plate.
3. Pull the base down onto the studs until the telephone is secure.

wall plate

The handset

Standby Screen

Handset 1
Jan 1 12:00

Answer calls
- answer a call
- start a call
- dial a number from the phonebook or Caller ID history

End calls
- end a call
- in the menu, escape to the standby screen

i Press the [⊗] soft key to mute or disable mute

talk screen
00:30
Mute Soft Key → [menu] [spk] [ ]

Call Waiting / Flash
The Flash feature is used to activate calling services available through your local phone company, such as Call Waiting, and Three Way Calling. To use the features below you must subscribe to these services from your local telephone company.

To answer an incoming call while having a conversation:
After you hear the Call Waiting tone, press and release the [talk] button. The first call is placed on hold and the second call is answered.

press to flash

To return to the first call and put the second call on hold:
Press and release the [talk] button again to return to the first call, the second call will be put on hold.

To activate Three Way Calling:
Press and release the [talk] button while on the first call, you will hear a dial tone. Dial a second number, and press the [talk] button again to connect the two calls.

Using the phone

Speaker
[spk] • to use the speakerphone, press the [spk] button, this can be done before or during a call

Volume
• during a call or while using the speakerphone, use the ▲ and ▼ buttons to increase or decrease the volume

volume screen

Redial
[redial *] • to redial a number, press and HOLD the [ ] button, then use the ▲ and ▼ buttons to select from a list of recently dialed numbers, and press [talk] to make the call

redial screen
555-555-1111
555-555-2222
555-555-3333
555-555-4444
                    Option

Caller ID / Call Waiting Caller ID
IMPORTANT: In order to use this unit's Caller ID features, you must subscribe to either the standard Name/Number Caller ID Service or Call Waiting Caller ID Service from your local telephone company.
This telephone automatically displays an incoming caller's name and telephone number, as well as the date and time of the call. It can record and store the information of up to 30 calls into the phone's Caller ID memory.

Reviewing Caller ID information:
- In the standby mode, use the ▲ and ▼ buttons to review the Caller ID history
- you can select a number and press [ ] to dial it
- to save a number to the phonebook, press the [Option] softkey and then select "Save Number" and press the [ ] softkey to confirm and save

Caller ID screen   **Caller ID options screen**
877-768-8483   Save Number
Aug 20 12:30   Delete
New   Delete All
        Option
[menu] [spk] [ ]   [menu] [spk] [ ]
        Soft Keys

i You can delete a number, or all numbers from the Caller ID history in the Caller ID options screen

---

Phonebook
The phone can store up to 50 names and numbers in its phonebook. Caller information may be saved from the received calls in the Caller ID memory (see "Reviewing Caller ID information"), or entered manually.

Dialing a number from the phonebook:
1. Press the [ ] button to enter the phonebook.
2. Use the ▲ and ▼ buttons to navigate up or down.
3. Press the [ ] button to dial the selected number.

phonebook screen
John Smith
Mike Hayes
Paul Williams
Angela Dotson

Adding numbers to the phonebook:
1. Press the [ ] button to enter the phonebook.
   (open phonebook)
2. Press the [Option] softkey, and select "New Entry" from the phonebook options screen and press the [ ] softkey.
   (multi-press for a,b, or c)
3. Use the handset keypad to enter a name for the entry by multi-pressing a key until the desired letter is displayed.
4. Press [0] to add a space and the [◀C] softkey to go back.
   (add space)
5. When finished entering the name, press the [Save] softkey.
   (small letters / capital letters)
6. Enter the number using the handset keypad.
7. When finished entering the number, press the [Save] softkey.
8. Select a ring tone and press the [Save] softkey to save the number in the phonebook.
9. It is possible to edit and delete numbers in the phonebook from the phonebook options screen.

phonebook screen   **phonebook options screen**
John Smith   New Entry
Mike Hayes   Edit Entry
Paul Williams   Show Details
Angela Dotson   Delete Entry
        Option
[menu] [spk] [ ]   [menu] [spk] [ ]
        Soft Keys

entry screen (name)   **entry screen (number)**
Name: abc   Number:
John Smith   555-555-1234
◀C   Save   ◀C   Save
[menu] [spk] [ ]   [menu] [spk] [ ]
        Soft Keys

Menu
Use the menu to customize various settings such as ringer volume, ring tones, language, display settings and more.

1. Press the [menu] button to enter the menu.
2. use the ▲ and ▼ buttons to navigate from the following selections: Phonebook, Handset, Base Settings, Time, and Tools.
3. Press the [✓] softkey to select an option.
4. Press the [ ] softkey to go back.

menu screen
Phonebook
Handset
Base Settings
Time
[menu] [spk] [ ]
Soft Keys

Intercom
The intercom feature is only available for cordless phone systems with multiple handsets (see "Adding additional handsets" on the reverse side of this user guide).
1. To use the intercom, press and HOLD the [#] button.
2. Dial the number of the handset you would like to call.

intercom screen
Internal_
        End

Paging
• Press [find handset] and the handset will emit an alarm making it easy to find

page handset