


## **Block Diagram (2.401~2.480GHz)**

FCC ID: VO8-BTH820 Model No.: BTH820







## TEST POINT and SOLDERING POINT TABLE NO. DESCRIPTION NO. DESCRIPTION NO. DESCRIPTION 3V3\_USB Default low: module, / P2\_0 high: dongle TP1 RF output TP11 SDP1 BATTERY VBAT SDP2 GND USB+ TP13 Regulator Enable USB-3V3\_USB Default low: module, / P2\_0 high: dongle TP14 SDP4 TP5 (P2.4) Default low: non-boot mode, high: boot mode (or Vol +) GND Earphone+ TP15 SDP5 UART\_RXD Earphone-TP6 TP16 USB+ UART TXD TP17 TP7 USB-Default high: internal memory, low: external memory GND TP8 (EAN) TP18 TP9 Piezo TP19 MFB TP10 Regulator Enable TP18 Vol -CONFIGURATION MODE HIGH LOW EAN INT MEMORY EXT MEMORY P2\_0 DONGLE MODULE ISSC P2\_4 BOOT MODE NON BOOT MODE 2-1 3 65-356 \* FOR BOOT MODE -> EAN:High, P2\_4:High, P2\_0:High Rev 1.0 Bate: Monday, February 06, 2006 Shee