Bluetooth Headset User's Guide

Contents

1 Introduction	headset with your phone2
Bluetooth wireless technology 16	Troubleshooting2
2. Get started17	3. Basic use
Overview	Calling administration23
Chargers and batteries 18	Switch the call between
Charge the battery18	phone and headset24
Switch the headset on or off 19	Use the headset with several phones24
Pair the headset with a compatible phone20	4. Battery information
Disconnect the headset from the phone20	Maintenance20
Reconnect the paired	

15

1. Introduction

The Bluetooth Headset T9 allows you freely to make or receive calls whether on the journey or in the office. You can connect the headset with a compatible phone that supports Bluetooth wireless technology. Read this user guide carefully before using the headset. Read also the user guide for your phone, which provides important safety and mainte -nance information.

Bluetooth wireless technology

Bluetooth wireless technology allows you to connect compatible comm -unication devices without cables. A Bluetooth connection does not require that the phone and the headset should be in line of sight, but both devices should be within 10 meters (30 feet) between each other. Connections can be subject to interference from obstructions, such as walls, or other electronic devices.

The headset is compliant with the Bluetooth Specification 2.0+EDR supporting the following profiles: Headset Profile 1.1 and Hands-Free Profile 1. 5. Check with the manufacturers of other devices to determine their compatibility with this device.

2. Get started

Overview

The headset contains the following parts:

1.Multifunction key()

2.Microphone (1)

3.Charger jack (− € +)

4.Earphone(♠) 5.Earloop(Q)

6.Indicator light (*Q*)

Before using the headset you must charge the battery and pair the headset with a compatible phone.

Note: Parts of the headset are magnetic, Metallic materials may be adhered to the headset.Do not place credit cards or other magnetic storage media near the headset.because information stored in them may be erased.

Chargers and batteries

Check if the charger is the affiliated device before using.

Warning: Use only batteries and chargers approved for use. The use of any other types may invalidate any approval or

warranty, and may be dangerous.

For availability of approved affiliated devices please check with your deal -er. When you disconnect the power cord of any device, grasp and pull the plug, instead of the cord.

Charge the battery

This device has an internal, nonremovable, rechargeable battery. Do not attempt to remove the battery from the device as you may damage the device.

- 1. Connect the charger cable to the headset.
- 2. Connect the charger to an electrical outlet.

The red indicator light is on during charging.

If charging does not start, disconnect the charger, plug it in again, and retry. Charging the battery fully may take up to 2 hours.

3. When the battery is fully charged, the red indicator light turns off and the blue indicater light turns on. Disconnect the charger from the electrical outlet and the headset.

The fully charged battery has power for up to 3 hours-6 hours 30 minutes of talk-time or up to 100 hours-180 hours of standby time. However, the talk and standby time may vary with different mobile phones, products that use a Bluetooth connection, usage settings, styles. and environments.

Switch the headset on or off

To switch on, press and hold the multifunction key(\(\bullet\)), The headset beeps, and the blue indicator light is displayed. When the headset is connected to a paired phone and is ready for use, the blue indicator light flashes slowly. To switch off, press and hold the multifunction key(~). The headset beeps, and the blue indicator light is flashing twice.

19

Pair the headset with a compatible phone

- 1. Press and hold milti-Fanctional button until the indicator light turns on in blue
- 2. Activate the Bluetooth feature on the phone, and set the phone to search for Bluetooth devices.
- 3. Select the headset from the list of found devices.
- 4 Enter the passcode 0000 to pair and connect the headset to your phone. If the pairing is successful, the indictor light will flash in blue 2 times, In some phones you may need to make the connection separately after pairing. See the user guide of your phone for details. You only need to pair the headset with your phone once.
- 5 If the pairing is successful, the headset beeps and appears in the phone menu where you can view the currently paired Bluetooth devices.

Disconnect the headset from the phone

To disconnect the headset from your phone (for example, to connect

20

the phone to another Bluetooth device). you can find how to make it in the following ways:

- Switch off the headset.
- Disconnect the headset in the Bluetooth menu of your phone.
- Move the headset 10 meters (30 feets) away from the phone.

You do not need to delete the bluetooth headset from your phone's blue -tooth device list if you want to disconnect the headset with your phone.

Reconnect the paired headset with your phone

To reconnect the headset with your phone, please switch on the headset and it will be connected with your phone automatically, this is subject to the phone.

Troubleshooting

If you cannot connect the headset with your phone, do as followings: Ensure that the headset is charged, switched on, and paired with and connected to your phone.

Ensure that the Bluetooth function is activated on your phone.

21

Check that the headset is within 10 metters (30 feet) from your phone and that there are no obstacles between the headset and the phone, such as walls or other electronic devices.

22

3. Basic use

Call administration

To make a call, use your phone in the normal way when the headset is connected with your phone. The blue indicator light flashes slowly during the call

If your phone supports redialing with this device, press the multifunction key () for 2 sec. when no call is in progress.

If your phone supports voice dialing with this device, press and hold the multifunction key(\(\sigma\)) when no call is in progress, and proceed as described in the user guide of your phone.

When you receive a call, the blue indicator light flashes quickly, and you hear a ringing tone through the headset. To answer the call, press the multifunction key (), or use the phone keys. If the automatic answer function is on, the phone automatically answers the incoming call after one ring. To reject an incoming call, briefly press the multifunction key () twice. Or use the phone keys.

To end a call, press the multifunction key(\(\bullet\)), or use the phone keys.

■ Switch the call between phone and headset

To switch the call between the headset and a compatible phone, press and hold the multifunction key () for 2 seconds, or use the resp -ective function in your phone.

Use the headset with several phones

You can pair the headset with up to eight phones but connect it with only one phone at a time.

The phone that was first paired with the headset is the default phone, If the headset is switched on within 10 meters (30 feet) of several paired phones, the headset tries to connect with the default phone. If the headset cannot connect with the default phone, the headset tries to connect with the last used phone if the headset cannot connect with

this phone either, one of the other six paired phones can be connected with the headset.

To make the connection, see the user guide of your phone.

24

4. Battery information

Your device is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but it will eventually wear out. Recharge your battery only with approved chargers designated for this device.

Unplug the charger from the electrical plug and the device when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.

Never use any charger that is damaged.

Leaving the device in hot or cold places, such as in closed car in summer or winter conditions, will reduce the capacity and life time of the battery.

Always try to keep the battery between 15°C and 25°C (59°F and 77°F). A device with a hot or cold battery may not work temporarily, even if the battery is fully charged. Battery performance is particularly limit -ed in temperatures below freezing.

Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste.

Maintenance

Your device is a product with superior design and craftsmanship and should be treated with care. The suggestions below will help you protect your warranty coverage.

Keep all accessories and enhancements out of reach of small

Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, allow it to dry completely.

26

 Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.

25

- Do not store the device in hot areas. High temperatures can shorten the life time of electronic devices damage batteries and warp or melt certain plastics.
- Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not attempt to open the device.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.

All of the above suggestions apply equally to your device, battery, charger, or any enhancement. If any device is not working properly, take it to the nearest authorized service facility for maintenance.

FCC ID: V08-N76

FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to

the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference

that may cause undesired operation.

Note: The manufacturer is not responsible for ANY interference, for example RADIO or TV interference, caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the

14