

### SHARP

P8000 Series

### 4K UHD Smart TV Quick Start Guide

Help SHARP improve the environment by reducing paper waste. For detailed instructions and feature descriptions, access the full User Manual online. Before using the TV, please read this guide carefully and keep it for future reference.

© 2017 Hisense Company Ltd. All Rights Reserved.

manner, electronic, print, or otherwise, without the prior written consent of Hisense Company Ltd., is a violation of Hisense Company Ltd. International copyright and/or other intellectual property laws. Reproduction or transmission of the materials, in whole or in part, in any All material in this Quick Start Guide is the property of Hisense Company Ltd. and its subsidiaries, and is protected under US and rights under the aforementioned laws.

otherwise, whether or not for a charge or other or no consideration, without the prior written permission of Hisense Company Ltd. No part of this publication may be stored, reproduced, transmitted or distributed, in whole or in part, in any manner, electronic or Requests for permission to store, reproduce, transmit or distribute materials may be made in writing to the following address:

JSA: Hisense USA Corporation

PO Box 3289

Suwanee, GA 30024

CANADA: Hisense Canada Co., Ltd

2283 Argentia Road, Unit 16

Mississauga, ON, Canada

L5N 5Z2

MEXICO: Hisense Mexico S. de R.L. de C.V.

Blvd. Miguel de Cervantes Saavedra No 301

Torre Norte Piso 2, Col. Ampliación Granada

Miguel Hidalgo, Ciudad de México, C.P. 11520

'Sharp™", "Aquos™", "Quattron™" and any and all other Sharp product names, logo's, slogans or marks are registered trademarks owned exclusively by Sharp Corporation. "Hisense™", and any and all other Hisense product names, logo's, slogans or marks are registered trademarks and intellectual property rights of Hisense Company Ltd. and its subsidiaries.

This product is sold to you under one or more license agreements between Sharp Corporation and Hisense International (Hong Kong) America Investment Co. Ltd. All other trademarks are the property of their respective holders.

# 4K color that'll give you chills

# Smart LED TV with Popular Features

- Ultra-fast access to launch Netflix®
- Numerous built-in social media, gaming and movie apps
- · Thousands of movie titles and streaming content to view
- · 4K Media Player and Receiver
- App Store and Web Browser
- Many other cool features

## High-Quality Picture and Sound

- Vibrant contrast and brightness to display images accurately
- dbx-tv® Award-winning sound
- 4K technology that supports 4K online streaming, 4K USB content, HDMI 2.0 devices and much more to maximize your entertainment experience
- Standard Dynamic Range with HDR10-compatible

### **Multiple Connection Methods**

- · Built-in wireless connection
- 3 USB Connectors (2 USB 2.0 Connectors and 1 USB 3.0 Connector)
- 4 HDMI Connectors (2 HDMI 4K@30Hz Connectors and 2 HDMI 4K@60Hz Connectors)
- 1 LAN (Ethernet) port

# Easy Setup Menu and Simple Design

- Short and easy-to-follow first-time setup menu
- · Simple user interface (UI) design to navigate
- Descriptive features to help make your selections

### Register Your TV!

Congratulations on the purchase of your new TV! This Quick Start Guide will walk you through a few easy steps to set up your TV. For detailed instructions, access the User Manual on the support pages listed below. Because we value your business, we want to keep you in the know of 'all things SHARP'. Using your mobile phone, scan the Registration page QR code to register your TV. Depending on the make and model of your phone, you may need to download a QR code scanning

Country	Customer Care Center	SHARP Support Page	REGISTER YOUR TV
A.S.	• Phone: 1-888-935-8880 • Hours of Operation: Monday - Friday: 9 AM to 9 PM EST Saturday - Sunday: 9 AM to 6 PM EST • Service Email: support@sharptvusa.com	http://www.sharptvusa.com	www.sharptvusa.com/
CANADA	• Phone: 1-855-271-6271 • Hours of Operation:  Monday - Friday: 8 AM to 8 PM EST • Service Email: Canadasupport@sharp-canada.ca	http://www.sharp-canada.	No need to register
MEXICO	• Phone: 01-800-999-7277 • Hours of Operation: Monday - Friday 9:00-18:00 • Service Email: servicio@SHARPTV.com.mx	mx/support/ *Scan to download user	http://www.SHARPTV.

**Disclaimer:** This Quick Start Guide is intended as a general guideline to help you set up your TV. Images throughout this document are for illustrative purposes only and may differ from the actual product.

### PACKAGED CONTENTS

Your package in which you purchased your new TV contains the following items:

- 2 base stands
  - Power Cord
- Remote Control

- Quick Start Guide (this document)
- Important Safety Information and Warranty Card

 1 set of AAA batteries 4 screws (M4×12)

#### **IMPORTANT**:

To prevent accidentally discarding items that came with your TV, be sure to check ALL of the foam in the carton box.




- · Please check foam for accessories before discarding.
- · Veuillez vérifier la mousse pour qu'il n'y ait pas d'accessoires avant de la jeter.
  - · Antes de desechar la espuma, asegúrese de retirar todos los accesorios.

### Required tools and devices

- Wireless router (not included) for Internet connectivity
- Phillips screwdriver (not included) to secure the TV stand
- HDMI and other types of cables (not included) to connect external devices to the TV
  - Wall mount bracket (not included) if you prefer to mount the TV to the wall

# **BUTTONS AND PORTS ON THE TV**



4

# STEP 1. Attach the TV Stand or Wall Mount Bracket

### Attach the TV Stand


#### CAUTION:

- Be sure to disconnect the A/C power cord before removing a base stand or installing Wall-Mount brackets.
- object, or anything that could scratch or damage the screen display, comes into contact with it. DO NOT exert pressure on the front of • The screen display is very fragile, and must be protected at all times when installing the base stand. Be sure that no hard or sharp the TV at any time because the screen could crack.

Follow the illustrations and instructions below to complete the installation steps:


#### For 50"/55"

- 1. Carefully place your TV face-down on a soft, flat surface to prevent damage to the TV or scratching to the screen.
- 2. Remove the 2 stands from the accessory bag and then insert the stands into the bottom slots of the TV.
- 3. Use the 4 screws in the accessory bag to secure the BASE STAND to the TV.



#### For 65"

- 1. Carefully place your TV face-down on a soft, flat surface to prevent damage to the TV or scratching to the screen.
- 2. Remove the 2 stands from the accessory bag and then insert the stands into the bottom slots of the TV.
- 3. Use the 4 screws in the accessory bag to secure the BASE STAND to the TV.




NOTE: According to the desktop size, you can select one of the base stand installation, as shown in the figure.

# Attach the Wall Mount Bracket (not included)

Before you begin the third-party manufacturer instructions, be sure to do the following things:


- 1.Place the TV face down on a clean, safe and cushioned surface. 2.Remove the TV stand if you already attached it.
- 3. Place the spacers (not included) in the corresponding bracket



#### CAUTION:

 When you attach the mount, be sure to use the spacers (provided by the third-party manufacturer) between the TV and the bracket.

 To prevent internal damage to the TV and ensure it is mounted securely, be sure to use fixing screws (not provided) that are 9.5 - 11.5 mm in length when measured from the attaching surface of the mounting hook.




Follow instructions provided with the Wall mount bracket.

- To complete the installation, please contact the wall-mount manufacturer or the retailer from which you purchased the TV.
  - The selected screws are 9.5 11.5 mm in length when measured from the attaching surface of the rear cover.

NOTE: The diameter and length of the screws differ depending on the Wall-mount bracket model.

# STEP 2. Connect devices to your TV

Check to ensure that you have selected the right cables for the ports and that they are connected securely. Loose connections can affect the quality of the picture image and color.



Brief Description	Connect an optical cable from an external digital audio system.	Connect headphones to hear audio from the TV.	Connect an audio adapter (not provided) from an external analog audio system.	Connect a USB 3.0 device to USB 3 to transfer photos, music and movies to your TV at a rate that's 10 times faster than the USB 2.0 port. NOTE: You can still plug a USB 2.0 device into a USB 3.0 port; however, the rate of speed will not be as fast. USB 3.0 devices are also backwards compatible with USB 2.0 ports.	Connect an Ethernet cable to access a network or the Internet. The TV also has a wireless connectivity feature.	This port is not available for you to connect an external device. It can only be used by our factory for testing purposes.
External Equipment	Audio Amplifier Speaker		Speaker Audio Ampliffer		LAN	ou to connect an external device. It o
Cable		Ü	White			This port is not available for y purposes.
Port		0				•
TV label	DIGITAL AUDIO OUT	O AUDIO OUT		÷	LAN	SERVICE