2. Installation Steps

for an insuli discrete at particle owing is a blor supe. Four hard some questors againing is allabora places cone, you osciol polici, (2009-2012).

2.1 Connecting HDMI cable

Connect Horizodea (3): VW.P. HDMI jick, If your IV is cot, types farit.



FORM or kay relations must reveal as need parents a represent a result to present on eligible locations.
 Includes hard suppression to the conference of the result of the conference of

2.2 Connecting the Antenna

Connect one end of the antenna cable to the ANT IN on the back of the receiver and the other end to a terrestrial antenna connection or the jack for the public anterna on the wall.

2.3 Connecting Power cable


Connect the Power cable with the receiver as well as the electric socket.



2.4 Turning On and Off Your Receiver

Power On

1. Lanuar trepezant switch exercisal the back of hereceism.
2. Pessite STANDBY buffer on the front of the series on the remote count.



Installation Guide

CLARO SC7210

Power Off Test the STANDBY button again The race versal display Off.

2.5 Connecting other equipments

2.5.1 Connecting Audio & Video cable Ifyou have Audio cable If you have Audio cable and Video cable(CVBS or YPBP), you can watch TV by connecting them with TV and the receiver.

 $2.5.2 \ \, \text{Connecting the receiver with VCR} \\ \text{You can connect the receiver with VCR by using Scart cable or Audio \& Wideo cable.}$

2.5.3 Connecting the receiver with Audio System You can connect the receiver with Audio System by using audio cable.

Installation Notice

if degraded picture quality is observed while viewing copy-protected pay-per-view programs, connect the set-top box directly to the TV set. Do not connect through a VCR.

2

Please read the entire manual thoroughly and retain it for future reference.

Important safety instructions

Cautions



CAUTION : To reduce the risk of electrical shock, do not remove the cover. No user serviceable parts inside. Refer any servicing to qualified Service personnel.

Read this manual carefully before using the product. The cautions described below contain important information to the carefully the company will not take any responsibility for accidents or damage resulting from carefuss handling by the user.

This item incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Rovi Corporation, and is intended for home and another limited viewing uses only unless otherwise authorized by Rovi Corporation. Reverse engineering or diseasembly is prohibited.

Caution: Any changes or modifications to the equipment not expressly approved by the party responsible compliance could void user's authority to operate the equipment.

1. Introduction

1.1 Front Panel



Connection JSB Mass are age device for VW upgrade. 1 USB 2 MICRO SD

The front of the product is subject to change without notice.

1.2 Rear Panel

CLARO SC7210



- 1		
-	RESET	
2	AV OUT	W ou⊤
m	S/PDIF	To connect a cigital ampliher output
4	HDMI	Neithe H0All rathers connect the lask not the FDM. Jack on your the existin for the best quality picture.
2	RJ45	Connect the telephone line.
9	6 12V1A	6 12V 1A To connect your decoder to the mains power supply.

🕏 The design of the Front/Rear Panel may be changed without any notice in advance.

This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited. * Product Notice

NOTE. This equipment has been tested and found to comply with the limits for a class B digital device programment and reference to the complex of the comple

—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a forcul different from that to which the receiver is connected.
—Connect the delainment of an experienced radio/TV technician for help.

N