字体颜色:银色专色(877C)

60.00 mm — Guofen7 注意事项 / 温馨提示 Precautions / Tips 前言 Preface Preface Precautions / Tips TWS Dear Customer 尊敬的用户: 注意事项: Cautions 20.00 非常感谢您选用 " 果粉 7TWS " 无线音乐蓝牙耳 ▲ 请在常温环境中存放以及使用本产品; Thank you for choosing "Guofen7TWS" wireless music ▲ Please keep or use this product at normal temperature 机请在使用前,详细阅读本说明书,正确操作使用,更 Bluetooth headset.Please read the user manual carefully ▲ 请勿将本产品暴露在雨中或潮湿环境中 ▲ Do not expose this product in rain or moisture; for proper instruction to maximize the advantage of our 好发挥产品优越性能。我司蓝牙耳机外观设计时尚绚丽 ▲ Do not throw this product in case any damage thus made ▲ 请勿丟掷,避免因跌落造成产品损坏; product. Our Bluetooth headset are well designed, fashio \blacktriangle Do not disassemble, repair or reform this product; 、小巧便携、音质纯美、多功能一体化设计,全系列拥 smart and portable, pure acoustic and multi functional. ▲ 请勿自行拆解、修理和改造本产品; We have patents for the whole series of our Bluetooth ▲ Do not clean this product with any chemical solvents; 有外观设计专利,系统上采用了行业领先电声技术,使 headsets. Our Bluetooth headsets are applied with the top ▲ Do not throw away or put it in fire to avoid any danger. ▲ 请勿使用化学溶剂擦拭本产品; 您在居家使用、户外旅行、商务工作中随时随地享受到 advanced electro acoustic technology, providing you the best enjoyment of music any time at home, outdoor or ▲ 请勿随意丢弃,或置于高温(温度高于60度)与火中, 卓越的音响效果,为您的笔记本电脑、数码音乐播放器 business work, and provide the perfect acoustic with your 等视听产品提供超值完美的音质,带您聆听美妙音乐, notebook and any digital audio/visual devices. Lead you to 以免引起危险! wonderful music, enjoy healthy & happy life. 感受健康快乐生活! 大康 蓝牙耳机 全国统一服务热线: 400-881-0138 СН TWS蓝牙耳机 产品名称:G22A+ EN Product Description 多功能键 产品名称: 果粉 7TWS 无线音乐蓝牙耳机 Item: Guofen7TWS wireless music Bluetooth headset Bluetooth standard: V4.2 蓝牙版本: V4.2 DC5V 充电接口 电池指标:高性能锂聚合物锂电池 蓝牙指标: Class 2 Bluetooth Operation: class 2 支持协议: Headset/Handsfree/A2DP/AVRCP Profiles Supported: Headset/Handsfree/A2DP/AVRCP 耳机充电指示灯-持续通话时长:约4小时 Talk time: up to 4 hours 持续播放时长:约4小时 Playing time: up to 4 hours 待机时长:约120小时 Stand by time: up to 120 hours USB charging iuput port - -底充充电指示灯 The charging indicate light of the bottom 功能介绍 Features 功能介绍 Features 功能介绍 Features Features Features Features Power on:1.In the off state, long press "MFB" button until the blue light flashes, headset power on. 2.Picking up the headphones, it will be power on while headphones in the charged state. Power off: 1.Not connected to the peer device, the one headset will be power off with long press the "MFB" button for 3 seconds. 2. Connected to the peer device, two headset at the same time off with long press any headset "MFB" button for 3 seconds. → 开机 -1. 关机状态下,长按 "MFB" 键直到蓝灯闪烁。 EQ 切换:音乐播放状态下,长按 "MBF" 键 1 秒释放按键。 Bluetooth pairing step (when using the single headset) ☑ 语音提示 Voice Prompt Pair the Bluetooth headset for the first time, the distance between the Bluetooth headset and your Bluetooth phone would be better within 1 meter when pairing. When the headset is off, press and hold the "MFB" until the red and blue lights flash alternately. Start mobile phone bluetooth function. Search bluetooth device, choose "GF7tws". Repeat above-mentioned steps if the pairing was unsucces. The blue light will flash if paired successfully. 低电报警 - 开机状态中, 电量低时每隔 60 秒发出 → 当开机时,耳机会自动语音提示:"开机"。 2. 充电状态下,拿起耳机可开机。 一次提示音并闪红灯。 多 复位功能 - 充电状态中,长按 "MFB" 键 6 秒清除 当关机时,耳机会自动语音提示: "关机"。当配对成功时,耳机会自动语音提示:"已连接"。当连接断开时,耳机会自动语音提示: "已断开"。 关机 - 1. 未连接对等设备,长按 "MFB" 键 3 秒,按按键 那台耳机关机。 耳机配对信息,蓝牙灯亮两下。 当电量低时,耳机会自动语音提示:"电量低"。 2. 已连接对等设备,长按任意一台耳机 "MFB" 低电关机 - 开机状态中, 电量很低时耳机将自动关机。 voice prompt: connected When being disconnected, there will be automatic voice prompt: disconnected When the battery is low, there will be voice prompt: same time off with long press any headset "MFB" button for 3 seconds. 3. Putting back into the charged charging case, the headphones will be power off. Answering a call: 1. Press the answer key on your phone or short press the "MFB" button on your headset. 2. Bluetooth Headset and mobile phone paired and can answe a call directly by picking up the headset in the charging state Ending a call: 1. Press the end key on your phone or short press the "MFB" button on your headset. 2. Putting back the charged charging case to end the phone while during a call. Rejecting a call: Press the end key on your phone or long press the "MFB" for about 2 seconds Redialing the last called number: By double-clicking WT 键 3 秒 , 两台耳机同时关机。 3. 开机状态下放回带电充电座 , 可关机。 🗖 充电指示 - 充电过程中亮红灯 , 充满电亮蓝灯后 € 接听电话 -1. 按手机接听键接听或短按耳机 "MFB" 即 没有连接对等设备状态下,一个耳机连接两个手机: * 蓝牙配对步骤(单耳机使用时) → 按配对步骤,配对第一个手机后,将手机蓝牙功能 关闭,再配对第二个蓝牙手机; → 打开第一个手机的蓝牙功能,手动连接第一部手机。 → 通话时,短按"MFB"键挂断当前电话,按通等待电话; → 双击"MFB"键,按听第二个来电,并保留第一通话 以下两个通话,如识标记和格 2. 耳机与手机配对过并且在充电状态下 ─○ 蓝牙首次配对时,请将蓝牙耳机和手机的距离控制 (2 headset working at the same time) Please pair the left headset following by above-mentioned pairing steps of single headset. With the headsets power off, press and hold the "MFB" of both headset, please do not release when the purple indicator lights flash alternatively, and the headsets will be connected until both of the blue light flash at the same time. After the two headsets connected successfully, power off both of the headsets and then power on, thus the headsets and phone will be connected automatically. In the TWS mode, incoming and dialing calls, only the main headset (left headset) have sound. Charring: It will be bright red led when charging, bright blue After paired the first mobile phone, please turn off the Bluetooth function of the first mobile phone, then pair to the second Bluetooth mobile phone. Open Bluetooth function of the first mobile phone, and Manually get it connected. During a call, short press the "MFB" to answer the incoming call. 拿起耳机,可自动接听。 ─○ 关机状态下长按蓝牙耳机 "MFB" 键直到红蓝灯交替 ★ 挂断电话 -1. 按手机挂断键挂断或短按耳机 "MFB" → 开启手机蓝牙功能,搜索蓝牙设备; → 选择 "GF7tws" 耳机; 以及两个通话之间进行切换。 —○ 短按 "MFB" 键 , 可以逐一挂断电话。 2. 通话中,放回带电充电座,可结束通话。 → 配对失败后,请重复上述操作; ■ 拒接电话 - 按手机挂断键或长按 "MFB" 键约 1 秒 Double press the "MFB" to answer another incoming call while the first call is held on, and can switch between the tw incoming call by double pressing the "MFB". Short press the "MFB" to cut off the incoming calls one by or └─○ 如果配对成功后,蓝灯闪烁。 # 末码拨号 - 在耳机处于连接待机或听歌状态下双击 ₩ TWS 配对方式(双耳机使用时) Pause:1.Not connected to the peer device, press the " MFB " 键针对最后一个拔出的电话 备注:对等设备指 TWS 左右耳机链接状态 "button on the master headset. onnected to the peer device , press the "MFB" button any headset 号码进行重拔。 (注:须手机支持 BLUETOOTH 重拔模式) 音乐播放 -1. 未连接对等设备,按一下耳机 "MFB" 键 ─○ 请按以上配对方式,必须左耳机与手机配对成功。 Low power alarm: In the power on state, if the battery voltage is low, there will be issued a prompt and the red indicator light flashes every 60 seconds. → 关机状态下,同时长按 MFB 键进入紫灯状态 备注:当两个耳机进行 TWS 链接后 , 不能同时链接两台手机 . e switching: Double press the "MFB" when the s charging. 不放,直至两耳机同时闪蓝灯,耳机配对成功。 2. 已连接对等设备,按一下任意一台耳机 → 耳机相互连接成功后,关机再同时开机,自动回连手机 switch: Music playing state, long press "MFB" button for econd and release. econic and release. set: In the charging state, press and hold the "MFB" Buttor about 6 seconds to clear the headset pairing information, etooth indicater light will flash twice. 引 语音切换:充电状态下,双击 "MFB" 键。 **S** ─○ TWS 通话,来电、拨打电话时,只有主耳机(左耳机) 售后服务条例与说明 Service Regulations and Explanati 废弃电器处理 Handling of the Waste 售后服务条例与说明 Service Regulations and Explanati Handling of the Waste Electrical Service Regulations and Explanation Service Regulations and Explanation ④ 无有效三包凭证和有效发票 The waste Electrical 废弃电器和电子设备 售后服务条例: (能证明产品确属服务期内者除外)。 provide charged service : This marking shown on the product or its literature indicates (A) Service system 本产品或附有如下标识的产品,寿命结束时不应与其它 1. 咨询服务:用户在使用产品前,请仔细阅读本产品的使 ⑤ 因不可抗拒如地震、火灾、水灾、雷击等导致的产品 The warranty date is expired; The warranty card is altered, or the series number differs from that of the product; Accidental or deliberate damage is done to the product (for that it should not be disposed with other household wastes 用说明书。在使用过程中遇到的如何问题,均可与当地经销商联系,或致电全国统一客服热线 400-881-0138 1.Consultancies: Please read this user manual carefully before at the end of its working life. using this product. For any problem during using it, you can ⑥ 未经本公司许可,擅自拆卸、修理或改装。 为了防止因废物受理不受控制而可能使环境或人身健康受到损害,请将本产品与其他类型的废物分开,并负责 2. 包换服务:包换期内(自购机之日起七日内),正常使用 To prevent possible harm to the environment or human Accidental or deliberate darlinge is done to the product (for example: improper use against the user manual, improper set up which causes error, plugging in unmatched power, exposed to water, fallen etc.) 4. cannot provide valid warranty card or invoice (other but can prove that it is within the service limit); 5. Any error damage caused by force majeure such as earthquake, fire, flood, lightning strike etc. Deliberate assembling repair or prefirm without permission from Exchange service: within exchange time limit, for any indeliberate error during proper use, making sure the product as well as its health from uncontrolled waste disposal, please separate 出现了非人为故障,请保持产品、配件和包装的完整(若 关于售后服务的说明: 外观不损坏、作保修处理)经检测确认故障后,可选择换 accessories and package are all not damaged(if the appearance 任地回收本产品,以促进可持续地重复利用材料资源。 to promote the sustainable reuse of material resources. 货或维修,用户可到当地授权经销商处)联系并处理。 1. 购机日期以本凭证或购机发票为准,不能提供有效证明的, 3. 保修服务:保修期内,正常使用出现的非人为故障,均可享受免费保修服务(主机一年内免费保修,若人为损坏 以生产日期为准。 exchanged for a new one or repaired after the error is tested and 请与本产品的零售商或当地相关机构联系,了解家庭 2. 质量问题不包括用户个人对音质、音色等主观差异。 purchased this product or their local government office, for 用户对电子产品环保回收条例,进行适当的回收。 details of where and how they can take this item for 3.Warranty service: within the warranty time limit, for any indelibe-3. 外壳、说明书包装不在保修服务范围内。 4. 已停产机型,本公司仅做功能性修复。 4. 收费维修服务:产品在自购机之日起一年到三年内,出现故障可收费维修,用户需支付维修所产品的元件费、 rate error that occurs during proper use, warranty service is free for no charge (the headphone has warranty service for free within environmentally safe recycling . 企业用户应与其供应商联系并检查采购合同的条款和 5. 经销商向您做出的非本公司保证的承诺,本公司不承担任 Business users should contact their one year; for any deliberate damage, the warranty service should 条件,本产品不应与其他商业废品混在一起处理。 (B) Explanation of After Service: 5. 以下情况不在三包范围内,本公司提供有偿服务: conditions of the purchase contract. This product 1.The date of purchased should be in accordance ② 涂改三包凭证,或序列号与产品本身不符 will be charged; and user should pay the repair components, ③ 意外因素或人为导致的产品损坏(如:未按使用说明书操作、维护或保管,安装错误造成的故障,接入不 2.Quality problem does not include user's personal preference to Services Hot Line: 400-881-0138 3. The shell and user manual package are exclusive to warranty 合适的电源、进水、摔坏等) 全国统一服务热线: 400-881-0138 5.We are not responsible for any promises by retailer other than NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may

cause undesired operation.