



Title				
Size B	Document Number	53125 Power		Rev 1.0
Date:	Wednesday, April 25, 2012		Sheet	9 of 18









Title		
Size	Document Number	Rev
C	43236 HSIC, JTAG, etc	1.0

Date: Wednesday, April 25, 2012 Sheet 14 of 18

Connections from C223 to R96 & R97
needs to be a "star-point". Place the
0.1uF caps right at the 43236 pins.



Connections from C248 to R103 & R105
needs to be a "star-point". Place the
0.1uF caps right at the 43236 pins.



43236 Strapping Option Pin	Function	Setting	Default Pull
CORE1_ANTO_RX	0 = Serial Flash NOT present [default] 1 = Serial Flash present	0	PD
CORE0_ANTO_RX	0 = Serial Flash Type is ST Micro [default] 1 = Serial Flash Type is Atmel	0*	PD
CORE0_ANTI1_TX	0 = HSIC mode (board setting) 1 = USB 2.0 PHY mode [default]	0	PU
CORE0_ANTI1_RX	0 = backplane at 96 (98.4) MHz 1 = backplane at 120 (123) MHz [default]	1	PU
CORE0_ANTO_TX	0 = Do not use OTP for configuration (setting) 1 = Use OTP for configuration [default]	0	PU
GPIO[7:6] LNA 5G PU 1/ LNA 5G PU 0	00 = boot from RAM, ARM held in reset 01 = boot from ROM [default] 10 = Reserved 11 = Reserved	01	none

* = Strapping option set at the default with no option to change.

