

AFTERGLOW® AP.2 AFTERGLOW





Thank you for purchasing the AFTERGLOW® AP.2 Wireless for PlavStation®3!


- 1 AFTERGLOW® AP.2 for PlayStation®3.
- 1 AFTERGLOW® Wireless Link USB Adapter
- 1 USB Charge Cable
- 1 Manual

Using the AFTERGLOW® AP.2:

- 1) The AFTERGLOW® AP.2 is designed to work with the Sony PlayStation®3 videogame system.
- 2) Your new AP.2 Wireless controller features an integrated rechargeable battery pack that should be fully charged prior to first use. To do so, connect the large USB plug to a powered USB port, such as your PlayStation®3 when it is powered on. Connect the mini-USB plug to your AP.2 controller. The indicator LEDs on the AP.2 controller will flash while charging takes place.









3) When charging is complete the AP.2 indicator LEDs will turn off. At this point, insert the AFTERGLOW® $Wire less\ Link\ USB\ Adapter\ into\ one\ of\ your\ Play Station "3's\ USB\ ports\ while\ the\ system\ is\ powered\ on.$ Press any button on your AP.2 controller and an automatic pairing will take place.






4) After pairing is complete your AP.2 controller will show it's controller number designation via one of 4 indicator LEDs. It is now ready to use. Time for some gaming!



5) When your AP.2's battery runs low, the indicator LED will flash quickly. You should charge your controller soon to avoid interruption of play.

Changing AFTERGLOW® Modes:

- 1) The AFTERGLOW® AP.2 features three (3) modes of lighting effects: "ON", "VIBRATION", and "OFF." The AP.2 must be connected to a PlayStation®3 console to function.
- 2) The AFTERGLOW® button on the AP.2 is located near the controller indicator lights on the controller.



3) The AFTERGLOW® AP.2's default setting is "ON."



4) Press the AFTERGLOW® button once to change to "VIBRATION" mode. Lighting occurs in this mode when

the AP.2 rumble motors activate.



5) Press the AFTERGLOW® button once more to change to "OFF" mode. No lighting occurs in this mode.



6) Press the AFTERGLOW® button once more to return to "ON" mode.

7) Cycle through the three settings as often as you like and enjoy the AFTERGLOW® in your favorite mode!

Frequently Asked Questions

Can I charge my AP.2 controller before the battery is completely drained? -Yes, you can charge the AP.2 any time you like. You will not damage the battery by charging when the battery still carries a charge.

Can I use my AP.2 controller while it is charging via USB? -Yes, you can play with the AP.2 and charge it at the

Can I use multiple AP.2 controllers with my PlayStation®3? -Yes, you can use up to 4 AP.2 controllers with your PlayStation®3 provided your system has 4 USB ports available.

My AP.2 controller will not sync with the PlayStation®3. What can I do? - When you first insert the AP.2 Wireless Link USB adapter an indicator light in the adapter will flash. Tap various buttons on your AP.2 controller and a wireless link should be established. Make sure your PlayStation 3 is powered on and that your AP.2 controller's battery has a charge

 ${f \triangle}$ **CAUTION**: Changes or modifications to this equipment not expressly approved by the manufacturer could void the users authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

- following measures:

 —Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help. FCC ID for Controller: X5B-PL6422 FCC ID for Dongle: X5B-PL6422A

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

2 year limited warranty. See www.pdp.com for details.



please keep this information for future reference 1840 East 27th Street CBX II - 382-390 Midsummer Blvd., Milton Keynes, Buckinghamshire MK9 2RG UK Vernon, CA 90058 USA For technical questions please visit

www.pdp.com or call: 1-800-331-3844 (USA ONLY)

© 2011 Performance Designed Products LLC. All rights reserved. PDP is a trademark, and AFTERGLOW is a spittered trademark, of Performance Designed Products LLC. PlayStation*3 is a registered trademark of Sony Computer Entertainment, Inc. This product is not designed, manufactured, sponsored or endorsed by Sony Computer Entertainment.



Contenu


- 1 AFTERGLOW^{MD} AP.2 pour PlayStation^{MD} 3.
- 1 adaptateur USB de connexion sans fil pour l'AFTERGLOW™
- 1 Câble USB de charge
- 1 manuel


Utilisation de l'AFTERGLOW™ AP.2:

1) L'AFTERGLOW™ AP 2 est conçu pour être utilisé avec le système de jeux vidéo Sony PlayStation™ 3.

2) Cette manette sans fil AP.2 neuve intègre un bloc-batterie rechargeable qui doit être complètement chargé avant toute première utilisation. Pour cela, connectez la prise USB large à un port USB alimenté, tel que celui de la PlayStation¹⁰⁰ 3 quand elle est en marche. Connectez la miniprise USB à votre manette AP.2. Les témoins DEL de la manette AP.2 clignoteront dès que la charge débutera.










3) Quand la charge est terminée les témoins DEL de l'AP.2 s'éteindront. À ce moment là, insérez l'adaptateur de connexion sans fil pour l'AFTERGLOW™ dans l'un des ports USB de la PlayStation™ 3 quand le système est en marche. Appuyez sur n'importe quel bouton de la manette AP.2 pour lancer le couplage

automatique.





4) Quand le couplage est terminé, la manette AP.2 affiche son numéro d'identification dans l'un des 4 témoins DEL. Elle est désormais prête à être utilisée. C'est le moment de jouer!



5) Quand la batterie de l'AP.2 est faible, le témoin DEL clignote rapidement. Il est alors nécessaire de charger la manette dès que possible pour éviter l'interruption du jeu.

Modification des modes de l'AFTERGLOW™ :

- 1) L'AFTERGLOW™ AP.2 intègre trois (3) modes d'effets lumineux : « ON » (Activé), « VIBRATION » et « OFF » (Désactivé). L'AP.2 doit être connectée à une console PlayStation™ 3 pour fonctionner.
- 2) Le bouton de l'AFTERGLOW^{MD} sur l'AP.2 est situé près des lumières des témoins DEL de la manette.



3) Le réglage par défaut de l'AFTERGLOWMD AP.2 est « ON » (Activé).



 Appuyez une fois sur le bouton AFTERGLOW^{MO} pour passer en mode « VIBRATION ». L'illumination intervient dans ce mode quand les moteurs de bruit de fond de l'AP.2 sont activés.



5) Appuyez de nouveau sur le bouton de l'AFTERGLOWnD pour passer au mode « OFF » (Désactivé). Aucune illumination ne se produit dans ce mode.



- 6) Pour revenir au mode activé (ON), appuyez de nouveau sur le bouton de l'AFTERGLOWMD.
- 7) Alternez entre ces trois possibilités autant que vous le souhaitez et divertissez-vous avec l'AFTERGLOW^{MD} dans votre mode favori!

Questions les plus fréquentes

Est-ce que je peux recharger ma manette AP.2 avant que la batterie ne soit complètement déchargée? -Oui, vous pouvez charger l'AP.2 à tout moment. La batterie ne sera pas endommagée si vous la rechargez alors qu'elle n'est pas déchargée.

Est-ce que je peux utiliser ma manette AP.2 pendant qu'elle se recharge par le port USB? -Oui, vous pouvez jouer avec l'AP.2 et la recharger en même temps.

Est-ce que je peux utiliser plusieurs manettes AP.2 avec ma PlayStation¹⁰⁰ 3? -Oui, vous pouvez utiliser un maximum de 4 manettes AP.2 avec votre PlayStation¹⁰⁰ 3 sous réserve que votre système dispose de 4 ports USB disponibles.

Ma manette AP.2 ne se synchronise pas avec la PlayStation⁴⁰ 3. Que faut-il faire? - Quand vous insérez l'adaptateur USB de connexion sans fil pour la première fois, un témoin lumineux de l'adaptateur clignote. Appuyez sur plusieurs boutons de la manette AP.2 et une liaison sans fil doit s'établir. Vérifiez que votre PlayStation⁴⁰ 3 est en marche et que la batterie de la manette AP.2 est chargée.

Garantie limitée de 2 ans. Voir www.pdp.com pour plus de détails.

* Veuillez conserver cette information pour toute référence ultérieure



1840 East 27th Street Vernon, CA 90058 USA CBX II - 382-390 Midsummer Blvd., Milton Keynes, Buckinghamshire MK9 2RG UK

Pour toute question technique allez sur le site www.pdp.com ou appelez le : 1-800-331-3844 (ÉTATS-UNIS UNIQUEMENT)

© 2011 Performance Designed Products, LLC. Tous droits réservès. PDP est une marque de commerce et AFTERGLOW est une marque déposée de Performance Designed Products LLC. PlaystationMD 3 est une marque déposée de Sony Computer Entertainment Inc. Ce produit n'a pas été conçu, fabriqué, commandité ou approuvé par Sony Computer Entertainment.





¡Gracias por comprar el AFTERGLOW® AP.2 para PlayStation®3!

Contenido


- 1 AFTERGLOW® AP.2 para PlayStation®3.
- 1 adaptador USB de conexión inalámbrica para AFTERGLOW®
- 1 Cable de carga USB
- 1 manual

Uso del AFTERGLOW® AP.2:

- 1) El AFTERGLOW® AP.2 está diseñado para funcionar con el sistema de videojuegos Sony PlayStation® 3.
- 2) Su control inalámbrico AP.2 nuevo incorpora un paquete de baterías recargable que se debe cargar completamente antes del primer uso. Par eso, conecte el enchufe USB ancho a un puerto USB alimentado, tal como su PlayStation® cuando está encendido. Conecte el enchufe mini USB a su control AP.2. Los indicadores LEDs del control AP.2 parpadearán mientras se carga.







3) Cuando la carga se terminará los indicadores LEDs del AP.2 se apagarán. En este momento, inserte el adaptador USB de conexión inalámbrica del AFTERGLOW® en uno de los puertos USB de su PlayStation®3 cuando el sistema se encienda.





4) Cuando se termine el acoplamiento su control AP.2 mostrará el número de identificación del control en uno de los 4 indicadores LEDs. Ya está listo para su uso. ¡Ahora es el tiempo de disfrutar un videojuego!