# X1-Device User Manual/Specification

HSDPA/WCDMA/EDGE/GPRS Data Module

PN: **310-1053-00-SP** 

TITLE: X1-DEVICE

PAGE 2 OF 13

REV **1.0** 

#### **Contents**

Revision History	
1. Overview	4
2. Receive Specifications	5
3.1 WCDMA/HSDPA 3.2 GPRS / EDGE	6
5. PIN Descriptions	9
<ul><li>6.1 Power Managem</li><li>6.2 SIM Card Detect</li><li>6.3 UART</li><li>6.4 USB</li><li>6.5 Host Wake &amp; Interest</li></ul>	10 ent 10 ion 10 10 10 10 10 10 10 10 10 10
7.1 SUPPLIER PART 7.2 SUPPLIER PART – Com 7.3 Mechanical Drav	

\_ . \_

PN: 310-1053-00-SP


TITLE: X1-DEVICE PAGE 3 OF 13 REV 1.0

#### **REVISION HISTORY**

RE	/ ECO	CHANGE DESCRIPTION	APPROVED BY	DATE
1.		Initial release		09/08/10

#### Notes (unless otherwise specified):

1. All parts and materials must be ROHS compliant.



#### **⚠** FCC Regulations:

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - -Reorient or relocate the receiving antenna.
  - -Increase the separation between the equipment and receiver.
  - -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - -Consult the dealer or an experienced radio/TV technician for help.
  - Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **A** RF Exposure Information:

This device meets the government's requirements for exposure to radio waves.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

• This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20cm (8 inches) during normal operation.

Maximum antenna gain allowed for use with this device is +2 dBi.

USER MANUAL / SPECIFICATION
-----------------------------

PN: **310-1053-00-SP** 

TITLE: **X1-DEVICE** PAGE 4 OF 13 REV **1.0** 

#### 1.1 GENERAL SPECIFICATIONS

I.1 GENERAL SPECIFICATIO PARAMETERS	DESCRIPTIONS					
External Access	WCDMA 850/1900/2100					
External Access	GSM 850/900/1800/1900					
Protocols	3GPP TS 34.121 (WCDMA / HSDPA), 3GPP TS 51.010-1 (GSM/GPRS)					
	HSDPA r5	3.6Mbps [	Down / 384	Kbps Up		
May Data Bata	WCDMA	384 Kbps				
Max Data Rate	GPRS	Multi slot	class 10 – 4	8Kbps (Dow	n / Up)	
	EDGE	384 Kbps	@ MSC9 (D	own / Up)		
	WCDMA / HSDPA 850	45 MHz			8	
	WCDMA / HSDPA 1900	80 MHz			1	
	WCDMA / HSDPA 2100	190 MHz			19	
RX / TX Frequency Interval	GPRS / EDGE 850	45 MHz			A P	
	GPRS / EDGE 900	45 MHz				
	GPRS / EDGE 1800	95 MHz			1	
	GPRS / EDGE 1900	80 MHz			a Bell 10	
	WCDMA / HSDPA 23dBm (Power class: 3)			FULL		
	GPRS 850 / 900 33dBm (Power class: 4)			000		
Max Output Power	GPRS 1800 / 1900 30dBm (Power class: 1)			1)		
	EDGE 850 / 900	EDGE 850 / 900 27dBm (Power class: E2)				
	EDGE 1800 / 1900	26dBm (P	ower class:	E2)		
Operating Voltage	VBATT 3.4V ~ 4.2V	- 10	- No.			
	Rock Bottom [Sleep]	0.75mA (Typical), 1.0mA (Max)				
	WCDMA standby	0.64s	1.28s	2.56s	5.12s	
Current Consumption	WCDMA Standby	3.37mA	2.27mA	1.71mA	1.36mA	
Current Consumption	GPRS standby	0.471s	0.471s		1.177s	
	GFR3 Stallaby	2.98mA		1.69mA		
le de la companya de	Peak Current	1.8A				
Operating Temperature Range	-10°C ~ +60°C					
Storage Temperature Range	nge -30°C ~ +80°C					
	WCDMA / HSDPA 800	±80Hz				
Frequency Stability	WCDMA / HSDPA 2100	±170Hz				
	GSM / GPRS	±0.1ppm				
Physical Dimensions	45.00 x 32.00 x 2.63mm					
Weight	0.2656 oz					

PN: **310-1053-00-SP** 

REV **1.0** 

TITLE: **X1-DEVICE** PAGE 5 of 13

#### 2. RECEIVE SPECIFICATIONS

2.1 WCDMA/HSDPA

2.1 WCDMA/HSDPA						
PARAMETERS		T	DESCRIPTIONS			
	WCDMA 2100	Down: 2110 ~ 2170 MHz				
Frequency Range	WCDMA 1900	Down: 1930 ~ 1990 MHz				
	WCDMA 850	Down: 869 ~ 894 MHz				
	WCDMA 2100	-106.7dBm				
Reference Sensitivity Level	WCDMA 1900	-104.7dBm				
	WCDMA 850	-104.7dBm				
	WCDMA 2100	-92.7dBm	193			
Adjacent Channel Selectivity	WCDMA 1900	-90.7dBm	33dB @ ±5MHz			
Sciectivity	WCDMA 850	-90.7dBm				
	WCDMA 2100	-103.7dBm				
Intermoduation	WCDMA 1900	-101.7dBm	-46dBm ±10MHz, ±20MHz			
	WCDMA 850	-101.7dBm				
	WCDMA 2100	-103.7dBm	1 10 611			
Spurious Response	WCDMA 1900	-101.7dBm	-44dBm			
	WCDMA 850	-101.7dBm	MIN ON.			
	WCDMA 2100	-103.7dBm				
In-Band Blocking	WCDMA 1900	-101.7dBm	-56dBm @ ±10MHz, -44dBm @ ±10MHz			
	WCDMA 850	-101.7dBm				
Peak throughput	HSDPA	-	3.6Mbps			

2.2 GSM / GPRS

2.2 GSM / GPRS	Al	lies		
PARAMETERS	DESCRIPTIONS			
	GPRS / EDGE 850	Down: 869 ~ 894 MHz		
Fraguency Dange	GPRS / EDGE 900	Down: 925 ~ 960 MHz		
Frequency Range	GPRS / EDGE 1800	Down: 1805 ~ 1880 M	Hz	
	GPRS / EDGE 1900	Down: 1930 ~ 1990 M	Hz	
		Type of Channel	Propagation Condition: BLER < 10%, Static	
	C. C.	PDTCH/CS-1	-102dBm	
	GPRS 850/900/1800/1900	PDTCH/CS-2	-102dBm	
(1)	9	PDTCH/CS-3	-102dBm	
Minimum Input level for		PDTCH/CS-4	-102dBm	
Reference Performance		PDTCH/CS-5	-99dBm	
The State of the S		PDTCH/MCS-5	-98dBm	
		PDTCH/MCS-6	-96dBm	
	EDGE 850/900/1800/1900	PDTCH/MCS-7	-93dBm	
		PDTCH/MCS-8	-90.5dBm	
		PDTCH/MCS-9	-86dBm	

TITLE: **X1-DEVICE** PAGE 6 OF 13

PN: **310-1053-00-SP** 

REV **1.0** 

#### 3. TRANSMIT SPECIFICATIONS

3.1 WCDMA/HSDPA

PARAMETERS		DESCRIPTIONS				
	WCDMA 2100	WCDMA 2100		Up: 1920 ~ 1980 MHz		
Frequency Range	WCDMA 1900		Up: 1850	) ~ 1910 MHz		
	WCDMA 850	WCDMA 850		Up: 824 ~ 849 MHz		
Max Output Power	20.3 ~ 25.7dBm (	20.3 ~ 25.7dBm (Power Class III)				
Min Output Power	Below -50dBm	Below -50dBm				
	Below -35dBc	2.5 ~ 3.5	MHz	Offset 30KHz		
Chartrum Emission Mask	Below -35dBc	5dBc 3.5 ~ 7.5 MHz		Offset 1MHz	15 P.	
Spectrum Emission Mask	Below -39dBc	-39dBc 7.5 ~ 8.5 MHz		Offset 1MHz	The same of the sa	
	Below -49dBc	8.5 ~ 12.	5 MHz	Offset 1MHz	~ ( )	
Occupied Bandwidth	Below 5MHz					
ACLR	±5MHz 33dB, ±10	±5MHz 33dB, ±10MHz 43dB				

3.2 GPRS / EDGE

PARAMETERS	DESCRIPTIONS					
	GPRS / EDGE 850	Up: 824 ~ 849 MHz				
Frequency Range	GPRS / EDGE 900	Up: 880 ~ 915 MHz				
Frequency Range	GPRS / EDGE 1800	Up: 1710 ~ 1785 MHz				
	GPRS / EDGE 1900	Up: 1850 ~ 1910 MHz				
Frequency error	GPRS / EDGE	±0.1ppm				
Phase error	GPRS	Peak phase err	or	Below 20°		
riiase error	GFKS	RMS phase err	or	Below 5°		
Modulation	EDGE	Peak EVM		Less than 5%		
accuracy	LDGL NEW MAN	RMS EVM		Less than 30%		
	1/10/1	Power Level	Output Power (dBm)	Tolerance (dBm)		
	10 16 100	5	33			
	GPRS / EDGE 850 / 900	6	31	±3		
		7	29	±3		
		8	27	±3		
- CO.		9	25	±3		
		10	23	±3		
100		11	21	±3		
17/2		12 19		±3		
		13	17	±3		
Transmitter output power		14	15	±3		
A Car Car		15	13	±3		
		16	11	±5		
		Power Level	Output Power (dBm)	Tolerance (dBm)		
The same of the sa		0	30	±2		
		1	28	±3		
	GPRS / EDGE 1800 / 1900	2	26	±3		
		3	24	±3		
		4	22	±3		
		5	20	±3		
		6	18	±3		

PN: **310-1053-00-SP** 

TITLE: X1-DEVICE PAGE 7 OF 13 REV 1.0

	T	_				
		7	16		±3	
		9	14		±3	
			12		±4	
		10	10		±4	
		11	8		±4	
		12	6		±4	
		13	4		±4	
		14	2		±5	
		15	0		±5	
		5 (15 )	Frequency of	offset (KHz)		
	GSM / GPRS 850 / 900	Power (dBm)	±400	±600	±1200	±1800
		33	-19	-21	-21	-24
ORFS @		31	-21	-23	-23	-26
Spectrum due to		29	-23	-25	-25	-28
modulation		27	-23	-26	-27	-30
		25	-23	-26	-29	-32
		23	-23	-26	-31	-34
		≤20	-23	-26	-32	-36
		Power (dBm)	Frequency offset (KHz)			•
			±400	±600	±1200	±1800
ORFS @		30	-22	-24	-24	-27
Spectrum due to switching transient	GSM / GPRS 1800 / 1900	28	-23	-25	-26	-29
		26	-23	-26	-28	-31
	1.00	24	-23	-26	-30	-33
		22	-23	-26	-31	-35
	A A M	≤21	-23	-26	-32	-36

TITLE: X1-DEVICE PAGE 8 OF 13 REV 1.0

#### 4. BASEBAND

#### Processors

- RISC CPU @ 230 MHz
- DSP @ 115 MHz

#### Memory

- Multichip Package (MCP) contains both RAM & Flash
- 1GB NAND Flash
- 256MB (16MB x 16) DDR @ 92MHz

#### Connectivity

- Full Speed USB
- UART
- JTAG (Debug Port)

TITLE: X1-DEVICE

PAGE 9 OF 13

REV **1.0** 

#### **5. PIN DESCRIPTIONS**

PIN	Name	Description	on PIN Name		Description
1	GND	Ground	2	VBAT	Battery
3	GND	Ground	4	VBAT	Battery
5	GND	Ground	6	VBAT	Battery
7	GND	Ground	8	VBAT	Battery
9	GND	Ground	10	VBAT	Battery
11	GND	Ground	12	VBAT	Battery
13	GND	Ground	14	VBAT	Battery
15	GND	Ground	16	VBAT	Battery
17	GND	Ground	18	VBAT	Battery
19	NC	No Connect	20	NC	No Connect
21	PS_HOLD	Power Supply Hold Up	22	UART_RXD	Serial Receive
23	SIM_DETECT	SIM card presence	24	UART_TXD	Serial Transmit
25	GPIO2	Spare GPIO	26	UART_RTS	Flow Control
27	GPIO3	Spare GPIO	28 UART_CTS		Flow Control
29	GND	Ground	30 JTAG_TDI		Test Data In
31	USB_DM	USB Data -	32	JTAG_TDO	Test Data Out
33	USB_DP	USB Data +	34	JTAG_TMS	Test Mode Select
35	GND	Ground	36	JTAG_TCK	Test Clock
37	USB_EN	USB Enable	38	JTAG_RTCK	Return Clock
39	HOST_WAKE	Host wake-up event	40	JTAG_TRST	Test Reset +
41	H_M_INT	Host to Modem Interrupt	42	JTAG_RESET_N	Test Reset -
43	M_H_INT	Modem to Host Interrupt	terrupt 44 UIM_DATA		SIM DATA
45	VBATT_EN	Modem Power Enable	46 UIM_CLK S		SIM Clock
47	VREG_MSME	1.8V (Linear)	48 UIM_RESET SIM Reset		SIM Reset
49	POWER_ON_OFF	Modem ON/OFF	50 VREG_USIM SIM Voltage		SIM Voltage
51	GND	Ground	52	GND	Ground
53	GND	Ground	54	GND	Ground

PN: **310-1053-00-SP** 

TITLE: **X1-DEVICE** PAGE 10 of 13 REV **1.0** 


#### 6. PIN CHARACTERISTICS

6.1 Power Management

011	ower management	•		
PIN	Name	Direction	Voltage	Description
21	PS_HOLD	Modem → Host	1.8V	Drive to 1.8V and hold for JTAG debug mode
49	POWER_ON_OFF	Host → Modem	1.8V	Pulling this pin LOW and holding for 500ms toggles power ON/OFF.
37	USB_EN	Host → Modem	1.8V	Enable/Disable USB PHY
45	VBATT_EN	Host → Modem	1.8V	Drive low to disconnect modem from the main battery

POWER\_ON\_OFF application note:

POWER\_ON\_OFF should be driven open collector on the host board.



**6.2 SIM Card Detection** 

PIN	Name	Direction	Voltage	Description
23	SIM_DETECT	Host → Modem	1.8V	Software drives this pin HIGH. Hardware should pull it LOW when a SIM Card is inserted.

#### 6.3 UART

PIN	Name	Direction	Voltage	Description
22	UART_RXD	Host → Modem	1.8V	Receive Data
24	UART_TXD	Modem → Host	1.8V	Transmit Data
26	UART_RTS	Reserve		Reserve
28	UART_CTS	Reserve	The state of the s	Reserve

#### 6.4 USB

ı	PIN	Name	Direction	Voltage	Description	
	31	USB_DM	Bidirectional	1.8V	USB Data -	
ı	33	USB_DP	Bidirectional	1.8V	USB Data +	

DEVICE supports full-speed USB only. The UART operates at 115,200 Baud with no Flow Control.

6.5 Host Wake & Interrupts

٧).	0.5 H	o nost wake & interrupts			
8	PIN	Name	Direction	Voltage	Description
4	39	HOST_WAKE	Modem → Host	2.6V	Signals the host device to wake from sleep mode when a TPH event has occurred.
3	41	H_M_INT	Host → Modem	1.8V	Host to Modem Interrupt
A	43	M_H_INT	Modem → Host	1.8V	Modem to Host Interrupt

PN: **310-1053-00-SP** 


TITLE: X1-DEVICE

PAGE 11 OF 13


**REV 1.0** 


#### 7. MECHANICAL INTERFACE

#### 7.1 SUPPLIER Part



#### 7.2 SUPPLIER Part - Complementary Part #1 (0.7mm stacking height)







TITLE: X1-DEVICE

PAGE 12 OF 13

**REV 1.0** 

#### 7.3 MECHANICAL DRAWINGS





#### **OEM Installation Instruction**

This 3G Module has been authorized for mobile operation in North America. End user installation is not allowed. This module must be installed at factory by the host integrator and should not provide any instruction to the user on how to remove or install the module.

This 3G module is approved to be used as a mobile device per FCC section 2.1091 and the antenna must be positioned in the host to provide at least 20 cm separation distance from user and nearby person.

The following conditions must be met:

- 1. Maintain at least a 20 cm separation between the antenna and the user's body.
- 2. To comply with FCC regulations limiting both maximum RF output power and human exposure to RF radiation, maximum antenna gain (including cable loss) must not exceed 4dBi for Cellular and PCS band.
- 3. This 3G module must not be co-located or jointly operated with any other transmitter or antenna within the host device.
- 4. A label with the following statements must be attached to the host end product if the FCC ID label is not visible at the time of purchasing: Contains TX FCC ID: X8E-1459.
- 5. The host end product must include a user manual that clearly defines operating requirements and conditions that must be observed to ensure compliance with current FCC/IC RF exposure guidelines.
- 6. The host end product must also pass the FCC Part 15 unintentional emission testing requirement and be properly authorized per FCC Part 15. For portable devices, a separate approval is required to satisfy the SAR requirements of FCC Part 2.1093.