

V900 GSM REMOTE CAMERA

User Manual

XIAMEN YOUTHNET CO.,LTD.

V900 GSM Remote Camera

Thank you for purchasing the GSM Remote Camera. The GSM remote camera is a remote images capturing device with a detect sensor, microphone, infrared lights and high quality camera. With the camera, you can capture images remotely and send them to your multimedia messaging (MMS) enabled mobile phone with a color display, or an e-mail address. You can control and configure the camera by SMS command.

Modern design GSM Remote camera with excellent 300,000 pixel camera, you can send SMS command to get remote images. You can view the MMS by your mobile phone or computer. MMS images can be displayed in slide form. With the built-in high-light infrared LED, the camera can take clear images even in darkness environment.

The Remote camera is compatible with 315MHz (433MHz optional) wireless sensor in the market, such as wireless infrared body sensor, door sensor, smoking sensor etc, and all of them are wireless, easy to use. You can also select to buy our remote camera assembled with any kinds of sensors mentioned above. You or your families or your guards can receive the alarm message with your previous setting way such as standard calls, SMS or MMS as soon as the camera is activated by the wireless sensor.

The remote camera can perform its duty well without any wireless sensor. The motion detective function of the remote camera can detect any unallowable entry into your house and send MMS images to you immediately.

All services and functions need to support by the GSM network and SIM card. Completely operation and product function information refer in this document.

This document suits for V900 model.

Contents

	or Your Safety	
	Peclaration of Conformity	. 5
Chap	ter 1 Product Features	. 7
Ρ	Product Accessories	. 8
Chap	ter 2 Terms Explanation	. 8
L	Jser Authorization Level:	. 8
S	Set defense/ Automatic alarm	. 9
C	Cancel defense	10
Е	mergency number	10
C	Capture Images	10
L	isten in voice	10
S	Setting	10
Ir	nfrared body detector	10
Chap	ter 3 Installation	10
V	900 Host Instruction	10
R	Remote control Instruction	11
Ir	ndicator Status Instruction	12
Ir	nstallation	12
Chap	ter 4 Quick Start	13
1	. Power on/ off	14
2	. Start Remote camera	14
3	. Active remote control	14
4	. Set defense	14
5	. Cancel defense	15
6	. Capturing images	15
7	. Listen in live voice	15
8	. Check status	16
9	. Getting Help	16
1	0. Reset the camera	16
Chap	ter 5. Advanced Operation	17
1	. Activate remote camera	17
2	. Change password	17
3	. Change master number	18
4	. Add or delete family number	18
5	. Add or delete emergency number	19
6	. Remote control instruction	20
7	. Add or delete remote control	21
8	. Set defense	21
9	. Cancel defense	22
1	0. Wireless sensor	22
1	1. Motion detection	24
1	2. Infrared body detector	24
	3. Infrared light	

14. Capturing images	25
15. E-mail	26
16. Alarm setting	27
17. Emergency Alarm	29
18. Add prefix number	29
19. The notify SMS when the power changed	30
20. Image parameter setting	30
21. Network parameter setting	32
22. Timing send MMS	33
23. Automatically cancel defense	34
24. Open/ Close indicator	34
25. English and Spanish version switch	35
26. Check status	35
27. Getting help	36
28. Reset the camera	36
Chapter 6 Maintenance	37
Chapter 7 General Troubleshooting	38
Chapter 8 Main Technical Parameters	39
Appendix: SMS command list	40
FCC Caution	47



- The GSM SIM card for V900 need to activate calling line presentation & MMS functions.
- 2. Be sure to remember and keep the product's password, SIM card number secret. Don't disclose to others to ensure your privacy safety.

For Your Safety

- This product is a wireless signal transmission device. Keep away from electronic equipment which is likely to interfere by the wireless signal to avoid the signals interrupt.
- Switch off your phone in any area marked "Explosive", "might explode",
 "closed wireless transceiver devices" etc.
- Do not dispose the product in a fire, otherwise, it may cause the battery explosion.
- Use only power approved by the product manufacturer. The use of any other types may damage the product
- Keep the product and the accessories out of the reach of the children.

Declaration of Conformity

- We operate a policy of continuous development. We reserve the right to make changes and improvements to any of the products described in this document without prior notice.
- For latest product information, visit: http://www.vision900.com. We don't guarantee for the document veracity, reliability or any content except regulate in proper laws. Including no guarantee for product suitable market or suitable area promise.
- Use only this product legally. Do not monitor other one's private places.
 We don't take any charge for the illegal use of this product.
- Under no circumstances should be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.
- The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied,

including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. We reserve the right to revise this document or withdraw it at any time without prior notice.

Chapter 1 Product Features

- This product use GSM SIM card. It can send MMS images to MMS supported mobile phone with a color display or to an e-mail address.
- Remote control: control & configure the camera with SMS command from mobile phone.
- Rea-time audio: call the camera number (SIM card) to listen in voices.
- Motion detection: Detect and alarm any motion within the monitoring area.
- Sensor detection: Connects max 15 sensors such as door magnet sensor, infrared body sensor, smoke sensor, gas sensor etc. Any sensor active will alarm by SMS.
- Infrared light: Even in dark environment, camera can get clear image with the built-in infrared LED.
- Special Camera: 300,000 pixel CMOS camera, get clear image for MMS.
- Send images to mobile: The camera will send MMS images to your mobile phone. You can check them anywhere.
- Send images to E-mail: The camera can send MMS images to pre-set
 E-mail. You can check the image in your email anytime.
- Multimode alarm: Camera can send alarm messages by SMS, MMS,
 E-mail or standard phone-call.
- Fixed time monitor: Monitor schedule can be set flexibly with multiple time-intervals.
- Easy installation: Wireless connection. The product can be installed at any place you wanted.
- Accessory: Include 2 remote controls for manual operation on/off and panic button.
- Built-in Lithium battery: Rechargeable battery ensuring operation in case of external power failure.
- Download user manual: Manual can be downloaded anytime using SMS command.
- Integrated infrared body detector.

Product Accessories

1.	Remote camera host	1 unit
2.	Power adapter (5.5V/2A)	1 unit
3.	Remote control	2 units
4.	User manual	1 unit

Chapter 2 Terms Explanation

Any MMS enabled mobile phone can receive the image with password command.

Any SMS supported mobile phone can control the remote camera with password command.

Keep the product's password and SIM number secret. Don't disclose to others to ensure your privacy safety.

User Authorization Level:

There are three levels remote camera user with different authority:

Master: Master need to store his/ her mobile number into the camera (see "Chapter 4, Quick Start, 2. Start remote camera"), otherwise, all the functions of the remote camera are disabled. Only one master mobile number can be set in the remote camera. The camera will send the alarm message to master's mobile number and his/her families or emergency numbers setting by the master. Master should firmly remember the password and SIM number. Only master has the authority to change the camera password and the families or emergency numbers.

Families: Family members have the authority to listen in voice, get images, add the sensor & remote control, and receive alarm. Family member's telephone numbers are set by the master. (See "Chapter 5. Advanced Operation, 4, Add or delete family number"). Family members should remember the camera's SIM number.

Guest: Anyone can be guest if they know the password and SIM number. Guest can use any mobile send SMS command including password to remote camera to get the MMS image.

Difference authority for Master, Family and Guest:

Func	User Type Master Fa		Family	Guest
Change authority	Change authority, password		NO	NO
	Receive SMS	YES	NO	NO
Automatic	Receive MMS	YES	NO	NO
Alarm	Receive alarm calling	YES	YES	NO
	Get images by e-mail	YES	NO	NO
	Receive SMS	YES	NO	NO
Emergency	Receive MMS	YES	NO	NO
alarm	Receive emergency calling	YES	YES (Only emergency	
	Receive energency canning	ILS	number)	
Wire taping, requ	YES	YES	NO	
Get work status	s, images, help and instruction by	YES	YES	YES
sending SMS cor	nmand	IES	1 ES	(Password)
Get images by e	YES	YES	NO	
Set remote came	YES	YES	NO	
Add, modify or d	YES	YES	NO	
Set infrared body	YES	YES	NO	
Spanish & English version switch		YES	NO	NO

Set defense/ Automatic alarm

Set defense is to make the remote camera in alarm status. In this status, all connected wireless sensors, infrared body detector and motion detector are in work status.

Under the defense status, if any wireless sensor, motion detector is activated, camera will send SMS or MMS images to the master mobile phone or automatically dialed master number to alarm immediately. If the master doesn't answer the call, it will dial the other pre-set numbers orderly until answered. This process will repeat three times, then exit dialing mode automatically if none of the pre-set numbers answered.

Cancel defense

Cancel defense is deactivated the alarm function of remote camera. All connected wireless sensors and motion detector doesn't work unless pressing the emergency key.

Emergency number

The emergency numbers in this document are the phone numbers (not including the master number) that the camera will dial when the emergency key of the remote control is pressed. Emergency numbers could be the telephone numbers of guarders, family numbers as well as the first-aid station. When press the Emergency Key, the camera will dial master number firstly, then dial other emergency numbers (the default alarm mode of the camera is dial phone number). Only master has the authority to set emergency numbers. The maximum emergency numbers (including master number) are 10.

Capture Images

Master/ family / guest send SMS to the camera to get the MMS image.

Master/ family member call the camera to get the images.

Master/ family send SMS command to the camera to send MMS image to an e-mail address (Need to pre-set E-mail address).

Listen in voice

The master or family members can listen in live voice by calling the camera. Only one line can be connected to the camera at a time.

Setting

All camera settings can be set or adjusted by sending SMS command.

Infrared body detector

When the device is in set defense mode, if an intruder approach to the monitoring area, the integrated infrared body detector can trigger the device send alarm messages to pre-set users.

Chapter 3 Installation

V900 Host Instruction




Figure 1: Host Instruction

- 1. SIM card Slot (rubber cover)
- 2. Camera
- 3. Infrared lights (8 pcs)
- 4. Micphone
- 5. Indicator
- 6. Power switch
- 13. Infrared body detector

- 7. Power Interface (Mini USB)
- 8. Line Holder
- 9. Slot buckle
- 10. Hanging hole
- 11. Setting key
- 12. Base board

Important suggest: Keep the lens of the camera clean to assure best imaging quality.

Remote control Instruction




Figure 2: Remote control Instructions

1. Antenna

3. Set defense Key

- 2. Remote control indicator
- 4. Cancel defense Key
- 5. Emergency key

Indicator Status Instruction

Color	Action	Status	
	Flash slowly	Searching the network.	
Red	Flash quickly	Sensor alarm, motion detection alarm or Infrared body detect alarm	
	Constant Light	Not installed SIM card, or the remote camera damaged.	
	Constant Light	Defense status. Activating the auto-alarm function.	
	Flash slowly	Cancel defense status. Canceling the auto-alarm	
Green		function.	
Green	Flash quickly	Processing data.	
	Light two	Suggestible report factors, acting, or leading concer-	
	seconds	Successfully reset factory setting, or loading sensor.	
Orange	Flash	Loading remote control status.	
Red &	Two color lights	Loading concer	
Green	alternately	Loading sensor	

Note: Slow flash 1 time per second, quick flash 2 times per second.

Installation

Install the SIM card

Remove the rubber cover from the left side of host. Open the SIM card slot by pressing the small dot beside the SIM card slot with the tip of a pencil, and pop-up the slot. Insert the SIM card into the slot then push the slot back to its place, get back the rubber cover.

Note: This camera only supports GSM network. The Calling line presentation and MMS function of the SIM card must be activated. Contact your SIM card provider for more information about the SIM card additional services.

Extend host base board

Hold the base of the host and pull the head of the camera far away the base direction and the slot buckle will be indrawn.

The head of the camera now can be located at any direction.

Connect external Power

Connect the adapter to an AC power, and connect the mini-USB plug to the power interface of the host. (See Figure 1 Host Instruction, 7)

The product has a built-in rechargeable Lithium battery. The camera will notify you when the power supply switch. For example, if the power adapter is disconnected or the AC power is failure, it will notify you "External power cut off, supply by battery now". If the power adapter is connected again or the AC power is available, it will notify you "Remote camera resume to external power now".

4. Mount the host

The host can be mounted vertically on the wall with the screws or located horizontally at suitable place.

Choose the Installing place:

- For better image quality, avoid the bright light irradiated directly into the lens of the camera. It is suggested that the camera is located at the place which can look down the monitoring place with the minimum angel 30°.
- To prevent to be stolen, it is suggested that the camera is located at the place above the ground more than 2.2 meters.
- GSM network signal strength may affect the image and live voice quality and MMS transmission speed; therefore, the camera should be located at the place which has strong network signal.
- After installation, try to take several images and send to mobile to check the image quality. Re-locate the remote camera and adjust the host's angle to get best image.

Chapter 4 Quick Start

About the SMS Command:

- 1) All the SMS commands are composed with symbol # and Arabic numerals.
 - 2) Master & family SMS command format: #code#content#.
 - 3) Guest SMS command format: #code#password#content#.
 - 4) Password is a four-digit number. The default is 1234.
 - 5) The maximum digit of the phone number is 16.
 - 6) Camera will reply you after received the SMS command.

Note: The symbol "#" in SMS command can not be ignored. No space

character can be included within the commands.

1. Power on/ off

Power on: turn the power switch to upside "On" position. The indicator will be light constantly with red color for 3-5 seconds, then change to flash slowly, After about 35 seconds, the indicator change to green color flashed slowly (indicated cancel defense status) or green color lighted constantly (indicated set defense status), which indicated that the camera search the network and begun to work. A "Di..." tone can be heard from the camera. For more information of the status, refer to indicator status instruction.

Power off: Turn the power switch to downside "Off" position.

2. Start Remote camera

Method 1: Call remote camera with your mobile, the call will be hung up after connected, which indicated that your mobile number has been recognized as master.

Method 2: Edit and send the following SMS to camera:

#00#

After initiation, the camera will send the following SMS to your mobile: "Welcome to use remote camera, the password is 1234".

3. Active remote control

When the green indicator lightened constantly or flashed, press and hold the "Set" key at the rear board of the host for 2 seconds. The indicator change to flash with orange color indicated the camera switched to learning state. Then press any key of the remote control to send signal to the host. After the host receives the new remote control signal successfully, the indicator of the host will lighten constantly with green color for 2 seconds. Press "Set" key again to exit the learning state. Otherwise, it will automatically exit after 15 seconds.

Remote camera can be recognized and controlled by more than 5 remote controls.

4. Set defense

Press "Set defense" key directly in the remote control to set defense.

If setting successful, a "DI..." tone can be heard from the host, and a "Set defense successfully" SMS will be sent to the master's mobile. The indicator of

the host will lighten constantly with green color.

5. Cancel defense

Press "Cancel defense" key directly in the remote control to cancel defense.

If setting successful, a "Di..." tone can be heard from the host, and a "Cancel

defense successfully" SMS will be sent to the master's mobile. The indicator of

the host will flash in green color.

6. Capturing images

Capturing one image each time:

Method 1: Master or family call remote camera number; hang up as soon

as the ringing tone is heard. You can receive notify message "Image capturing request received, the camera is busy sending MMS images", and then you

will receive images later.

Method 2: Send following SMS command to camera:

For master and family: #03#

For guest: #03#password#

Capturing several images one time:

If user needs several images, send following SMS command to camera:

For master and family: #03#image quantity#

For guest: #03#Password#image quantity#

If the image size is 160×128 or 320×240, the maximum number of the images

can be requested at one time is 8, the image quantity number should be set

from 1 to 8. As the same, the number should be set between 1 and 2 if the

image size is 640×480.

You can receive notify message "Image capturing request received, the

camera is busy sending MMS images", and then you will receive images later.

7. Listen in live voice

Initiative listens in:

Master or families call the camera and it answers the call automatically. Then

you can listen in live voice of monitoring area.

Emergency alarm listens in:

15

In normal status, when pressed the "emergency alarm" key of the remote control, the camera will automatically dial master number, and master can listen once answers the call. If master doesn't answer the call, it will dial other emergency numbers sequentially. If the camera called master number and other emergency numbers circularly three times and none of the numbers answers, the camera will exit alarming status automatically.

8. Check status

At any time, send the following SMS command to camera and it will reply a MMS about the camera's present setting and work status (Not including the password).

For master and families: #07#
For guest: #07#password#

9. Getting Help

You can send SMS to the camera to get the SMS command list or the MMS user manual to your cell phone.

Getting normal command list:

Send following SMS command to camera:

For master and families: #09#
For guest: #09#password#

Getting user manual:

If you need detail instruction, send following SMS command to camera:

For master and families: #09#1#
For guest: #09#password#1#

10. Reset the camera

This function reset all settings to their original values, it will clean all setting. The setting values of master number, remote control, and wireless sensor will be cleared too, so you need to use this function carefully.

Method 1: Switch off the remote camera(push the power switch to bottom side) for more than 20 seconds. Press and hold the setting key at the rear board of the camera and then switch on the camera again. The indicator will lighten green constantly for 2-4 seconds and turn to flash red slowly. A "DI" tone can be heard from the camera indicated the successful reset operation.

Method 2: Master sends following SMS command to camera:

#08#password#

It will reply "The GSM camera have successfully reset to its default settings".

Note:

- 1. The password is needed with the SMS command, otherwise, a SMS "You forgot including 4 digit password to reset camera" will be sent and the operation is rejected.
- 2. Only master can make this operation, otherwise, it will reply SMS "Sorry, you are prohibited to request this command".
- After resetting, the camera is needed to restart. Activating the remote control and loading the wireless sensor are needed too. Read "Chapter 4. Quick Start, 2. Start remote camera" operation for detail information.
- 4. The MMS center number is often stored to the camera. After reset the camera to default setting, It is not need to reset the MMS parameter until the MMS works abnormally. Refer to Chapter 5. 18 Network MMS parameter setting.

Chapter 5. Advanced Operation

1. Activate remote camera

(Authority: Master)

When first time using or after resetting the remote camera, it needs to set the master number to activate the camera with following methods:

Method 1: Call remote camera with your cell phone, and it will notify you the number is busy now.

Method 2: Edit following SMS command and send to camera:

#00#

After activating the camera, it will reply you: "Welcome to use remote camera, the password is 1234".

Note: If the camera has been activated, the master number will be saved in it. If you try to activate it again with method 1, the call will be hung up with no SMS reply. With method 2, it will reply SMS "Master already exists".

2. Change password

(Authority: Master)

For private and safe using the camera, change the password once beginning

to use it.

Only master can change the password. Master edit following SMS command to camera to change the password:

#04#old password # new password

The password is a 4-digit number. The default password is 1234. After succeed to change the password, the camera will send SMS to you: The password has been successfully changed. The new password is ****. If others send above SMS command to camera, it will reply "Sorry, you are prohibited to request this command".

3. Change master number

(Authority: Master)

Only master can change the master number. Send following SMS command to camera:

#14#new master number#

If changed successfully, it will reply you "The Master number have been successfully changed. The new number is *******. Old master number didn't have the authority to control the camera afterward.

4. Add or delete family number

The difference between master and family refer to "Chapter 2, Terms explain, User authorization level". Family don't need contain password when send SMS command.

Only master has authority to add or delete family number, otherwise it will reply "Sorry, you are prohibited to request this command".

Add family number:

(Authority: Master)

To be a family member, the master sends following SMS to store the family member's cell phone number into the camera. Maximum 10 family numbers can be stored.

#06#Family number#

Add several family numbers:

#06#family number # family number#...

After succeed setting, camera will reply you "The family number ***** has been successfully added".

Check family number:

Refer to Chapter 4. Quick Start, 8. Check status.

Delete family number:

(Authority: Master)

Master sends following SMS command to delete family's phone number:

Delete single phone number:

#113#family number#

Delete several family numbers:

#113#family number # family number#...

Delete all family numbers:

#113#

After delete successfully, it will reply "Family number ******* deleted successfully", otherwise, it will reply "Fail to delete family number ******.

5. Add or delete emergency number

(Authority: Master)

Only master can add or delete emergency number.

Add emergency number:

To be emergency number, master should send following SMS command to store it into the camera. The master number is defaulted to be emergency number and max other 9 emergency numbers can be stored.

Add single emergency number:

#106#telephone number#

Add several emergency numbers:

#106#emergency number#emergency number#...

After set successfully the camera will reply "The emergency number ****** has been successfully added.". If the emergency numbers are full, it will reply "The Emergency numbers are full. Please delete numbers before you add new ones.". If the number existed, it will reply "Emergency number already exist".

Check emergency number:

Refer to Chapter 4. Quick start 8. Check status.

Delete emergency number:

(Authority: Master)

Master sends following SMS to delete emergency number:

Delete single emergency number:

#107#emergency number#

Delete several emergency numbers:

#107#emergency number #emergency number#...

Delete all emergency number:

#107#

After succeed deleted, it will reply "Emergency number ****** successfully deleted", otherwise it will reply "Delete emergency number ***** failed". If the SMS command error, it will reply "The emergency number ***** is invalid, please check and try again."

6. Remote control instruction

There are three keys on the remote control: <u>Set defense</u>, <u>Emergency key</u>, Cancel defense.

When press the <u>Set defense</u> key, the camera indicator will turn constant green, and the camera enter the defense state. If the wireless detector or motion detection is activated by the broken-in, the camera will alarm to dial or send SMS/MMS.

When press the <u>Emergency</u> key, the camera indicator will turn to flash green quickly and the camera will dial the master and the emergency numbers orderly. Live voice can be heard by answering the calling. It will call master and all emergency numbers three times unit answered, then exit dialing automatically.

When press <u>Cancel Defense</u> key, the camera indicator turn green and flash slowly, and the camera enter the state of cancel defense. In this statue, the camera can alarm only by pressing the <u>Emergency</u> key.

A "Di..." tone can be heard from the camera by pressing any remote control key.

Whether to send SMS notify when set or cancel defense status (default setting is sending SMS notify):

Master or family number edit:

Send SMS notify when set or cancel defense: #137#1#

Not send SMS notify when set or cancel defense: #137#0#

7. Add or delete remote control

Add remote control

Press the <u>set key</u> on the rear board and the indicator turn to flash slowly with orange color. Then press any key of the remote control. When the host receives the new wireless remote control signal, a "Di …" tone will be heard and the indicator will turn green for 2 seconds then turn to orange, flash slowly. It can continue to load new remote control in this time. The camera will automatically exit from the learning status after 15 seconds, or press the <u>set</u>

key to exit directly.

Max 5 remote controls can be loaded.

Delete remote control:

(Authority: Master, family)

Master or family sends following SMS to camera:

#111#

Camera will reply "All remote control delete successfully". If guest send above SMS command to camera, it will reply "Sorry, you are prohibited to request this command".

8. Set defense

(Authority: Master, Family)

If the camera indicator display in green color and flash, it is indicated the defense status has been canceled (no alarming status). To recover defense state, you can do as following:

Method 1: send following SMS to camera.

Master and family: #01#

Method 2: Press the "<u>Set defense</u>" key of the remote control directly and you can hear "Di …" tone indicated operation successful.

The camera will reply you SMS "Defense mode activated" for both methods, and the indicator lightens constant in green color.

21

Default defense status: The infrared light will turn on in dark environments or areas with insufficient lighting. The device can send a MMS message including 5 images when alarm is triggered. The MMS image quality is QVGA. The motion detection and infrared body detector is activated.

9. Cancel defense

(Authority: Master, Family)

In cancel defense status, camera won't make any alarm (Unless press the emergency key in the remote control).

All connected wireless sensor, motion detection and infrared body detection etc function didn't work.

Method 1: send following SMS command to camera:

Master and family edit: #02#

Method 2: press the key of "Cancel defense" on the remote control. You can hear "Di..." tone if operation successful and receive "Defense mode de-activated" SMS. Then the indicator display in flash green light.

10. Wireless sensor

(Authority: Master, Family)

Any 315MHz (433MHz optional) wireless sensor, such as infrared body sensor, wireless door magnet, wireless smoke sensor etc, can be set as alarm sensor of the camera.

Add wireless sensor:

- 1) Power on the wireless sensor.
- 2) Master or family sends following SMS command to camera. The camera enter the receive wireless sensor status:

#05#sensor description#

"Sensor description" is used for identify the sensors. Only character or number with max 20-digits can be used.

For example: #05#door# or #05#1#

If send SMS with #05# only but without sensor description, camera will default recognize the sensor with its order number.

3) After receive the SMS command, camera will sound "Di..." tone and the indicator flash with red and green alternately. When received SMS "Waiting to load sensor, make the sensor work immediately", make wireless sensor work immediately. For example, for wireless door magnet, make it open and close once to send the signal to the camera.

Once the sensor loading successfully, the camera will sound "Di..." tone, exit the loading status, and reply "Loading sensor successfully".

- 4) In loading status, press the set key at the back of the camera. The camera will sound "Di..." tone and exit the loading status.
- 5) If the camera failed to load the sensor or no sensor exist, the indicator of the camera will flash with red and green alternately for about one minute, then the camera will exit the loading status automatically and back to the previous defense or cancel defense status.
- 6) Max 15 pieces wireless sensors can be loaded in remote camera. If reach its max numbers, the camera will send SMS as: "The sensors are full. Please delete old sensors before add new ones.".
- 7) If the sensor description invalid, the camera will reply "Sensor description invalid, please rename the sensor".

Modify wireless sensor:

In **step 2 add wireless sensor**, if the "Sensor description" in sent SMS is same as old sensor's, the camera will load new sensor information and replace the old sensor.

Delete all wireless sensors:

Master or family sends following SMS to camera:

#112#

After successful delete, it will reply "All sensor delete successfully"

Guests are forbidden to do this operation. If guest send above SMS command to camera, it will reply "Sorry, you are forbidden to do this operation".

Only send SMS when the wireless alarm is activated.

#140#sensor description #...#

The "sensor description" must be the sensor which has been successfully loaded to the camera (Refer to Chapter 5, advance operation,10 wireless sensor). After successfully set, the camera will reply SMS "Below sensor only send SMS when alarm:***".

Note:

- 1, After successfully set, it will not be affected by other setting.
- 2.If the sensor are not studied by the camera, it will reply you SMS "Sensor description are not exist, please check and try again".

Cancel all wireless alarm send SMS when activated.

#140#

After successfully set, the camera will reply SMS:"Clear all sensors which marked only send SMS when alarm successfully".

11. Motion detection

(Authority: Master, Family)

Motion detection is a moving body recognition technology by comparing the difference between the sequential images.

Motion detection can be functional only when the camera is in set defense status and the motion detection function is enabled. Motion detection function is active in the default setting.

Note: Only use the motion detection function in still and quiet place, such as quiet room. Don't make it face shaking tree or other moving things, otherwise, it will continuously alarm and may destroy the camera.

Master or family sends following SMS command to camera:

Close motion detection: #22#0#

After successful set, it will reply "Motion detection closed"

Open motion detection (default setting):

#22#1#

After successful set, it will reply "motion detection open"

Motion detection sensitivity: #36#grade#

(Note: grade can be 1, 2, 3, 4, 5. The larger the number, the stronger the sensitivity. The default value is 4. In grade 4, the camera can detect human body motion)

After successfully set, it will reply: "Motion detection sensitivity set successfully.", With wrong parameter, it will reply "Invalid detection sensitivity parameter, the range is 1-5, please check and try again"

12. Infrared body detector

(Authority: Master, Family)

Wireless monitor integrate infrared body detector, only in set defense status, anyone approach to the detecting area, and monitor will alarm you as pre-set ways.

Open infrared body detector:

Master or family sends one of following SMS command to monitor:

#118#1#

After success set, it will reply "Infrared body detector open".

Close infrared body detector:

Master or family sends one of following SMS command to monitor:

#118#0#

After success set, it will reply "Infrared body detector close".

13. Infrared light

(Authority: Master, Family)

Only turn on infrared light can enable the camera get clear image in dark night. Camera will control the infrared light automatically. However, if AC power failure and user hope to turn off the infrared light to save the battery power, master or family can send following SMS command to turn off the infrared light:

Close infrared light: #31#0#

After successful set, It will reply "Infrared light closed".

Once turn off the infrared light, it can't take images in dark night. User need to send following SMS to turn on the infrared light:

Turn on infrared light: (default setting) #31#1#

After successful set, it will reply "Infrared light activated, it will auto work to adjust the brightness".

14. Capturing images

(Authority: Master, Family, Guest)

No matter the camera is in defense status or cancel defense status, master or family or guest can capturing images from the camera.

Capturing one image:

Method 1: Master or family call the camera, hand up as soon as heard the ringing tone. The camera will reply "Image capturing request received. The camera is busy sending the MMS image." And the caller can receive the MMS image later.

If guest call the camera number, it will not reply and can't receive MMS image.

Method 2: Send following SMS command to camera:

For master and families: #03#

For guest: #03#password#

Capturing several images one time:

If user needs several images, send following SMS command to camera:

For master and families: #03#image quantity#

For guest: #03#Password#image quantity#

When the image size set 160×128 or 320×240, camera can only send max 8 images one time. So the image quantity number should be between 1 and 8. When the image size set 640×480, camera can send max 2 images and the

image quantity number should be 1 or 2.

After received the SMS command, camera will reply "Image capturing request received. The camera is busy sending the MMS image.", and send the images to your cell phone later.

Initiative capture MMS images name format: Model-Time (Such as V900-094843 means V900 model, image captured at 09: 48: 43 AM)... If several images send in one MMS, the image size is same as pre-set image size, and the interval between the first image and second image is 500 ms and other images interval is same as user pre-set.

Send image to E-mail

(Authority: Master, Family)

If user wants to send the image to E-mail, send following SMS command to camera.

For master and families: #03# image quantity#1#

When the image size set 160×128 or 320×240, Remote camera can only accept max 8 images one time, therefore, the image quantity number should be between 1 and 8. When he image size set 640×480, Remote camera can accept max 2 images so the number should be 1 or 2.

After received the SMS command, it will reply "Image capturing request received. The camera is busy sending the MMS image." and send the MMS image to pre-set E-mail later.

Note: the image quantity can't be ignored. About E-mail setting, refer to Chapter 5. Advanced operation, 15. E-mail.

15. E-mail

(Authority: Master, Family)

Note: This function should support by local network provider. Contact with local network operator for detail.

Master and family send following SMS to add, modify or delete e-mail. Master and family can set each e-mail separately.

Add or modify e-mail:

#108#EMAIL#

After successful set, it will reply: "Email address ***** has been changed successfully.". The E-mail address should be exact. Master and family can set one E-mail to one number. If more than one E-mail set for one number, only the last one can be recognized.

If the SMS command of add or modify E-mail not including E-mail parameter,

camera will reply "Invalid format".

Delete e-mail: #109#

After successful set, it will reply "Delete email successfully". Only master can operate this function. All E-mail will be deleted after receive this SMS command.

Note: If this SMS command including E-mail parameter, it will reply "No need E-mail parameter".

When master or family require images to be sent to E-mail, camera will send the MMS images to pre-set E-mail.

When set "Alarm sends MMS images to E-mail" (Refer Chapter 5. Advanced operation, 16. Alarm setting), it will send MMS images to E-mail when alarm.

16. Alarm setting

Remote camera can alarm by motion detection, wireless sensor or by pressing the emergency key in remote control. The previous two ways are activated automatically. The default alarm way is sending SMS and MMS.

Master or families send following SMS command to set the automatic alarm method:

(Authority: Master, Family)
Warning tone when alarm:

For master and families: #130#1# For quest: #130#password#1#

After successful set, the camera will sound "Di..." tone when alarming.

No warning tone when alarm (Default):

Master and families send SMS: #130#0#

Not send SMS when alarm: #11#0#

After successful set, camera will reply "Set alarm without SMS successfully".

Send SMS when alarm (Default): #11#1#

After successful set, camera will reply "Set alarm with SMS successfully".

Not send MMS when alarm: #12#0#

After successful set, camera will reply "Set alarm without MMS successfully, alarm with SMS". When camera alarm, user can't receive MMS, but only can receive a SMS "*** alarm, image quantity 5".

Send MMS when alarm (Default): #12#1#

After successful set, camera will reply "Set alarm with MMS successfully". User can receive MMS images when camera alarm.

No calling when alarm (Default): #13#0#

After successful set, camera will reply "Set alarm without calling successfully".

Calling when alarm: #13#1#

After successful set, camera will reply "Set alarm with calling successfully". Once alarm, it will call master and family numbers orderly until someone answer the calling. It will automatic dial three times, and exit if no one answer. If set alarm with SMS, MMS and calling, it will send SMS firstly, then send MMS, and make calling at last. Each alarm method only work one time.

Not send MMS image to E-mail (Default): #110#0#

After successful set, camera will reply "Set alarm without MMS image to E-mail successfully".

Send MMS image to E-mail: #110#1#

After successful set, camera will reply "Set alarm sending MMS image to E-mail successfully". If user set alarm with MMS also, it will send MMS image to mobile phone at first and then to E-mail when alarm.

Image quantity when alarm: #33#quantity#

Quantity should be the number from 2 to 8. The default number is 5.

Note:

1) MMS file name:

Wireless sensor and infrared body detector alarm: Model-Time (Sensor name), such as V900-171154(Sensor 1).

Motion detection alarm: Model-Time (Motion detection), such as V900-171154 (motion detection).

- Image quantity: is same as pre-set image quantity when alarm, default setting is 5.
- 3) Image size: first two images is 160×128, others are same as pre-setting. If image size is 640×480, only two additional images can be taken except two fixed size images.
- Image capture interval: first two images is 500 ms, others same as pre-setting. Refer "Chapter 5. Advanced operation, 17. Capture image interval".

Auto cancel defense:

After alarm times reaching to the setting value and sending out the MMS alarm successfully, the camera will auto quit defense status.

#138#1#

After successfully set, it will reply "Auto cancel defense activated". Then, the value of alarm times must be set (See "Auto cancel defense after several times alarm".)

Close auto cancel defense (default setting).

#138#0#

After set successfully, it will reply:"Auto cancel defense de-activated"

Auto cancel defense after several times alarm.

To do this setting, you have to active the function of auto cancel defense first. #139#*times*#

After set successfully, it will reply: "set auto cancel defense after * time alarm successfully". Any alarm comes from the motion detector, PIR detector, sensor and remote control will be counted in alarm times. When the alarm times reach to the value setting in the "auto cancel defense after several times alarm", the camera will auto cancel defense and notify you " auto cancel defense" by SMS. After that, if you do any setting as below, set defense, cancel defense or auto cancel defense, the alarm times will be cleared to 0.

Send MMS to family number when alarm:#146#1#
Not send MMS to family number when alarm:#146#0#
Send SMS to family number when alarm:#147#1#
Not send SMS to family number when alarm:#147#0#

17. Emergency Alarm

(Authority: Master, Family)

If emergent state happening, the camera can make emergency call when the user presses the Emergency key of the remote control.

Two ways of emergency key alarm: dial emergency number (including master) and send SMS (MMS).

Master and families send SMS: #39#number#

If the number is 0 (default), when pressing emergency key of the remote control, the camera will dial master and other pre-set emergency number orderly for 3 times until answering. Answering the calling can hear the live voice.

After successful set, camera replies: "Set emergency alarm by dialing successfully".

If the number is 1, the camera will send SMS and MMS to master when alarm. After successful set, camera reply:" Set emergency alarm by SMS & MMS successfully.".

18. Add prefix number.

Add prefix number before mobile number for the number calling to catch

image:

#132#1#prefix number#

Not add prefix number before mobile number for the number calling to catch image:

#132#0#prefix number#

19. The notify SMS when the power changed.

Master or family number can send following SMS command to decide whether to send the notify SMS when the external power failure. (Default setting is notify the user through SMS when the external power changed.)

Send SMS when the power changed:

#144#1#

Not send SMS when the power changed:

#144#0#

When successfully set, the camera will reply: "Send SMS when the external power changed" or "not send SMS when the external power changed".

20. Image parameter setting

(Authority: Master, Family)

Set Image Size:

Master or family sends following SMS command to set three different sizes:

#32#value#

Value is 1, it means image size is 160 x128(pixel).

Value is 2, size is 320×240;(QVGA default).

Value is 3, size is 640×480 (VGA).

After successful set, camera will reply "Set image size successfully".

For normal small screen cell phone, the image size is 160×128 , one MMS image size is 4K.

For image QVGA (default) 320×240, one MMS image size is 9K.

For image VGA 640×480, one MMS image size is 33K.

If the value incorrect, camera will reply "Wrong parameter, please check and try again".

Image quantity when alarm:

#33#quantity#

Quantity is number 2-8, default is 5. After successful set, it will reply "Set alarm image quantity successfully". If wrong parameter, it will reply "Wrong parameter, please check and try again".

Note: if image size 640×480, max image quantity is 2.

Set Image brightness:

Master or family sends following SMS command to set five kinds of different brightness.

#34#value#

The value should be 1,2,3,4,5 (1 is darkest, 5 is brightest), default value is 4. After successful set, it will reply "Set image brightness successfully". If wrong parameter, it will reply "Wrong parameter, please check and try again".

Set Image direction:

The remote camera host can capture image in different direction. When fixed the direction, Master or family need to send following SMS command to set the image direction:

#35#value#

Value is 1, means Camera handstand direction capture image (camera is handstand capture image).

Value is 2, means camera thwart to capture image.

Value is 3, means camera capture image in normal level direction. Default value is 3.

After successful set, camera will reply "Set image direction successfully"; if wrong parameter, it will reply "Wrong parameter, please check and try again".

Set Image contrast:

Master or family sends following SMS command to set five different image contrast:

#38#value#

Value should be 1,2,3,4,5. The image contrast will enhance from 1 to 5, default value is 4.

After successful set, camera will reply "Set image contrast successfully"; if wrong parameter, it will reply "Wrong parameter, please check and try again".

Set image compressibility:

Master or family sends following SMS command to set four kinds of

compressibility:

#119#value#

Value should be 1, 2, 3, 4.

Value 1 means image compressibility 20 times (default).

Value 2 means image compressibility 14 times.

Value 3 means image compressibility 10 times.

Value 4 means image compressibility 5 times. (Invalid for 640×480).

After successful set, camera will reply "Set image compressibility successfully". If wrong parameter, it will reply "Wrong parameter, please check and try again".

Capture image Interval:

Master or family sends following SMS command:

#103#time#

Interval time value should be 3 to 10, the unit is 0.1 second. Default value is 5, it's 0.5 second.

After successful set, camera will reply "Set capture image interval successfully". If parameter wrong, it will reply "Wrong parameter, please check and try again".

The quantity and size of the image sent when motion detector activated.

Master edits: #142# 0#

The camera will send out 5 images with size of 160×128 (Pixel) when motion detector activated:

Master edits: #142#1#

The quantity of the images send out when motion detector activated is the same as the setting value in "Send image quantity when alarm". The size of the first 2 images is 160×128 (Pixel), the size of the others is the setting value in "set image size"

After successfully set, the camera will reply: "Set parameter successfully, the parameter is *".

21. Network parameter setting

(Authority: Master)

Generally, user don't need to set the network parameter before use, The factory have set the right parameter according to different country's GSM network provider. If your remote camera can't send MMS all the time, you can try to do following operation:

MMS center setting:

Master sends following SMS command:

#124#MMS center#

For example: #124#http://mmsc.monternet.com#

Set APN parameters

Master sends following SMS command to camera:

#125#gateway IP#gateway port#APN#APN user name#APN password#

For example: #125#10.0.0.172#9201#cmwap#wap#wap#

Choose network operator's MMS parameter:

The factory has been preset some importer local operators MMS parameter in the camera. Master and family number send following SMS command to select the right operator according to the camera SIM card:

MMS sent by WAP mode

#145#operator# such as #145#vodafone#

MMS sent by HTTP mode,

#145#operator#HTTP#

When set successfully, it will reply "set operator *** MMS parameter successfully", the camera's MMS parameter is operator *** MMS parameter. If the camera did not preset MMS center, it will reply "Operator is not exist".

Noted: Detail operator list please ask local seller.

22. Timing send MMS

(Authority: Master, Family)

Available timing send MMS:

Master or family sends following SMS command to available this function:

#115#1#

After successful set, camera will reply "Timing send MMS open". It will send MMS to master according to the setting.

Set time period to send MMS:

Master or family sends following SMS command to camera:

#116#work day#period 1 start time#period 1 end time#period 1 interval#period 2 start time#period 2 end time#period 2 interval#...

Note: Each period time should set by start time, end time, interval. Max allow 3 periods.

The value of work day, hour, minute as following:

Work day: (one digit, 0-8)

0 means everyday;

8 means from Monday to Friday;

1 means Monday;

2 means Tuesday;

3 means Wednesday;

4 means Thursday;

5 means Friday:

6 means Saturday;

7 means Sunday.

Start time-end time: (4 digits, 24 hours, such as 0000 means 00:00AM, 2359

means 11.59 PM)).

Interval time: (1-3 digits, 1-480, means sending MMS image interval, the unit is minute) 1-480 minutes interval.

If parameter wrong, camera will reply "Wrong parameter, please check and try again".

Disable timing send MMS image

Master or family sends following SMS command to disable this function: #115#0#

After successful set, camera will reply "Timing send MMS image close".

23. Automatically cancel defense

The camera can be set to deactivate defense after several times alarm. Master can set the alarm times by SMS command.

Set alarm times: #139#parameter#, parameter value between 1-100, it means the camera will deactivated the defense function after (parameter value) times alarm if this function activated.

Activated this function: #138#1#
Deactivated this function: #138#0#

24. Open/ Close indicator

When the indicator open, it will display in different ways to show camera working status. Close the indicator, it can make the camera private and avoid to be found easily.

Method 1: In normal work status, press the setting key for more than 2 seconds, it will close or open the indicator directly.

Method 2: Master edits following SMS and sends to camera:

Close indicator: #143#0# Open indicator: #143#1#

25. English and Spanish version switch

(Authority: Master)

Our product support English and Spanish language display, you need to send

following SMS command to get the right language you want:

Master sends following SMS command to camera:

Spanish version: #127#0#

After success set, it will reply "Set Spanish version successfully".

English version: #127#1#

After success set, it will reply "Set English version successfully".

26. Check status

(Authority: Master, Family, Guest)

User want to know the present setting and work status of camera, just need to send one of following SMS to camera, it will reply MMS including all settings (Not including the password.).

For master and families: #07#

For guest: #07#password#

Reply MMS content decided by the camera's actual work status:

Set defense (Or Cancel defense)

No SMS when alarm (or send SMS once alarm)

No MMS when alarm (or send MMS once alarm)

Motion detection open (or motion detection close)

Timing send MMS open (or Timing send MMS close)

Infrared light close (or infrared light open)

Image size: 160×128 (or 320×240 or 640×480)

Send image quantity when alarm

Image brightness

Image compressibility

Motion detection sensitivity

Master number

Master E-mail

Family E-mail

Camera user

Wireless sensor

Emergency number

English version (or Spanish version)

Note: details refer to the actual MMS reply from camera.

27. Getting help

(Authority: Master, Family, Guest)

If forget the SMS command, user can send SMS to get the help. Camera will send the command list or user guide to user's cell phone by SMS or MMS.

Get normal command help:

User sends following SMS command to camera:

For master and families: #09#

For guest: #09#password#

Camera will reply two SMS including normal commands as following:

Active equipment: #00#

Set defense: #01#Password#
Cancel defense: #02#password#

Require image quantity: #03#password#quantity#

Change password: #04#old password#new password#

Loaded sensor: #05#sensor description#

Added family: #06#number# Check status: #07#password#

Recover defeat setting: #08#password#

Get detail instruction:

User sends following SMS command to camera:

For master and families: #09#1#

For guest: #09#password#1#

Camera will reply "V900 user manual" by MMS to user's cell phone.

28. Reset the camera

(Authority: Master)

If the remote camera setting is wrong, or fail to work even after restarting the camera, the following operation will enable the remote camera restore to the

factory setting (clear of all users' setting), and resume to regular work status:

Method 1: Power off the camera, cut off the power for more than 20 seconds. Press and hold the setting key at the rear of the camera, switch on the camera, release the setting key when a "DI" tone can be heard. (The indicator will lighten constantly for 2-4seconds, and then flash slowly in red color when a "DI" tone sounded, which indicated restoring factory setting successfully.)

Note: After resetting the camera, the remote control is needed to reload. See "Chapter 5, Advanced Operation, 7 add / delete remote control" operation.

Method 2: Master sends following SMS command to camera:

#08#password#

After successful set, it will reply "The GSM camera has successfully reset to its default settings". The remote control is needed to reload too.

Password is required with the SMS command, otherwise, it will reply "You forgot including 4 digit password to reset camera".

Generally, after restore to factory settings, the network parameters such as MMS center, APN etc. are not needed to reset, unless it is necessary.

Chapter 6 Maintenance

Store and use the remote camera in suitable temperature. Too high or too low temperature will likely to damage the device.

Try to keep the host and all its accessories dry. Do not store and use it in the bathroom, or other place with high humidity. Do not allow pour water or other liquids into the camera, otherwise, it might cause malfunctions.

Do not store and use the camera in dusty.

Do not use alcohol, acetone and other similar solvents to clean it. Wipe it with soft-wet cloth.

Do not attempt to open it except as instructed. If the camera does not work normally, try to resolve it as the guide of the "general troubleshooting", if to the problem can not be solved, contact with the dealer immediately.

To prolong the life-span of the battery, connect the camera host to the power supply to charge the built-in Lithium battery for 4 hours every 3 months if the camera does not use for long time. Charge the battery at least 12 hours at the first time use to achieve the full performance of the battery.

Chapter 7 General Troubleshooting

No.	General Trouble	Possible Reason	Solution
1	Can't start camera	Other master already be	Recover to factory
ı	(Indicator is work)	set in the camera.	default setting.
2	All functions disable (Indicator is work)	Calling line presentation or MMS functions of the SIM card do not active, insufficient fee of the SIM card.	Contact network provider to active SIM card function. Pay for the card.
3	Indicator constant light in red color.	Can't find or identify the SIM card;	SIM card no install properly: Power off the camera and check it again.
4	Camera didn't response of any operation.	Host work abnormally.	Switch off the power, check SIM card, or reset factory setting.
5	After starting the camera, indicator flashed in red color	Network signal weak or network busy. SIM card PIN code	Place the camera at other place with strong signal and try again. Close the PIN code.
	and can not turn to green.	active. SIM card invalid.	Contact with local operator to check of it.
	Domesto control	Camera low power.	Connect external power to recharge the battery.
6	Remote control can't work. Or action slowly. Or control distance	Remote control low power.	Change remote control battery.
6		Didn't pull out the antenna.	Pull out remote control antenna.
	range shortened.	Two remote control work simultaneously.	Try only one remote control.
7	Can't add new remote control or wireless sensor	The remote control or sensor already studies successfully.	Exit the loading status.
		The sensor quantity	Delete old sensors

		already reach its max	before add new sensor.
		number.	
		Didn't set master	Set master number
		number.	before add sensor.
8	Can't start the	Battery run out of power.	Connect the camera to
	camera after long		external AC power and
	time supply with		charge for at least one
	the battery.		hour, then, restart
			camera.

Note: If the problem can't be solved with above guidelines, contact to your local distributor or after service center.

Chapter 8 Main Technical Parameters

Power adaptor Input: 100V~240V/50Hz Output: 5.5V DC

Work temperature $-10 \sim +45$ Store temperature $-20 \sim +60$

Relative Humidity 10-90%, without condensation

Working band EGSM900、DCS1800 (GSM850、PCS1900 Optional)
Communication protocols GSM PHASE 2/2+(including data operation)

Wireless sensor receiving code ASK

Wireless sensor receiving band 315MHz (433MHz optional)

Max wireless sensor 15 units

Remote control receiving band 315MHz (433MHz optional)

Effective distant of the remote control 10 Meters (wide area)

Image format JPEG

Image resolution 160×128 QVGA320 $\times 240$ VGA640 $\times 480$

Camera pixel300K pixelCamera Shooting angel60.8 degreeBest shooting distance in night≤6 meterLithium battery800mAh

Battery standby time 24 hours (Affected by network)

Appendix: SMS command list

User	Function	SMS Command
Mootor	Start remote	#00#
Master	camera	Refer to Chapter 4. Quick Start 2. Start remote camera.
	Chango	#04#old password#new password#
	Change Password	Refer to Chapter 5. Advanced operation, 2. change password.
	Change master	#14#new master number#
	Change master number	Refer to Chapter 5. Advanced operation, 3. change master number.
	Add family	#06#family number#
	Add family number	Refer to Chapter 5. Advanced operation, 4. Add or delete family number.
	Dalata Gara	#113#family number#
Master	Delete family number	Refer to Chapter 5. Advanced operation, 4. Add or delete
Waster	Hamber	family number.
	Add emergency- number	#106#telephone number#
		Refer to Chapter 5. Advanced operation, 5. Add or
		delete emergency number.
	Delete	#107#
	emergency	Delete all numbers except mater number, refer to
	number	Chapter 5. Advanced operation, 5. Add or delete emergency number.
		#39# <i>number</i> #
	Emergency alarm way	The number is 0, means make calls, 1 means send SMS and MMS.
	Add prefix	and mine.
	number before	#132#1# prefix number #
	mobile number	
Master	Not add prefix	#400 #0 # #
	number before	#132#0# prefix number #
	mobile number	
	Refer to Chapter 5	Advance operation 18. Add prefix number
Master and	Set defense	#01#
family	Set deletise	Refer to Chapter 5. Advanced operation, 8. Set defense.

User	Function	SMS Command
		#02#
	Cancel defense	Refer to Chapter 5. Advanced operation, 9. Cancel
		defense.
	Add or delete	#05#sensor description#
	sensor	Refer to Chapter 5. Advanced operation, 10. wireless
	3611301	sensor.
		#112#
	Delete sensor	Delete all sensors, refer to Chapter 5. Advanced
		operation, 10. Wireless sensor.
Master and	Delete remote	#111#
family	control	Refer to Chapter 5. Advanced operation, 6. Add or delete
	Control	remote control.
	Active infrared	#118#1#
	body detector	# 110#1#
	Disable infrared body detector	#118#0#
		Note: refer Chapter 5. Advanced operation, 12. Infrared
		body detector.
	Close infrared	#31#0#
Master and	light	#31#0#
family	Turn on Infrared	#31#1#
lailing		Refer to Chapter 5. Advanced operation, 13. Infrared
		light.
Master,		#03#quantity#
Family, and	Capture MMS Image	#03#password#image quantity#
Guest		Refer to Chapter 4. Quick Start, 6. Capturing images,
		and Chapter 5. Advanced operation, 14.Capturing
		images.
	Send image to	#03#image quantity#1#
	E-mail	Refer to Chapter 5. Advanced operation, 14.Capturing
	(Guest forbid)	images. How to set E-mail, refer to Chapter 5. Advanced
	(Cassi loibia)	operation, 15. E-mail.
	Check status	#07#
		#07#password#
		Refer to Chapter 5. Advanced operation, 26. Check
		status.

User	Function	SMS Command
	Get normal	#09#
	command help	#09#password#
		#09#1#
		#09#password#1#
	Get detail	Refer to Chapter 5. Advanced operation, 27. Getting
	instruction	help.
		Refer to Chapter 5. Advanced operation,16. Alarm
		setting.
	D	#08#password#
	Recover factory	Refer to Chapter 5. Advanced operation, 28 Reset the
	setting	camera.
Mantan	Set MMS center	#124#MMS center#
Master		#125#gateway IP#gateway port#APN#APN user
	Set APN	name#APN password#
	parameter	Refer to Chapter 5. Advanced operation,21. Network
		Parameter setting.
		For WAP:
		#145#operator# Such as #145#WAP#vodafone#
	Choose network	For Http: #145#operator#HTTP#
Master	operator's MMS	
	parameter	Refer to Chapter 5. Advance operation 21.
		Choose network operator's MMS parameter:
Master and		Automatically alarm
family	Warning tone	"100"1"
	when alarm	#130#1#
	No warning tone	#130#0#
	when alarm	Refer to Chapter 5. Advanced operation,16 Alarm
	(default)	setting.
	No SMS when	#11#0#
	alarm	#11#U#
	Send SMS	
	when	#11#1#
	alarm(default)	
	No colling when	#12#0#
	No calling when	#13#U#

User	Function	SMS Command
	alarm (Default)	
	Calling when alarm	#13#1#
	Not send MMS	
	to E-mail when	#110#0#
	alarm (Default)	
	Send MMS to	
	E-mail when	#110#1#
	alarm	
	Not sent MMS	#12#0#
	when alarm	#12#0#
	Send MMS	
	when	#12#1#
	alarm(default)	
		#33#quantity#
	Send image	The quantity is between 2 and 8, default is 5. If image
	quantity when	size is 640×480, the quantity is 1 or 2.
	alarm	Refer to Chapter 5. Advanced operation, 16. Alarm
		setting.
	Set	#139#value#
	automatically cancel defense alarm times	The value is between 1 and 100.
	Set	#138#value#
	automatically cancel defense	The value can be 0 or 1, 1 means activated this function, 0 means close this function.
	01/ 0	#143#value#
	Close/ Open	The value can be 0 or 1, 0 means close the indicator, 1
	indicator	means opean the indicator, default setting is 1.
Master and	Not send SMS	
family	when set or	
laililly	cancel defense	#137#0#
	by remote	
	control.	

User	Function	SMS Command	
	SMS notify when		
	set or cancel	#4.27#4#	
	defense by	#137#1#	
	remote control.		
	Only send SMS		
	when wireless	#140# sensor description ##	
	sensor alarm		
	Cancel only	#140#	
	send SMS when	Refer to Chapter 5. Advanced operation, 15. Alarm	
	sensor alarm	setting.	
	Close/ Open	#4.42#value#	
	indicator	#143#value#	
	Send SMS when	The value can be 0 or 1. 0 mappe close the indicator 1.	
	the power	The value can be 0 or 1, 0 means close the indicator, 1	
	changed	means open the indicator, default setting is 1.	
	Not send SMS		
	when the power	#144#0#	
	changed		
Master and	Send MMS to	#146#1#	
family	family number	#140#1#	
laililly	when alarm:		
	Not send MMS	#146#0#	
	to family number	#140#0#	
	when alarm:		
	Send SMS to	#147#1#	
	family number	# 1 -11 # 1 #	
	when alarm:		
	Not send SMS		
	to family number	#147#0#	
	when alarm:		
		Emergency Alarm	
Master and	Calling when press		
family	Emergency	#39#0#	
lailiny	key(default)		
	Send SMS and	#39#1#	

User	Function	SMS Command
	MMS when press	
	Emergency key	
Master and family	Active timing	#115#1#
	send MMS	
	Close timing	#115#0#
	send MMS	
	Set timing period to send MMS period	#116#work day#period1 start time#period1 end
		time#period1 interval##period2 start time#period2
		end time#period 2 interval##period3 start
		time#period3 end time#period3 interval#
		Refer to Chapter 5. Advanced operation, 22. Timing
		send MMS.
	Close motion	#22#0#
	detection	
	Open motion detection	#22#1#
Master and		Refer to Chapter 5. Advanced operation, 11. motion
family		detection.
	Motion detection sensitivity	#36# <i>grade</i> #
		Note: the grade can be 1,2,3,4,5.Default value is 4. the
		larger the number, the stronger the sensitivity.
Master and		#32# <i>value</i> #
family	Set image size	Value 1, size 160×128(pixel).
		Value 2(default): QVGA size 320×240(pixel).
		Value 3: VGA size 640×480(pixel).
	Set image brightness	#34#value#
		The value should be: 1,2,3,4,5 (1 is darkest, 5 is
		brightest), default value is 4.
	Set Image	#38# <i>value</i> #
	contrast	The value should be 1,2,3,4,5, default value is 4.
	Set Image	#35#value#
	direction	The value 1 means up down, 2: left, right; 3: normal.
		#119#value#
	Set image	
	compressibility	Notes
		Note:
		Value 1 is 20 times (default).

Value 2 is ⁴⁵ 14 times.

User	Function	SMS Command
		Value 3 is 10 times. Value 4 is 5 times. (invalid for 640×480) Refer to Chapter 5. Advanced operation, 18. Image parameter setting.
	Interval of capture image	#103#time# Interval time should be 3-10, unit is 0.1 second, and default value is 5. Refer to Chapter 5. Advanced operation, 18. Image parameter setting.
Master and family	Motion detection alarm image quantity and size.	#142#0# Send out 5 images with size of 160×128(Pixel) when motion detector activated:: #142#1# The quantity of the images send out when motion detector activated is the presetting value in "Send image quantity when alarm", the size of the first 2 pictures is 160×128(Pixel), the size of the other pictures is the presetting value in "Set image size". Refer to Chapter 5. Advanced operation, 20. Image parameter setting.
Master and family	Add or modify E-mail Delete E-mail	#108#EMAIL# EMAIL means E-mail address. #109# Refer to Chapter 5. Advanced operation, 15. E-mail.
Master	English and Spanish version switch	#127#value# Value 0 is Spanish version. Value 1 (default) is English version. Refer to Chapter 5. Advanced operation, 25. English & Spanish version switch.

FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for uncontrolled environment .This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.