



User manual Transceiver module TXRX01

6.1 MODULE TXRX01 STR

FCC ID: XL4-TXRX01
IC: 8716A-TXRX01
Modell: TXRX01 STR

FCC ID: XL4-TXRX01 IC: 8716A-TXRX01 STR RABC DEF

Label for TXRX01 STR module (1,8 cm * 2,9 cm)

If the label is not visible when the module is installed inside another device, then the outside of the device into which the module is installed must also display a label referring to the enclosed module.

Contains

FCC ID: XL4-TXRX01 IC: 8716A-TXRX01 Modell: TXRX01 STR

Exterior label TXRX01 STR (3 cm * 4,1 cm)

6.2 MODULE TXRX01 UFL

FCC ID: XL4-TXRX01
IC: 8716A-TXRX01
Modell: TXRX01 UFL

FCC ID: XL4-TXRX01 IC: 8716A-TXRX01 UFL Modell: TXRX01 UFL F12 3 4 15 6 5 879 471

Label for TXRX01 UFL module (1,8 cm * 2,9 cm)

If the label is not visible when the module is installed inside another device, then the outside of the device into which the module is installed must also display a label referring to the enclosed module.

Contains

FCC ID: XL4-TXRX01 IC: 8716A-TXRX01 Modell: TXRX01 UFL

Exterior label TXRX01 UFL (3 cm * 4,1 cm)

File: TXRX01 MODUL G (User Manual).doc

Created by: Christian Bernatek
Date: 24 November 2011

Rev.: 1.01