



PRODUCT DESCRIPTIONS

Riding bicycle is getting popular nowadays because more and more people take global warming and their health seriously. However, stealing bicycle also become a big problem. Bike Guardian provide a solution not only a brake light for riding safety but burglarproof. When some one want to steal your bicycle, the sensor in the device would detect the movement. The device of transmitter and receiver will both triger the alarm to warn you. You can have more time to save your bicycle.

FFATURES

- · All mode can be set by remote control
- Provide real time burglarproof alarm
- Provide warning and brake light to keep you safe in driving.
- Support Tx/Rx connectivity alarm

SAFETY PRECAUTIONS

Please follow the safety precautions carefully before you use the product. Make sure that you use the product correctly according to the procedures described in the guide.

- 1. Never place the product close to equipment generating strong electromagnetic fields.
- * Exposure to strong magnetic fields may cause malfunctions.

 2. Never plug or unplug the product if your hands are wet,
- otherwise it will may cause electrical shock.

 3. Do not drop the product to the ground to avoid malfunction.
- 4. Do not attempt to disassemble or alter any part of the product
- that is not described in this guide.
- 5. Do not put heavy material on the product. 6. Do not use the product in a wet location.
- * In the event that water or other liquids enter the interior, immediately
- unplug the product from the computer. When continuing usage of the product under above situation may cause
- fire or electric shock 7. Do not place the product near a heat source or expose them to direct
- 8. Do not place the product in damp or dusty places.

SPECIFICATIONS

Transmitter

Size	92mmx59mmx59mm	
Power (Operation time)	50hrs	
	(AAA battery x 3)	
Transmission Distance	50m typ. (Open Space)	
Operating Temperature	0°C ~ +60°C (Excluding Battery)	
Relative Humidity	5% ~ 95%,	
	non-condensing.	
Frequency	ISM, 2.4GHz ~ 2.5GHz	
Output Power	0dBm, typ.	
Power Supply	4.5V DC (typ.)	
Red LED	Brake & Alarm Indicator (5 LEDs)	
	125 Lux (0 cm)	
Voice	100 dB	
Dust & Waterproof	IP65	

Receiver


Size	72mmx32mmx12mm	
Power (Operation time)	25hrs	
	(AAA battery x 1)	
Transmission Distance	50m typ. (Open Space)	
Operating Temperature	0°C ~ +60°C (Excluding Battery)	
Relative Humidity	5% ~ 95%, non-condensing	
Frequency	ISM, 2.4GHz ~ 2.5GHz	
Output Power	0dBm, typ.	
Power Supply	1.5VDC (typ.)	
Sensitivity	±8g for three axis	
	(adjustable by software)	
Red LED	Alarm Indicator	
Blue LED	Daytime Indicatior	
Green LED	Nighttime Indicator	
Yellow LED	Low battery Indicatior	
Voice	100 dB	


Package List

Transmitter x1	Receiver x1	User manual x1	
Stand x1	Screw (Small) x1	Screw (Big) x2	

PRODUCT OVERVIEW

Transmitter





4. Please follow the image on the battery holder to Install 3 x AAA battery (please note the orientation of battery).



5. Right turn to firm screws on the battery holder.



5. Right turn to firm the lampshade.

GETTING STARTED

Burglar Alarm Device Installation and Use



1. Left turn to take the lampshade off



2. Left turn to remove screws



Stand Installation



- 1. Setup the stand at the prop under the seat.
- 2. Right turn to firm the Bike Guardian on the stand



- 3. Turn a suitable angle for firm the Bike Guardian on the stand in case of the shaking when riding.
- 4. Turn an angle to make Bike Guardian parallel the road.

APPLICATION

Daylight mode

- 1. When both burglar alarm device and remote controller are powered on, the device will enter Daylight mode automatically.
- 2. In Daylight mode, the remote controller will have Blue LED lighting.
 3. If user's device is in Night mode and want to change back to Daylight mode, press the function
- button until the Blue LED lights up. Then, release the function button.

 4. If user press the brake of the bike when riding, the device can detect the motion and light up the brake light.

Night mode

- 1. Press the function button of remote controller until Green LED lights up. Then, release the function button. And, LEDs of burglar alarm device will be twinkling. (default state)
- 2. Press the button of remote controller for once, the LEDs of burglar alarm device will be twinkling
- 3. If user press the brake of the bike when riding, the device can detect the motion and light up the

Burglar Alarm Mode

- 1. Press and hold the function button on the remote controller until the Red LED lights up. Then, release the function button.
- 2. At this point the burglar alarm device will sound twice and LEDs will flashes twice as well. It means the product has entered the Burglar Alarm mo
- 3. To enter the anti-theft mode after any move; shake or sloshing burglar alarm device, The
- transmitter and receiver will both triger the buzzer and LEDs will keep flashing.

 4. To release the Burglar Alarm function, press the button on the remote controller once

Other Setting

- 1. In burglar mode if it exceeds the transmission coverage, the remote controller will be constant 2. If the burglar alarm device is in low battery, the remote controller will beep and the Yellow
- LED will lights up. Please change the batteries if you have the situation.
- 3. If the remote controller is in low battery, the Yellow LED will lights up. Please change the battery if you have the situation.

Federal Communication Commission

This equipment has been tested and found to comply with the limits for a Class B digital device,

Interference Statement

pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



6. Power on the device. The LEDs will twinkle once and buzzer will have a sound "bee"

Remote Control Device Installation and Use



- Take the battery cover off.
 Install 1 x AAA battery (please note the
- 3. Install battery cover



4. Power on. The Blue LED will be lighten and