QRF600 Host

(Model) BLOCK DIAGRAM

ANT

USB To UART Data Transfer	⟺	MCU Atmega	SCL →	RF(2404.1~2448.0MHz)	⟺	ANT OUT

SCL

SI

SO

Crystal frequency (26MHz)

Crystal frequency (7.3728MHz)