	SM-500元件清单			
元件名称	元件标值	元件封装	用量	备注
	18K	1/16W	2	
	12K	1/16W	2	
	101R	1/16W	8	
	22K	1/16W	10	
	10K	1/16W	10	
	100K	1/16W	6	
	2K2	1/16W	18	
	331R	1/16W	7	
	150K	1/16W	2	
	470K	1/16W	2	
	3K3	1/16W	6	
	47K	1/16W	6	
	47R	1/16W	4	
	VR203	1/16W	6	
}	1K	1/16W	14	
-	8MM	1/16W	5	+
H	1K5	1/16W	2	
电阻	10R	1/16W	2	
电阻	0. 5P		2	
-		5%/50V	2	
-	1P	5%/50V	2	
	2P	5%/50V	2	
	15P	5%/50V		
	104P	5%/50V	1	
	102P	5%/50V	2	
	103P	5%/50V	44	
	102J	5%/50V	2	
	103J	5%/50V	2	
	201P	5%/50V	2	
-	203P	5%/50V	6	
, ,	39P	5%/50V	2	
	5P	5%/50V	4	
电容 - - - -	7P	5%/50V	2	
	100U	20%/35V	3	
	1000U	20%/35V	1	
	10U	20%/50V	2	
	1U	20%/50V	2	
	4U7	20%/50V	7	
	47U	20%/35V	3	
	2200U	20%/16V	1	
电解电容	2U2	20%/50V	8	
-	T1716	7. 5*7. 5*12. 5	2	
	T1718	7. 5*7. 5*12. 5	2	
	T1550	7. 5*7. 5*12. 5	10	
	1UH	10%	2	
电感	0.68UH	10%	2	

	4148	D0-35	8		
	C9014	T092	13		
	BF96	S0T-103	2		
	C1674	T092	2		
	LED	#3	5		
	LA1186	DIP-9	2		
	LA1135	DIP16	2		
	NE571	DIP16	1		
			2		
— 1 17. ≦≤	LM4558	DIP8			
二极管	7812	221A	1		
三极管	10. 7MS	OSC	2		
IC	XTAL	49T	2		
					
天线座			2		
电源插座			1		
锣丝			1套		
天线		, 	2		
电位器	B10K		2		
机箱 机箱	SM-500		1		
	DF-112A		2		
	DF-113A		2		
PCB板	JM-500A		1		
电位器线			2		
RF线			4		
机箱	SM-500		1套		
铝箱	SM-500		1套		
电池	9V		2		
说明书	SM-500		1		
电源器	15V-DC400mA		1		
面板	SM-500		1		
机脚			4		
开关			1		
咪管	2				
网头			2		
铝头	2				
6.35插座	1				
旋钮			2		