

You must be trained and authorized

You or others around you can be seriously injured or even killed if you don't use this truck correctly. Read and obey all warnings and instructions in the TSP Operator Manual and on the truck.

The operator must be constantly aware of everything around the truck that could affect personal or pedestrian safety, such as the pallet, load, and rack

Auto Position System (APS)


This optional feature improves productivity by helping you get to a pick location as quickly as possible. The APS feature can only be used when the truck is being guided, and after a pick task has been received and accepted by the operator. While traveling to the pick location (as displayed on the screen), APS will control raise/lower and stop the truck at the pick location.

Removing your left hand from the control handle will interrupt auto raise/lower. To continue operation your hands must be on the control handles. Cancelling a task will stop APS.

You always have complete control of your truck. Moving the primary raise/lower handle or changing travel direction (plugging), will override APS.

Various APS screens will be displayed to help you get to your pick location. Such as:

- Direction of pick location.
- Side of aisle where pick is located.
- APS system status



11-09-15?