User Manual

Visor Clip

Fig.1

LEARN

30

x2

Fig.2

To Program Remote Control(s):

1. See Fig.2 to add a Remote Control. Press the "LEARN" button on the rear control panel of the Opener. The courtesy light will illuminate with an audible click*. The unit is now ready to learn a Remote Control.

2. Within 30 seconds, press the button on the Remote Control.

3. The courtesy light will flash twice indicating Remote Control has been stored successfully**.

Up to 20 Remote Controls (including wireless keypad codes) can be added to the unit by repeating the above procedures.

If more than 20 Remote Controls are stored, the first stored Remote Control will be replaced. (i.e. the 21st Remote Control replaces the 1st stored Remote Control.)

* If the courtesy light is already on, it will flash once and stay illuminated for 30 seconds.

** If a Remote Control is not accepted, the courtesy light will stay on for 30 seconds, flash 4 times and then stay on for 4-1/2

minutes. Retry programming the Remote Control by repeating the steps above.

Removing ALL Remote Controls:

To remove ALL Remote Controls from memory, press and hold the "LEARN" button for 5 seconds. The courtesy light will flash 7 times indicating ALL Remote Controls have been removed from memory.

Replacing Remote Control Battery:

When the battery of the hand held Remote Control is low, the indicator light will become dim and/or the range of the Remote Control will diminish. To replace the battery, remove the battery cover from the Remote Control as shown in Fig 3. Replace with two CR2016 6 volt alkaline batteries with polarity