RADIO CONTROL SPINNER
BATTERY OPERATED
FLIPS!
SPINNING WHEELIES
FRONT AXLE SPINS!
FLASHING LIGHTS!
PERFORMS AMAZING STUNTS!
RADIO CONTROL
Boley
Where the action is!
5+
FOR AGES 5 AND UP
WARNING:
CHOKING HAZARD - Small parts
Not for children under 3 years
VEHICLE
TRANSMITTER
INSTALLING THE BATTERIES:
• Unscrew and open battery compartment cover to insert batteries in the toy as shown in diagram. Make sure all batteries are at correct polarity. Close the cover and tighten the screw.
• Use 3 "1.5V" batteries, type "AA" or equivalent for vehicle (not included).
• Use 1 "9V" batteries, type "6F22" or equivalent for transmitter (not included).
• Use only the batteries recommended.
• Do not mix alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd) batteries.
• Do not mix new and used batteries together.
• Remove batteries when toy is not in use.
• Remove used batteries from toy and dispose of in accordance with the maker's recommendation.
• Do not attempt to recharge non-rechargeable batteries.
• Do not use echargeable batteries.
• Batteries are to be inserted with the correct polarity.
• To avoid short-circuit, keep battery compartment free of all material except batteries.
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Instructions shall caution users that modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
■ Reorient or relocate the receiving antenna.
■ Increase the separation between the equipment and receiver.
■ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
■ Consult the dealer or an experienced radio/TV technician for help.
FREQUENCY: 27 MHz
WARNING: Not suitable for children under 3 years of age, due to small parts.
Product contents, specifications & colors may vary from illustration.
Please retain all information for future reference.
NO. 31374 MADE IN CHINA
© 2011 BOLEY CORP. CHINO, CA 91710
0 84495 31374 6
CMYK Diecut
material: E-flute with PVC window