
User's Manual

Congratulations on your new purchase of a Headrest Entertainment System, Please take a moment to fully review this owner's manual thoroughly prior to the initial operation, which will provide you with the best understanding to properly opeate your new Headrest Entertainment System.

Description of Buttons






AV	Front AV input port	Ω	Wired Earphone input
SMART	SMART LINK Input polt	USB	USB Slot & Smart Phone Charging

How to change VIDEO Sources

This unit has 6 different Modes. DVD, USB, AV, AV2, SMART, DTV



- 1. DVD
- 1) Press OPEN button on the unit to load DVD or CD disc
- 2) Completely close the LCD flip until you hear the sound "Click"
- 3) DVD or CD disc will be playing automatically.
- 1) Put USB Memory on the slot locted on right bottom side (inside of folding flip)
- 2) Press V.SEL button on the unit or Remote to move cursor to USB on the screen
- 3) Select target file using I<</>>I buttons in the unit or <</>>> button on the remote
- 4) Press"PLAY" button on the unit or remote to play & pause the file 5) Press"EXIT" button on the unit or remote to move to previous folder
- 3. AV 1) AV input locate on the left bottom side of unit(Inside of folding flip)
- 2) You can simply connect Portable or Handheld devices to this front AV input
- 1) AV2 input locate on the DIN to RCA cable (together with POWER and AV output)

2) This input designed for slave external devices such as TV tuner or Game console

- 5.SMART
- 1) Please connect SMART LINK cable from external unit to Headrest's SMART input port. 2) Please change Video mode to SMART
- 3) Operate External device (especially video). Same picture as external device will be shown on the Headrest screen

6. DTV

- 1) This input designed for Digital TV.
- 2) Only able to watching Digital TV Conmect with TV-300 tuner box (sold seperately).
- 3) Defail Position method is explained on TV-300 Manual.
- * Smart phone Interface
- 1) Basically, operation for SMART LINK function of Smart phone is same as above
- 2) To operate your Smartphone, please connect the specific cable shown below 3) Please make sure USB needs to be connected on the port to activate SMART LINK
- function on the smart phone

Description of Remote Control



1	1 POWER	NER POWER On/Off		
2	2 V.SEL	V.SEL Video Mode Selection		
3	B DIMMER	DIMMER On/Off		
۷	4 MENU	MENU OSD Display		
5	S ASPECT	Select from Normal/PS, Normal LB and Wide		
E	5 MUTE	MUTE On/Off		
7	7 INFO	Information of current playing file or Disc		
8	REPEAT	Repeat playing of currently selected file		
9	VOL-	Decrease volume level		
1	0 VOL+	Increase volume level		
1	1 🕊	Fast Forward(X2,X4,X8,X16)		
1	2	Rewind(X2,X4,X8,X16)		
1	3 144	Previous Chaper		
1	4 ▶1	Next Chaper		
1.	5 ► ■	Play or Pause the file or Disc		
1	6	Stop the file or Disc		
1	7 EXIT	EXIT from Folder or MENU		
1	8 SEARCH	Search Target position on the DVD or Media file		
1	9 🔺	Cursor Up		
2	0 🔻	Cursor Down		
2	1	Cursor Left		
2	2	Cursor Right		
2.	3 ENTER	Function Select		
2	4 SET-UP	SET-Up MENU Display and EXIT		
2.	5 ZOOM	X2,X3,X4 time ZOOM up,1/2,1/3,1/4 times ZOOM Down		
2	6 CH.LIST	DTV use only		
2	7 EPG	DTV use only		
2	8 1~0keys	Number keys		
2	9 A-B	A-B		
3	0 ANGLE	Angle adjust of picture (Only selected file or Disc)		
3	1 DVD ROOT	Move to DVD ROOT Menu		
3	2 DVD TITLE	Move to DVD TITLE Menu		
3.	3 SUB-TITLE	SUB-TITLE Selection		
3	4 AUDIO	Audio mode for Mono, Mono Left, Mono Right and Stereo		
3.	5 TV/RADIO	DVB-T use only		
3	6 RECALL	DVB-T use only		
3	7 FAV	DVB-T use only		
3	8 TTX	DVB-T use only		
3	9	DVB-T use only		
4	0	DVB-T use only		
4	1	DVB-T use only		
4	2	DVB-T use only		


FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the equipment and receiver.
- --Connect the equipment into an outlet on a circuit different from that to which the receiver is
- -- Consult the dealer or an experienced radio/TV technician for help.



MENU



Please refer Monitor MENU adjust as below

Color		
Menu	Value Adjust	Defaul Setting
Brightness	0~100	50
Contrast	0~100	50
Hue	0~100	50
Saturation	0~100	50
Sharpness	0~100	50
Color Temp	Warm, Normal, Cool	Normal

EXIT: Exit from the MENU

Function		
Menu	Defaul Setting	
Language	English, Chinese, French, German, Italian, Spanish, Portuguese, Russian	English
OSD Setting	OSD Timeout and Transparency	Setting
Display Ratio	16:9 and 4:3	16:9
IR	IR-A, IR-B, Off	IR-A
FM TX	88.1MHz~107.9MHz	Off
RESET	Back to factory setting	

EXIT: Exit from the MENU

SET-UP

SET-UP page is consist with 4 different settings. It's General Set up page, Audio Set up page, Video Set up page and Preference page.

* Preferece page only able to OPEN when DVD is completely "STOP" or "NO Disc" position When DV is playing or only temporary stop, "Preferense page" will not able to reach

Please press "STOP" 2 tines tomake Disc completely stop or OPEN Monitor flip to reach "Preference page".

*Please use ◀,▶,▼,▲ butons and ENTER button to go inside of detail MENU and exit from detail menu.

1.General Set up Page

MENU	DetailSelection	Default Setting
TV Display	Normal/PS , Normal/LB , Wide , Wide Squeeze	Normal/PS
Angle Mark	On , Off	On
OSD Lang	English, Chinese, French, German, Italian Spanish, Portuguese, Russian	English
Captions	On,Off	Off
Screen Saver	On,Off	On
Last Memory	On,Off	On

2. Audio Set up Page

MENU	Detail Selection	Default Setting
Downmix	LT/RT,Stereo,V SURR,Off	Stereo

3. Video Set up Page

MENU	Detail Selection	Default Setting	
Dual Mono	Stereo,L-Mono,R-mono,Mix-Mono	Stereo	

4.Preference Setup Page

MENU	Detail Selection	Default Setting
TV Type	PAL TV, Multi, NTSC TV	Multi
Audio	English, French, Spanish, Chinese, Japanese	English
Audio	Korean, Russian, Thai	English
Subtitle	English, French, Spanish, Chinese, Japanese	English
Subtitle	Korean, Russian, Thai	English
Disc Menu	English, French, Spanish, Chinese, Japanese	English
Disc Menu	Korean, Russian, Thai	English
Parental	KID,G,PG,PG 13,PGR,R,NC 17,ADULT	ADULT
Password	8888	8888
Default	RESET	RESET

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device is measured RF output power is less than the SAR exclusion threshold value

for human head and body. Therefore, SAR test is not necessary.