MINI4



USER MANUAL

4 Channel Transmitter





MINI4



This 2,4GHz features a unique coding protocol, to use this transmitter with a receiver it must be bound to the receiver. The factory will bind the transmitter to the receiver but should it become unbound or should you purchase a second receiver then please follow the procedure outlined below.

- 1. Connect a bind plug to the receiver.
- 2. Switch on the power to the receiver, the green receiver LED will now flash.
- 3. Now pick up the transmitter, before you switch it on please ensure that the throttle is in the lowest position and that all the trims are in the middle position.
- 4. Holding the bind switch in the up position now switch on the transmitter.
- 5. The transmitter green LED will start flashing and the receiver LED will have gone off.
- 6. Release the bind switch on the transmitter.
- 7. Remove the bind plug on the receiver, the green LED will now illuminate on the receiver and will now be bound to the transmitter.
- 8. Finally confirm that you have now have the full control over all surfaces and controls.

Please note it will depend on your model if you have a 4 or 6 channel radio transmitter.

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: The manufacturer is not responsible for any changes or modifications not expressly approved by the manufacturer for compliance, such modifications could void the user's authority to operate the equipment.