


WM8650: Power / Ground


PART: E+F






































WM8650: UART/KEYPAD/JTAG PART: H









Strapping Option


Pin	Internal Pull up/down	Default	Description
KPADCOL0	pull down	0	Inert PWRBTN# 0:debounced for a few cycles 1:kept 2s to trigger


VSUS33

R39 V4.7K/X KPADCOLO >> KPADCOLO 11,14

WARMING:

ALL others strappings not listed above recommend to use internal settings as default. Otherwise un-expected results may encounter.





Version History

Version	Modify Content	Responsibility	Date
WMS8121A	Initial released.	Ben Huang	2010/12/12

Power Sequence:

