User's Manual of Mobile Phone

TABLE OF CONTENT

| 1. BA | ASIC INFORMATION | 6 |
|--------------------------------------|---|----------------------|
| 1.1. | BRIEF INTRODUCTION | 6 |
| 1.2. | SAFETY NOTICE | 6 |
| 1.3. | SAFETY ALERT AND CAUTIONS | 7 |
| 1.3. | 1. General Cautions | 7 |
| 1.3. | 2. Cautions of Using the Phone | 9 |
| 1.3. | 3. Cautions of Using the Battery | 11 |
| 1.3. | 4. Cautions of Using the Charger | 13 |
| | FCC STATEMENT | |
| | | |
| 2. BE | CFORE USE | 16 |
| 2. BE | INSTALL SIM CARD AND MEMORY CARD | |
| | INSTALL SIM CARD AND MEMORY CARD | 16 |
| 2.1. 2.1. | INSTALL SIM CARD AND MEMORY CARD | 16 16 |
| 2.1. 2.1. 2.1. | INSTALL SIM CARD AND MEMORY CARD 1. Insertion and Taking out SIM Card | 16 16 17 |
| 2.1. 2.1. 2.1. | INSTALL SIM CARD AND MEMORY CARD 1. Insertion and Taking out SIM Card 2. Memory Card BATTERY | 16 16 17 |
| 2.1. 2.1. 2.1. 2.2. 2.2. | INSTALL SIM CARD AND MEMORY CARD 1. Insertion and Taking out SIM Card 2. Memory Card BATTERY | 16 16 17 17 |
| 2.1. 2.1. 2.1. 2.2. 2.2. | INSTALL SIM CARD AND MEMORY CARD 1. Insertion and Taking out SIM Card 2. Memory Card BATTERY 1. Install the Battery | 16 17 17 17 17 |

| 3.1. CA | LL LOGS | 20 |
|----------|----------------|----|
| 3.1.1. | Dialed calls | 20 |
| 3.1.2. | Received calls | 20 |
| 3.1.3. | Missed calls | 20 |
| 3.1.4. | Rejected calls | 21 |
| 3.1.5. | Delete all | 21 |
| 3.1.6. | Call timers | 21 |
| 3.1.7. | Call cost | 21 |
| 3.1.8. | GPRS counter | 22 |
| 3.2. Co | NTACTS | 22 |
| 3.2.1. | Details | 22 |
| 3.2.2. | New | 23 |
| 3.2.3. | Search | 23 |
| 3.2.4. | Write message | 23 |
| 3.2.5. | Call | 23 |
| 3.2.6. | Send vcard | 23 |
| 3.2.7. | Delete | 24 |
| 3.2.8. | Mark | 24 |
| 3.2.9. | Copy | 24 |
| 3.2.10. | Others | 24 |
| 3.3. INT | TERNET | 25 |
| 3.4. Mu | JLTIMEDIA | 26 |
| 3.4.1. | Camera | 26 |
| 3.4.2. | Audio Player | 26 |
| 3.4.3. | Video Player | 27 |

| 3.4.4 | FM radio | 27 |
|-------|-------------------|----|
| 3.5. | Message | 27 |
| 3.5.1 | . Write messages | 27 |
| 3.5.2 | . Inbox | 27 |
| 3.5.3 | . Outbox | 28 |
| 3.5.4 | Draftbox | 28 |
| 3.5.5 | Sentbox | 28 |
| 3.6. | Гооls | 28 |
| 3.6.1 | . Alarm | 28 |
| 3.6.2 | Bluetooth | 29 |
| 3.6.3 | . Calendar | 30 |
| 3.6.4 | Calculator | 30 |
| 3.6.5 | Recorder | 30 |
| 3.6.6 | 5. STK | 30 |
| 3.7. | APPLICATION | 31 |
| 3.7.1 | . Image browser | 31 |
| 3.7.2 | | |
| 3.7.3 | Sokoban | 31 |
| 3.8. | FILE MANAGEMENT | 32 |
| 3.9. | SETTINGS | 32 |
| 3.9.1 | . Call settings | 32 |
| 3.9.2 | Phone settings | 33 |
| 3.9.3 | Display settings | 34 |
| 3.9.4 | Security settings | 35 |
| 3.9.5 | Profiles | 37 |

| | 3.9.6. | Connection management | 37 |
|----|--------|-----------------------|----|
| 4. | TEX | Γ INPUT | 37 |
| 5. | CAR | E AND MAINTENANCE | 38 |
| 6. | ADD | ITIONAL SAFETY | |
| IN | FORM | MATION | 40 |

1. Basic Information

1.1. Brief Introduction

Thanks for selecting the color screen GSM/GPRS digital mobile phone. Through reading the manual, you can fully know how to use the mobile phone, appreciate its complete function and simple operating method.

1.2. Safety Notice

If your phone is lost or stolen, please immediately inform the telecom department or commission agents of forbidding the use of SIM card, so that avoid the economic loss caused by false calling of others.

■ When you contact with telecom department or commission agents, they need to know your phone IMEI number (printed on the label on the back of the phone and can be found after taking down the battery). Please copy the number and keep it safe for future use.

In order to use the phone more safely, please adopt preventive measures, for example: set up the PIN code of SIM card, PIN code can prevent your SIM card from being used by others without permission. When leaving the car, please don't place the phone in a place easy to be seen, you had better to carry with you or lock in the suitcase.

1.3. Safety Alert and Cautions

Before using the phone, please read these cautions carefully so that make sure to use the phone correctly.

1.3.1. General Cautions

- On the plane, in the hospital and other places that forbidden to use the mobile phone, please turn off the phone; otherwise it may affect the normal operation of electronic equipments and medical instruments. Please comply with the relevant regulations if using the phone in these places,.
- Please strictly comply with the laws and regulations about the phone use in the driving place. If you use the phone while you are driving, please comply with the following rules: concentrate on driving, pay attention to the road conditions; if the phone has hands-free function, please make a phone call hands free; if the driving conditions are not good, please stop the car, and then dial or receive a call.
- When approaching the places that storing fuel, chemicals or explosives, and etc., please comply with the laws, regulations and the relevant signs.
- Please place the phone, battery and charger in the place out of

- children's reach, for fear that the children use them as tools and cause personal injury.
- Your phone only can use the batteries, chargers and other accessories specified by the company for fear that the phone is damaged. If using other batteries and chargers, it may cause liquid leaking, overheat, explosion, fire breakout and other failures of batteries.
- Please don't use the phone close to weak signal or high precision electronic equipments. Wireless wave interference may cause the mis-operation of these electronic equipments.
- The phone has the function of timely auto power-on, please check the auto power-on and shutdown settings of the phone, so that confirm that the phone will not power on automatically during the flight.
- Please don't strike, shake or sling the phone violently for fear that the phone is failed or fire breakout.
- Please don't place the battery, the phone and the charger in the micro-wave oven or high-voltage equipment; otherwise may cause circuit damage or fire breakout and other accidents.
- Please don't use the phone in the places with inflammable and explosive gas; otherwise may cause phone failure or fire hazard.
- Please don't place the phone in the places with high temperature, high humidity or a large amount of dust;

- otherwise it may cause phone failure.
- Please don't place the phone in the uneven or unstable phone, prevent the phone from falling off and then cause failure or damage.
- Please only use the original antenna or the antenna being approved by the company. Unapproved and modified antenna or the antenna with additional accessories may damage the phone. Please don't touch the antenna during a call. Touching the antenna may affect the call quality and make the phone power higher than the required power in normal use. In addition, using the unapproved antenna may violate the regulations in your country.

1.3.2. Cautions of Using the Phone

- Don't take down or modify the phone; otherwise it may cause the damage, creepage and circuit failure of the phone.
- Please don't knock the LCD by force or use the LCB to knock other things; otherwise may cause the damage of liquid crystal plate and the leaking of liquid crystal. If liquid crystal enters the eyes, it may cause ablepsia. At this time, please rinse the eyes immediately with clean water (don't rub the eyes), and see a doctor immediately.
- In very rare cases, if the phone is used in some types of vehicles, it may have bad effect on the electronic equipments in the vehicle. At this time, please don't use the phone for fear

- of losing the safety guarantee.
- If your vehicle is equipped with the air bag, please don't place the phone above the air bag or the area that can be touched after the air bag is swelled, for fear that the phone is applied very strong external force and cause serious damage on the vehicle owner when the air bag is swelled.
- Please don't touch the keystoke using needles, pen nibs and other sharp objects; otherwise it may damage the phone or cause mis-operation.
- If the antenna is damaged, please don't use the phone; otherwise it may cause the personal injury.
- Don't make the phone approach to the magcard and other magnetic objejcts too closely; radiation wave of the phone may clean out the information stored in the floppy disks, stored value cards and credit cards.
- Please place the drawing pin and other small metal objects in the place that far from the headphone of the phone. The loudhailer is magnetic when it is working and will attract these small metal objects so that may cause personal injury or damage the phone.
- Avoid phone damping, prevent water and other liquid from entering the phone, and then cause short circuit, creepage or other failures of the phone.
- Please use the phone in the place that far from fixed telephone,
 TV, radio and office automation equipments, for fear that it

may affect the using effects of these equipments and the phone.

1.3.3. Cautions of Using the Battery

- Please don't take down or modify the battery; otherwise it may cause liquid leaking, overheat, explosion or fire breakout of battery.
- Don't throw the old battery into general life rubbish. Treat the battery according to the regulated indication in the place that definitely regulates the waste battery treatment.
- Please don't throw the battery into the fire, otherwise it may cause the fire breakout or explosion of the battery.
- When installing the battery, don't apply pressure forcefully; otherwise it may cause liquid leaking, overheat, explosion or fire breakout of the battery.
- Please don't make the battery short circuit using the electrical wire, needle and other metal objects; don't place the battery, necklace and other metal objects together; otherwise it may cause liquid leaking, overheat, explosion or fire breakout of the battery.
- Please don't solder the battery contact; otherwise it may cause liquid leaking, overheat, explosion or fire breakout of the battery.
- If battery liquid enter the eyes, it may cause ablepsia; at this time, please don't rub the eyes using the hand, please rinse the

- eyes with clean water, and then see a doctor immediately.
- Please don't use or place the battery near the fire or oven and other high temperature places; otherwise it may cause liquid leaking, overheat, explosion or fire breakout of the battery.
- If the battery is increasing the temperature abnormally, color change, distortion and other phenomena during the using, charging or storing process, please stop using it and then change new battery.
- If leaking liquid of the battery contacts with the skin and clothing, it may cause skin burn, please rinse it with clean water immediately, and see a doctor if necessary.
- If the battery is leaking liquid or giving out strange odor, please take the battery away from open fire immediately, avoid fire breakout or explosion.
- Please don't make the battery damp, otherwise it may cause overheat, smoking or corrosion of the battery.
- Please don't use or place the battery under direct sunlight and other high temperature places, otherwise it may cause liquid leaking or overheat, reduce the performance and shorten the service life.
- Please don't charge the battery continuously for more than 24 hours
- Please place the battery in the cool and ventilated place away from direct sunlight.
- Service life of the battery is limited. Service time of the

battery is gradually shortened after the frequent charging. If many times of charging is failed, it means that battery life is drained, please replace the new battery of designated type.

1.3.4. Cautions of Using the Charger

- Please don't take down or modify the charger; otherwise it may cause personal injury, electric shock, fire breakout or charger damage.
- Please use 220V alternating current. Using other voltage may cause creepage, fire breakout and damage the phone and the charger.
- Short circuit of the charger is forbidden; otherwise it may cause electric shock, smoking and charger damage.
- Please don't use the charger when the power cord is damaged; otherwise it may cause fire breakout or electric shock.
- Please clean the dirt that accumulates in the power socket in time.
- Please don't place the water container, and etc. near the charger, for fear of water splashing and then cause short circuit, creepage or other failures.
- If the charger contacts water or other liquid, please cut off power supply immediately, so that prevent short circuit, fire breakout, electric shock or charger failure.
- Don't use the charger in the bathroom and other high humidity places; otherwise may cause electric shock, fire

- breakout or charger damage.
- Please don't contact the charger, electrical wire and power socket with wet hands; otherwise it may cause electric shock.
- Don't place heavy object on the power cord or reconstruct the electrical wire; otherwise may cause electric shock or fire breakout.
- Please pull out the charger plug from power sockert before the cleaning and maintenance.
- Seize the charger when pulling the plug, pulling the power cord will damage the electrical wire, cause electric shock or fire breakout.
- Don't charge in the following places: direct sunlight and other high temperature places; wet and ashy place or the place with large vibration (will cause failure); near TV, radio and other home applications (will affect the image and sound effects).

1.4. FCC Statement

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two
- conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

 Changes or modifications not expressly approved by the party responsible for compliance could

void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure

requirement. The device can be used in portable exposure condition without restriction.

2. Before Use

2.1. Install SIM Card and Memory Card

2.1.1. Insertion and Taking out SIM Card

Metal contact surface of SIM card is easily scratched. You must take out SIM care carefully before the assembly.

- Power off the phone, remove the rear cover, battery or other external power supply.
- according to the prompt shown on the card slot of SIM card, press the card slot of SIM card using the finger, and then move at the direction of OPEN, open the card slot cover of SIM card, make one end with metal card and metal surface face downward, place the SIM card in the card slot, close the card slot of SIM card, press the card slot of SIM card using the finger, and then moves at the direction of LOCK.
- When taking out SIM card, directly pull it outward and then can take out SIM card.

Prompt: If not special explanation, the explanation in the text is described according to the conditions of inserting three SIM cards; if you only insert one SIM card, then

some menus may not be shown.

2.1.2. Memory Card

Take out the rear cover and battery, according to the prompt shown on the card slot of memory card, press the card slot of memory card using the finger, and then move at the direction of OPEN, open the card slot cover of memory card, make one end with metal card and metal surface face downward, place the memory card in the card slot, close the card slot of memory card, press the card slot of memory card using the finger, and then moves at the direction of LOCK., the other memory card is also inserted in this way.

Prompt: If the memory card is failed, please check whether it is correctly placed and good contact of metal point.

2.2. Battery

2.2.1. Install the Battery

- Take out rear cover of the phone.
- Make one end of battery with metal surface aim at the battery connector.
- Then gently press the battery downward using the finger, and then press the other end to install the battery.

Prompt: Please operate correctly so that avoid damaging the battery connector.

2.2.2. Charging

Insert the charger in the charging interface at the side end of the phone.

After inserting the charging plug, battery strength icon stripe at the top right corner of the screen is scrolling, which means that the charging is processing; when the stripe is full of the whole icon and stop scrolling, which means that the battery charging is completed; after the charging is completed, press the button at both sides of the charger, and then pull out the plug.

When electric quantity is not enough, warning message will be sent; and electric quantity shows empty. When electric quantity is too low, the phone will power off automatically. Please don't make the battery in the status of not enough electric quantity for a long time; otherwise it may damage the battery quality and service life. Please don't charge the battery for a long time.

Prompt: In order to ensure normal operation of the phone, please make sure to use the designated charger.

2.3. Security Password

■ PIN

PIN (Personal Identification Number) is used to prevent your SIM card from being used illegally. PIN is usually provided with SIM card together. If you input wrong PIN for continuous three times, please input PUK to unlock it. Please contact with network operations company for more details.

■ PIN 2

You need to input PIN2 when entering some functions (such as call charge); if you input wrong PIN2 for continuous three times, you need to input PUK2 to unlock it. Please contact with network operations company for more details.

■ PUK

When changing the locked PIN, you need to input PUK (Personal Unlock Key). PUK is provided with SIM card together. If it is not provided, please contact with your service provider. If you input wrong PUK for continuous ten times, the SIM card can't be used again. Please contact with your service provider to buy new card. You can't change PUK. If you lose the code, please contact with your service provider.

■ PUK2

When changing the locked PIN2, you need to input PUK2. If you input wrong PUK2 for continuous ten times, you can't the functions that need PIN2. Please contact with your service provider to buy new card. You can't change PUK 2. If you lose the code, please contact with your service provider.

3. Function Menu

3.1. Call logs

Display your recent call history.

3.1.1. Dialed calls

Display the list of your recent dialed numbers.

3.1.2. Received calls

Display the list of your recent answered numbers. The operation is the same as the Dialed.

3.1.3. Missed calls

Display the list of your recent missed numbers. The operation is the same as the Dialed.

3.1.4. Rejected calls

Display the incoming call records in the blacklist.

3.1.5. Delete all

You could delete all the records of the Dialed, Missed, Answered and Rejected.

3.1.6. Call timers

You could choose the view the time counting in SIM1/SIM2, which displays the last call, answered call, dialed call and all the calls. Press the left soft key, the time counting will be zero.

3.1.7. Call cost

Display the total call expense, the upper limit of the call, charges, rater reset, the functions of which shall be supported by the network operators.

Note: The call expense function shall be supported by the network operator. The design of the charging unit and the phone rate limit shall require you to input the PIN2

code. Please contact with your network operator to achieve the password.

3.1.8. GPRS counter

You could check the GPRS flow of the SIM1/SIM2, and press the left soft key to reset.

3.2. Contacts

This function could help you browse the phone book, store, edit and delete the names and phone numbers in the phone and SIM card. To facilitate the management of the records, this phone sets the group function, collecting the similar items into a group. The storage capacity of the SIM card varies and the maximum storage capacity of this phone is 500.

Under the standby interface, press the right soft key to enter the interface of the phone book. When the record of the phone book is not empty, press the left soft key for the following operation:

Note: Take the records in SIM card 1 for example.

3.2.1. Details

You can browse details of the contact.

3.2.2. New

Create new phone book records to SIM card or the mobile phone.

3.2.3. Search

Search the phone number by inputting the first character of each name.

3.2.4. Write message

Send SMS or MMS to this record.

3.2.5. Call

You can dial this record directly or use IP dial.

3.2.6. Send vcard

You can send vcard by SMS , MMS or Bluetooth.

3.2.7. Delete

Delete this record.

3.2.8. Mark

You can mark this record or mark all records.

3.2.9. Copy

Copy to phone
Copy all to phone
Copy all to SIM 1
Copy all to SIM 2
Copy to memory card

3.2.10. Others

■ Speed dial setting

Set this record into shortcut dial. After setting, under the standby interface, long press the number key you've set to call this record.

Note: Under standby interface, long press number key 1 will enter the voice mailbox of SIM card 1.

Under standby interface, long press number key 2 will enter the voice mailbox of SIM card 2.

Caller ID

Could set the number of this phone in SIM1, SIM2.

Note: Under the interface of the phone book, you could check the records of other group by pressing the left and right keys.

■ Memory status

Could enquire the capacity of SIM1, SIM2 and the phone.

■ Single line/Double line display

Could set the numbers display style in single line or double line.

3.3. Internet

The device is compatible with WAP service. You can visit various WAP services, for instance, news, weather forecast and airlines etc. The services are specially designed for the device and are maintained by WAP service supplier.

WAP service requires network backup. You can consult the network operator or service supplier about the availability, rates and tax of WAP services.

3.4. Multimedia

3.4.1. Camera

The device is equipped with a webcam with high pixels. You can take a photo at any time and save the photo in the device or SIM card. The photo can be used as wallpaper of your device or you can send it to your friends through MMS (multimedia messaging service).

You can view the photo on screen or press the OK key to take a photo. On the camera preview interface, press the left or right navigation key, you can enter several options, such as shoot mode, size, profiles, brightness, contrast, exposure bias, frame, cont.shot, white balance, delay, effect, and so on.

3.4.2. Audio Player

This phone could play the audio files stored in the phone and support the background play.

Note: only supported suffix named music .MP3 format.

3.4.3. Video Player

This phone could play the audio files stored in the memory card. And the phone supports the 3pg and mp4.

3.4.4. FM radio

The interface of the key features are as follows:

Left or right key: Switch the radio station has been stored in the list of previous, next

High or low key: in order search broadcasting station

Key # /*: control the volume size.

3.5. Message

3.5.1. Write messages

You can write SMS or MMS.

3.5.2. Inbox

Store the message and picture message you've received.

3.5.3. **Outbox**

Store the message and picture message you've sent in failure.

3.5.4. Draftbox

Store the message and picture message you've edited.

3.5.5. Sentbox

Store the message and picture message you've sent successfully.

3.6. Tools

3.6.1. Alarm

You can edit alarm, time, ring and repeated ring mode.

In "Edit" mode, when the cursor goes to the desired option, select it, then you can select desired settings.

3.6.2. Bluetooth

Open/Close BluetoothYou can choose to open or close the Bluetooth.

■ Bluetooth visibility
You can choose to Show phone or Hidden when you've activated the Bluetooth.

Paired device

Search Bluetooth in the menu (ensure the Bluetooth is "visible" before you search it, the detailed operation can be found in Bluetooth User's Guide). When the compatible Bluetooth is found, it will display on Bluetooth earphone list, then select "Bluetooth earphone", you will enter into PIN code input page, input PIN code "0000" (PIN code may vary since the Bluetooth earphones are different, which can be found in Bluetooth Earphone User's Guide), then ensure the Bluetooth earphone is started up.

When the selected compatible Bluetooth earphone gets started, you can activate it and make a call.

My Bluetooth nameYou can change the Bluetooth name of your phone.

■ Help

You can look the Help to get how to use the Bluetooth.

3.6.3. Calendar

You can look up the calendar according to this function. On the Calendar interface, you can add new schedule, view schedules, clear today's task, clear all, go to date, and so on.

3.6.4. Calculator

The function will make your device a calculator with which you can carry out simple math calculation.

3.6.5. Recorder

Use this function you can record or listen to your own record. You can also set the record as incoming call ring. The record file format: way.

3.6.6. STK

Enter STK submenu, you can use the additional services that the network service operator provided.

The device has STK function. The service is provided by network operator. If SIM card or network operator fails to provide

the service, the function can not be available. Contact network service operator, if you want to have more information.

3.7. Application

3.7.1. Image browser

You can browse the photos and pictures more conveniently in this function. Enter the image browser, select the options, you can change folder, send picture, slide play, delete, set image as wallpaper, rename, mark, and so on.

3.7.2. E-book

You can read the format of *.txt、*.Lrc files which located in the SD card.

When you save some files, select one, then select the Option, you can do several options, such as Detail, Last read books, Send with BT, Delete, Mark, Settings, and so on.

3.7.3. Sokoban

You can start new game, resume, select level, and view help.

3.8. File management

You can check the files within in SD card by the function and do some interrelated operations.

3.9. Settings

You can customize the settings, such as time and date, language, call settings etc.

3.9.1. Call settings

- Dual -SIM: You can do several operations, such as set dual SIM call divert, standby mode, main SIM settings, set SIM name, dual SIM settings and so on.
- Network selection: When your phone enjoys roaming service, the network can automatically or manually select network. The network roaming service can only be used when you subscribed the effective roaming service provided by the other network operator.
- Call divert: When "call divert" function is started up, you can transfer the incoming call to voice inbox or other phone number according to the scheduled "call divert" conditions.
- Call barred: All outgoing calls, incoming calls, roaming incoming calls, international outgoing calls, roaming

- international outgoing calls are available.
- Call waiting: You can activate or deactivate the function. When it is activated, even when you are making a call, you can also receive another income call.
- Hide ID: You can set Hide ID/Display ID/ Display ID by network/check status.
- Select line: Select line 1 or line 2.
- Flight mode: active/select when power on.
- Others: IP shortcut key, 50 sec warning, Connect prompt, Answer/Reject mode, Auto redial, and so on.

Note: The above-mentioned function will have to need network support. To use the function, please contact your network service provider.

3.9.2. Phone settings

- Time and Date: You can set up the date and time on the phone.
- Select language: You can select phone language.
- Input method settings: You can set input method.
- Shortcut settings: You can set shortcuts.
- Auto power on/off: Set the auto power on or off.
- Flash Light: You can set it activated or off. And you can press the "0" key for a moment to activated or off it in the

standby interface.

- Key vibrate: You can set it activated or off.
- Power management: You can review power management.
- Restore factory settings: Some settings of the phone can be restored to factory settings.

3.9.3. Display settings

- Wallpaper settings: You can customize different wallpaper images.
- Idle screen style: You can set standard style or smart style.
- Idle display settings: You can customize the standby display.
- Contrast: You can set the lightness of your phone.
- Backlight: "Always on", "30seconds", "20seconds", "15seconds", "10seconds" and "5seconds" are available.
- Keypad backlight time: "20seconds", "10seconds", "5seconds", "night mode" and "suspended" are available.
- Animation effect: You can set the animation effect of main menu effect, power on and off display and others.

Note: When "night time" mode is turned on, the keypad light will not be on from am 6:00 to pm 6:00.

3.9.4. Security settings

■ PIN

You can startup, suspend or modify PIN code. Correct PIN code shall be input when you unlock or suspend PIN code. If PIN code verification is started up, each time when you switch on your phone, you will have to input PIN code. If you input mistaken PIN codes three times in a row, SIM card will be locked. You will have to get PUK1 code to unlock it. Please contact network operator to get PUK1 code when necessary.

The default PIN code is 1234.

■ PIN2

You can review PIN2 code. For details, please contact network operator.

Privacy

You can review privacy protection password. Besides, you can also set passwords for some menus, in this way, you will have to input password each time when you desire to open the menus.

The default password of privacy protection mode is 1234.

Auto keypad lock

Start up the function, when the phone is in any mode and without being touched, it will automatically lock the keypad (In case the screen backlight will be always on, the keypad will not be automatically locked).

Lock screen by end-key

You can lock screen by end-key when activate it.

■ Power-on password

You can start up or suspend "phone password" or revise it. When "phone password" is started up, you will have to input "password" each time when you use the phone.

■ Guardlock

You can start up or suspend anti-theft function or revise anti-theft function password (the password shall be 6-digit). When "Theft proof" function is started up, your can only use your SIM card. If different SIM card is used, the phone will automatically check it when you switch it on, and the phone will require you to input protection password. If the password is correct, you can set up the SIM card so that it is compatible with the anti-theft function.

If three mistaken passwords are input, when you switch on the phone, it will send warning SMS to your original SIM card every 24 hours If the phone is switched off, the warning messages will be sent when you switch on the phone. The warning messages will indicate the existing SIM card and the

neighborhood number. When 15 warning SMS were sent out, the phone cannot be used. You will have to take the purchase evidence to ask for the dealer's help.

3.9.5. Profiles

You could set different scene modes. Including Normal, Silent, Meeting, Indoor, Outdoor.

You could choose Activate, customize or Rename. Connection management

3.9.6. Connection management

Network account

You can link the settings and add network accounts.

GPRS settings

You can choose connect when needed or always connect.

4. Text Input

The device provides several text input modes so that you can write text or input data in your "contacts", edit "contacts" record,

search English names and write SMS and to-do list.

In "text input" mode, if you want to change the input way, you can press "#" key.

5. Care and Maintenance

Maintenance of battery

- ·Your device is powered by a rechargeable battery. It is necessary to have the battery charged when it is going to wear out. The full performance of a new battery is achieved only when it is fully wore out.
- ·Unplug the charger from the electrical plug and the device when not in use. Do not leave fully a charged battery connected to a charger over a week, since overcharging may shorten its lifetime.
- ·Temperature tends to affect the limit of battery to be charged. Therefore, it is necessary for the battery to be cooled or warmed before it is charged. If the temperature of batter exceeds 40°C ,the battery cannot be charged.
- ·Use the battery only for its intended purpose and avoid short-circuiting. Accidental short-circuiting can occur when a metallic object causes direct connection of the positive(+) and negative(-) terminals of the battery.
- ·Do not use damaged battery.

- ·Leave the battery in hot or cold places will reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily, even when the battery is fully charged.
- •Do not dispose of batteries in a fire as they may explode. Dispose of batteries according to local regulations.

Care of maintenance of your device

The suggestions below will help you protect your warranty coverage.

- ·Keep the device and accessories out of the reach of small children.
- ·Keep the device dry. All types of liquids or moisture will corrode electronic circuits.
- \cdot Do not store the device in hot areas. High temperatures can shorten the life of electronic devices and warp or melt certain plastics.
- •Do not attempt to open the device other than as instructed in this guide. Non-professional handling may damage the device.
- ·Do not use harsh chemicals or strong detergents to clean the device.
- ·Use only the supplied or an approved replacement attachments, for the unauthorized ones could invalidate the warranty of maintenance.

6. Additional Safety Information

Remember to follow any special regulations in force and use the device only in its normal operation positions.

Traffic Safety

- ·Unless there is an emergency, otherwise do not use the device when you are driving a vehicle without safety wireless equipment. Please park the vehicle in a safe place before you use the device in order to guarantee that you pay all attention to drive. Observe related regulations.
- In case there is no adequate protection, certain electronic systems of the vehicle may be affected by the electric wave of the device.
- ·You are suggested to use the device only in vehicles with
- Only qualified personnel should install the device in a vehicle.

Aircraft Safety

Switch off your device before boarding an aircraft. The use of wireless teledevices in an aircraft may be dangerous to the operation of the aircraft, disrupt the wireless telephone network, and may be illegal. The GSM service will be unavailable. Using your device while flying in aircraft is

prohibited.

Environment Safety

- Remember to follow any special regulations in force in any area, and always switch off your device when its use is prohibited or when it may cause interference or danger.
- Operation of any radio transmitting equipment, including wireless phones, may interfere with the functionality of inadequately protected medical devices. Consult a physician or the manufacture of the medical device to determine if you have any questions.
- Your device may interfere with some hearing aids, pacemakers and other medical devices. Please obey the suggestions provided by physicians or medical device manufacturers.
- · You are suggested to switch off the device in any area with potentially explosive atmosphere, such as gas station, chemical factories etc.
- ·Observe restrictions on the use of radio equipment.

Body-worn Operation

This device was tested for typical body-worn operations. To comply With RF exposure requirements, a minimum separation distance of 1.5cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and Similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided.

Certification information (SAR)

Your model wireless phone meets the governmental requirements for exposure to radio waves. Your mobile device is a radio transmitter and receiver. It is designed and manufactured to not exceed limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. overnment and by the Canadian regulatory authorities. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed for the safety of all persons, regardless of age or health, and to account for any variations in measurements. The exposure standard for mobile devices employs a unit of measurement known as the Specific Absorption Rate (SAR). The IEEE SAR limit set by the FCC and by the Canadian regulatory authorities is 1.6 watts per kilogram (W/kg), averaged over one gram of tissue. Tests for SAR are conducted using procedures accepted by

the FCC and by Industry Canada with the mobile device transmitting at its highest certified power level in all tested frequencies. Although the SAR is determined at the highest certified power level, the actual SAR level of the mobile device while operating can be below the maximum value. This is because the mobile device is designed to operate at multiple power levels so as to use only the power required to reach the

network. In general, the closer you are to a wireless base station, the lower the power output.

Before a mobile device is available for sale to the public in the U.S. and Canada, it must be tested and certified to the FCC and Industry Canada that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) submitted to the FCC and available for review by Industry Canada. The highest SAR value for this mobile device when tested for use at the head is 850/1900: 0.312 W/kg, and when worn on the body, as described in this guide, is 850/1900: 1.150 W/kg. Body-worn measurements can differ, depending upon available accessories and regulatory requirements. The SAR information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product. While there may be differences between the SAR levels of various mobile devices and at various positions, they meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.