






DRAWN	DATE	MODEL: M855	E E
CHECKED	TIME	TITLE:	VERSION


















	DRAWN	DATE	MODEL:	M855E	
	CHECKED	TIME	TITLE:		VERSION










	DRAWN	DATE	MODEL:	M855E	
	CHECKED	TIME	TITLE:	VERSION	









DRAWN	DATE	MODEL:	M855E	
CHECKED	TIME	TITLE:		VERSION








DRAWN	DATE	MODEL:	M855E	
CHECKED	TIME	TITLE:		VERSION

## ATV\_NMI601B/ATV168H ATV + ISDB-T\_NMI5625





TIME


CHECKED

TITLE:

**VERSION** 







If NFI interface is 1.8V level, please change R903 to NC and R904 to 0R, and change software setting.

