



AIRCRAFT MAINTENANCE MANUAL

MAIN DOOR - SERVICING

EFFECTIVITY: ALL

1. General

- A. The procedure for the lubrication of the Main Door is given in [AMM TASK 52-11-00-600-801-A/300](#) (airstairs main door) or [AMM TASK 52-18-00-600-801-A/300](#) (side-hinged main door).

