



AIRCRAFT  
MAINTENANCE MANUAL

**AUTODISCHARGE FIRE EXTINGUISHER BOTTLE - ADJUSTMENT/TEST**

*EFFECTIVITY: ALL*

1. General

- A. This section gives the procedures to do the check of the toilet waste auto-fire-extinguisher bottle.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

<i>TASK NUMBER</i>	<i>DESCRIPTION</i>	<i>EFFECTIVITY</i>
26-25-01-720-801-A ♦	TOILET WASTE AUTO FIRE EXTINGUISH- ALL ER BOTTLE - WEIGHT CHECK	

**TASK 26-25-01-720-801-A**
**EFFECTIVITY: ALL**
**2. TOILET WASTE AUTO FIRE EXTINGUISHER BOTTLE - WEIGHT CHECK**
**A. General**

- (1) This task gives the procedures to do the check of the weight of the toilet-waste auto-fire-extinguisher bottle.
- (2) To do the inspection, it is necessary to remove the toilet-waste auto-fire-extinguisher bottle from the aircraft.

**B. References**

<i>REFERENCE</i>	<i>DESIGNATION</i>
AMM TASK 26-25-01-000-801-A/400	AUTODISCHARGE FIRE EXTINGUISHER - REMOVAL
AMM TASK 26-25-01-400-801-A/400	AUTODISCHARGE FIRE EXTINGUISHER - INSTALLATION
CMM ATA 26-25-12	-

**C. Zones and Accesses**

Not Applicable

**D. Tools and Equipment**

Not Applicable

**E. Auxiliary Items**

Not Applicable

**F. Consumable Materials**

Not Applicable

**G. Expandable Parts**

Not Applicable

**H. Persons Recommended**

<i>QTY</i>	<i>FUNCTION</i>	<i>PLACE</i>
1	Does the task	Toilet

**I. Preparation**
**SUBTASK 840-002-A**

- (1) Remove the toilet-waste auto-fire-extinguisher bottle ( [AMM TASK 26-25-01-000-801-A/400](#) )

**J. Toilet-Waste Auto-Fire-Extinguisher Bottle - Weight Inspection**
**SUBTASK 280-002-A**

- (1) Weigh the toilet-waste auto-fire-extinguisher bottle. Refer to the last revision of CMM ATA 26-25-12



AIRCRAFT  
MAINTENANCE MANUAL

K. Follow-on

SUBTASK 840-003-A

- (1) Install the toilet-waste auto-fire-extinguisher bottle ( [AMM TASK 26-25-01-400-801-A/400](#))

