



AIRCRAFT MAINTENANCE MANUAL

HEADLINER - REMOVAL/INSTALLATION

EFFECTIVITY: ACFT MODEL(S) EMB-145

1. General

- A. This section gives the procedures to remove/install the headliner panels.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
25-22-04-000-801-A	HEADLINER - REMOVAL	ACFT MODEL(S) EMB-145
25-22-04-400-801-A	HEADLINER - INSTALLATION	ACFT MODEL(S) EMB-145



AIRCRAFT MAINTENANCE MANUAL

TASK 25-22-04-000-801-A

EFFECTIVITY: ACFT MODEL(S) EMB-145

2. HEADLINER - REMOVAL

A. General

- (1) This task gives the procedures to remove the headliner panels.
- (2) The headliner panels are installed in the passenger cabin of the aircraft, zones 233, 234, 243, 253, and 263.
- (3) The headliner panels include four types of panels: a main-door region ceiling panel, a service-door region ceiling panel, a forward cabin ceiling panel, and eleven standard ceiling panels.

B. References

REFERENCE	DESIGNATION
AMM TASK 25-23-06-000-801-A/400	MAIN-DOOR TRIM SHROUD ASSEMBLY - REMOVAL
AMM TASK 25-23-07-000-801-A/400	-
AMM TASK 25-27-05-000-801-A/400	-
AMM TASK 25-27-07-000-801-A/400	GALLEY CURTAIN - REMOVAL
AMM TASK 25-31-03-000-801-A/400	OVENs AND OVEN CONTROLLERS - REMOVAL

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin

I. Preparation

SUBTASK 841-017-A

- (1) Make sure that the aircraft is safe for maintenance.
- (2) If the standard ceiling panel to be removed has lamps, do the steps below:

- (a) On the LH electrical power control/distribution box, open the RDNG LT/ATTD CALL 1 circuit breaker (Location Tip: RB SHED DC BUS 1/RDNG LT/ATTD CALL 1).
 - (b) On the overhead panel, set the EMERG LT switch to the OFF position.
 - (c) On the circuit breaker panel, open the EMERG circuit breaker (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).
- (3) Before you remove the main-door/service-door region ceiling panel, do the steps below:
- (a) For aircraft with outboard galley installed.
 - 1 On the ELECTRICAL control panel, on the overhead panel, make sure that the SHED BUSES rotary switch is set to the OFF position.
 - 2 Put a DO-NOT-SET-AUTO tag on the SHED BUSES rotary switch.
 - (b) On the circuit breaker panel, open the circuit breakers below:
 - 1 COURTESY LIGHT 1 (Location Tip: HOT BUS 2/COURTESY LIGHT 1).
 - 2 COURTESY 2 (Location Tip: DC BUS 1/LIGHTS/COURTESY 2).
 - (c) On the LH electrical power control/distribution box, open the COURTESY 3 circuit breaker (Location Tip: RB SERV BUS/COURTESY 3).
 - (d) On the overhead panel, set the EMERG LT switch to the OFF position.
 - (e) On the circuit breaker panel, open the EMERG circuit breaker (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).
- (4) Before you remove the forward cabin ceiling panel, do the steps below:
- (a) On the overhead panel, set the EMERG LT switch to the OFF position.
 - (b) On the circuit breaker panel, open the EMERG circuit breaker (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).

J. Removal ([Figure 401](#))

SUBTASK 020-017-A

- (1) To remove the standard ceiling panel (1), do the steps below ([Figure 402](#)):
- (a) Remove the shims (5).
 - (b) Remove the lens (6).
 - (c) Open the door of the overhead bin in front of the ceiling panel that you will remove and remove the screws (3) and washers (2) that attach the standard ceiling panel (1) to the overhead bin.
 - (d) Turn the standard ceiling panel (1) around the catch (4) and remove it from the PSU extrusion.


- (e) Disconnect the electrical connector (7), if applicable.
 - (f) Remove the standard ceiling panel (1).
- (2) To remove the service-door region ceiling panel (6), do the steps below ([Figure 403](#)):
- (a) Remove the door upper trim shroud (3) (AMM TASK 25-23-07-000-801-A/400).
 - (b) Loosen the Camloc fasteners (2).
 - (c) Insert a pin in the holes (5) of the galley curtain track (4) to release it, and remove the galley curtain assembly ([AMM TASK 25-27-07-000-801-A/400](#)).
 - (d) Loosen the Camloc fasteners (1).
 - (e) Disconnect the electrical connectors (7).
 - (f) Remove the service-door region ceiling panel (6).
- (3) To remove the forward cabin ceiling panel (1), do the steps below ([Figure 404](#)):
- (a) Remove the service-door region ceiling panel (3), do the steps above ([Figure 403](#)).
 - (b) Loosen the attaching screws (2) and remove the galley curtain-track support (4).
 - (c) Remove the access panel (8) with the screws (10) and washers (9), on the forward galley.
 - (d) Remove the plug (7).
 - (e) Loosen the screw (6) and washer (5) that attach the ceiling panel.
 - (f) Remove the access panel (14) with the screws (15) and washers (16), on the aft galley.
 - (g) Remove the plug (13).
 - (h) Loosen the screw (12) and washer (11) that attach the ceiling panel.
 - (i) Remove the shims (19) and the lenses (18).
 - (j) Move the forward cabin ceiling panel (1) to remove the catches (17) from the Passenger Service Unit (PSU) extrusion.
 - (k) Slide the right end of the forward cabin ceiling panel (1) over the top of the forward galley by approximately 51 mm (2 inches).
 - (l) Turn the left end of the forward cabin ceiling panel (1) counterclockwise around the right end until it passes the light deflector.
 - (m) Disconnect the electrical connector (20).
- (4) To remove the main-door region ceiling panel (1), do the steps below ([Figure 405](#)):
- (a) For aircraft with RH wardrobe or outboard galley without ovens installed ([Figure 405](#)).

- 1 Remove the main-door curtain-track assembly (5) (AMM TASK 25-27-05-000-801-A/400).
 - 2 Remove the door upper forward trim shroud (6) ([AMM TASK 25-23-06-000-801-A/400](#)).
 - 3 Open the miscellaneous door (2) and remove the screws (4) that attach the access plates (3).
 - 4 Loosen the Camloc fasteners (7) that attach the ceiling panel.
 - 5 Disconnect the electrical connectors (8).
 - 6 Remove the main-door region ceiling panel (1).
- (b) For aircraft with outboard galley with ovens installed ([Figure 406](#)).
- 1 Remove the main-door curtain-track assembly (8) (AMM TASK 25-27-05-000-801-A/400).
 - 2 Remove the door upper forward trim shroud (9) ([AMM TASK 25-23-06-000-801-A/400](#)).
 - 3 Remove the oven (7) ([AMM TASK 25-31-03-000-801-A/400](#)).
 - 4 Remove oven controllers (2) and (3) ([AMM TASK 25-31-03-000-801-A/400](#)).
 - 5 Open the LH compartment door (4).
 - 6 Remove the access plates (5) with the screws (6) (see DET. C).
 - 7 Loosen the Camloc fasteners (10) that attach the ceiling panel.
 - 8 Disconnect the electrical connectors (11) (see DET. F).
 - 9 Remove the main-door region ceiling panel (1).

EFFECTIVITY: ACFT MODEL(S) EMB-145


Headliner Panels - Removal/Installation

Figure 401




145AMM250087.MCE

EFFECTIVITY: ACFT MODEL(S) EMB-145
Standard Ceiling Panels - Removal/Installation
Figure 402 - Sheet 1




EFFECTIVITY: ACFT MODEL(S) EMB-145
Standard Ceiling Panels - Removal/Installation
Figure 402 - Sheet 2



145AMM250067.MCE

EFFECTIVITY: ACFT MODEL(S) EMB-145
Service-Door Region Ceiling Panel - Removal/Installation
Figure 403 - Sheet 1




145AMM250081.MCE A

EFFECTIVITY: ACFT MODEL(S) EMB-145

Service-Door Region Ceiling Panel - Removal/Installation


Figure 403 - Sheet 2



DET. B



145AMM250083.MCE A

EFFECTIVITY: ACFT MODEL(S) EMB-145
Forward Cabin Ceiling Panel - Removal/Installation
Figure 404 - Sheet 1





EM145AMM253442A.DGN

EFFECTIVITY: ACFT MODEL(S) EMB-145
Forward Cabin Ceiling Panel - Removal/Installation
Figure 404 - Sheet 2



EM145AMM253443A.DGN

EFFECTIVITY: ACFT MODEL(S) EMB-145
Forward Cabin Ceiling Panel - Removal/Installation
Figure 404 - Sheet 3





EM145AMM253444A.DGN

EFFECTIVITY: AIRCRAFT WITH RH WARDROBE OR OUTBOARD GALLEY WITHOUT OVENS


Main-Door Region Ceiling Panel - Removal/Installation

Figure 405 - Sheet 1


DET. A

DET. B

145AMM250084.MCE A

EFFECTIVITY: AIRCRAFT WITH RH WARDROBE OR OUTBOARD GALLEY WITHOUT OVENS
Main-Door Region Ceiling Panel - Removal/Installation
Figure 405 - Sheet 2




145AMM250085.MCE

EFFECTIVITY: AIRCRAFT WITH OUTBOARD GALLEY WITH OVENS


Main-Door Region Ceiling Panel - Removal/Installation

Figure 406 - Sheet 1



145AMM250096.MCE A

EFFECTIVITY: AIRCRAFT WITH OUTBOARD GALLEY WITH OVENS
Main-Door Region Ceiling Panel - Removal/Installation
Figure 406 - Sheet 2



145AMM250101.MCE A



AIRCRAFT
MAINTENANCE MANUAL

TASK 25-22-04-400-801-A

EFFECTIVITY: ACFT MODEL(S) EMB-145

3. HEADLINER - INSTALLATION

A. General

- (1) This task gives the procedures to install the headliner panels.
- (2) The headliner panels are installed in the passenger cabin of the aircraft, zones 233, 234, 243, 253, and 263.
- (3) The headliner panels include four types of panels: a main-door region ceiling panel, a service-door region ceiling panel, a forward cabin ceiling panel, and eleven standard ceiling panels.

B. References

REFERENCE	DESIGNATION
AMM TASK 25-23-06-400-801-A/400	MAIN-DOOR TRIM SHROUD ASSEMBLY - INSTALLATION
AMM TASK 25-23-07-400-801-A/400	-
AMM TASK 25-27-05-400-801-A/400	-
AMM TASK 25-27-07-400-801-A/400	GALLEY CURTAIN - INSTALLATION
AMM TASK 25-31-03-400-801-A/400	OVENs AND OVEN CONTROLLERS - INSTALLATION
AMM TASK 33-25-00-700-801-A/500	READING AND ATTENDANT CALL LIGHTS (1) - OPERATIONAL TEST
AMM TASK 33-26-00-700-801-A/500	COURTESY/STAIR LIGHTS - OPERATIONAL TEST
AMM TASK 33-50-00-700-801-A/500	EMERGENCY LIGHTS - OPERATIONAL CHECK

C. Zones and Accesses

Not Applicable

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Passenger cabin

I. Installation (Figure 401)

SUBTASK 420-017-A

- (1) To install the main-door region ceiling panel (1), do the steps below:
 - (a) For aircraft with RH wardrobe or outboard galley without ovens installed (Figure 405).
 - 1 Connect the electrical connectors (8).
 - 2 Put the main-door region ceiling panel (1) in its installation position.
 - 3 Turn the Camloc fasteners (7) to attach the main-door region ceiling panel (1).
 - 4 Install the screws (4) to attach the access plates (3).
 - 5 Install the upper forward trim shroud of the door (6) ([AMM TASK 25-23-06-400-801-A/400](#)).
 - 6 Install the main-door curtain-track assembly (5) (AMM TASK 25-27-05-400-801-A/400).
 - (b) For aircraft with outboard galley with ovens installed (Figure 406).
 - 1 Connect the electrical connector (11) (see DET. F).
 - 2 Put the main-door region ceiling panel (1) in its installation position.
 - 3 Turn the Camloc fasteners (10) to attach the main-door region ceiling panel (1).
 - 4 Install the screws (6) to attach the access plates (5) (see DET. C).
 - 5 Install the oven controllers (2) and (3) ([AMM TASK 25-31-03-400-801-A/400](#)).
 - 6 Install the oven (7) ([AMM TASK 25-31-03-400-801-A/400](#)).
 - 7 Install the upper forward trim shroud of the door (9) ([AMM TASK 25-23-06-400-801-A/400](#)).
 - 8 Install the main-door curtain-track assembly (8) (AMM TASK 25-27-05-400-801-A/400).
- (2) To install the forward cabin ceiling panel (1), do the steps below (Figure 404):
 - (a) Connect the electrical connector (20).
 - (b) Put the forward cabin ceiling panel (1), in its installation position, as follows:
 - 1 Slide the right end of the forward cabin ceiling panel (1) over the top of the forward galley by approximately 51 mm (2 inches).
 - 2 Turn the left end of the forward cabin ceiling panel (1) clockwise around the right end until it passes the light deflector.


- 3 Move the left end of the panel to fit the catches (17) into the Passenger Service Unit (PSU) extrusion.
- (c) Install the screw (12) and washer (11) that attach the forward ceiling panel to the aft galley.
 - (d) Install the screws (15) and washers (16) to attach the access panel (14) to the aft galley.
 - (e) Install the plug (13).
 - (f) Install the screw (6) and washer (5) that attach the forward cabin ceiling panel (1) to the forward galley.
 - (g) Install the screws (10) and washers (9) to attach the access panel (8) to the forward galley.
 - (h) Install the plug (7).
 - (i) Install the lenses (18).
 - (j) Install the shims (19).
 - (k) Install the screws (2) to attach the galley curtain-track support (4).
 - (l) Install the service-door region ceiling panel (3), do the steps below (Figure 403).
- (3) To install the service-door region ceiling panel (6), do the steps below (Figure 403):
- (a) Connect the electrical connectors (7).
 - (b) Put the service-door region ceiling panel (6) in its installation position.
 - (c) Turn the Camloc fasteners (1) and (2) that attach the service-door region ceiling panel (6).
 - (d) Install the galley curtain-track assembly (4). Push in the lock pins on the curtain track and hold them in until they engage the receptacles on the curtain-track support assembly ([AMM TASK 25-27-07-400-801-A/400](#)).
 - (e) Install the service-door upper trim shroud (3) ([AMM TASK 25-23-07-400-801-A/400](#)).
- (4) To install the standard ceiling panel, do the steps below (Figure 402):
- (a) Connect the electrical connector (7), if applicable.
 - (b) Set the left catch (4) of the standard ceiling panel (1) into the PSU extrusion.
 - (c) Turn the standard ceiling panel (1) around the catch (4) to align the bracket holes with the inserts on the overhead bin.
 - (d) Install the screws (3) and the washers (2) that attach the standard ceiling panel (1).
 - (e) Install the lenses (6).

- (f) Install the shims (5).

J. Follow-on

SUBTASK 842-017-A

- (1) If you installed the standard ceiling panel with lamps, do the steps below:
 - (a) On the LH electrical power control/distribution box, close the RDNG LT/ATTD CALL 1 circuit breaker (Location Tip: RB SHED DC BUS 1/RDNG LT/ATTD CALL 1).
 - (b) On the overhead panel, set the EMERG LT switch to the ARM position.
 - (c) On the circuit breaker panel, close the EMERG circuit breaker (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).
 - (d) Do an operational test of the emergency lights ([AMM TASK 33-50-00-700-801-A/500](#)).
 - (e) Do an operational test of the reading and attendant call lights ([AMM TASK 33-25-00-700-801-A/500](#)).
- (2) If you installed the main-door/service-door region ceiling panel, do the steps below:
 - (a) For aircraft with outboard galley installed.
 - 1 On the ELECTRICAL control panel, on the overhead panel, remove the DO-NOT-SET-AUTO tag from the SHED BUSES rotary switch and turn it to the AUTO position.
 - 2 On the circuit breaker panel, close the circuit breakers below:
 - 1 COURTESY LIGHT 1 (Location Tip: HOT BUS 2/COURTESY LIGHT 1).
 - 2 COURTESY 2 (Location Tip: DC BUS 1/LIGHTS/COURTESY 2).
 - (c) On the LH electrical power control/distribution box, close the COURTESY 3 circuit breaker (Location Tip: RB SERV BUS/COURTESY 3).
 - (d) On the overhead panel, set the EMERG LT switch to the ARM position.
 - (e) On the circuit breaker panel, close the EMERG circuit breaker (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).
 - (f) Do an operational test of the emergency lights ([AMM TASK 33-50-00-700-801-A/500](#)).
 - (g) Do an operational test of the courtesy/stair lights ([AMM TASK 33-26-00-700-801-A/500](#)).
- (3) If you installed the forward cabin ceiling panel, do the steps below:
 - (a) On the overhead panel, set the EMERG LT switch to the ARM position.
 - (b) On the circuit breaker panel, close the EMERG circuit breaker (Location Tip: ESSENTIAL DC BUS 2/LIGHTS/EMERG).



AIRCRAFT MAINTENANCE MANUAL

- (c) Do an operational test of the emergency lights ([AMM TASK 33-50-00-700-801-A/500](#)).