



EMB145 - EMB135

AIRCRAFT
MAINTENANCE MANUAL

NOSE WHEEL ASSEMBLY - INSPECTION/CHECK

EFFECTIVITY: ALL

1. General

- A. This section gives the procedure to inspect the NLG wheel assembly for general condition.
- B. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
32-49-05-200-801-A ♦	NLG WHEEL ASSEMBLY - INSPECTION	ALL



AIRCRAFT
MAINTENANCE MANUAL

TASK 32-49-05-200-801-A

EFFECTIVITY: ALL

2. NLG WHEEL ASSEMBLY - INSPECTION

A. General

- (1) This procedure gives the instructions to inspect the NLG wheel assembly for general condition.

B. Zones and Accesses

Not Applicable

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended



QTY	FUNCTION	PLACE
1	Does the task	NLG

H. Inspect (Visual Inspection) NLG Wheel Assembly for General Condition ([Figure 601](#))

SUBTASK 212-002-A

- (1) Inspect the wheel hubs (flange and web) for cracks.
- (2) Inspect the overpressure plug for general condition.
- (3) Inspect the nuts and bolts of the wheel hubs for general condition.
- (4) Inspect the bearing retainer for integrity and grease leakage.

EFFECTIVITY: ALL
NLG Wheel Assembly - Inspection
Figure 601



DET. A

145AMM320247.MCE A

