



AIRCRAFT  
MAINTENANCE MANUAL

**AILERON&ELEVATOR DISCONNECT SYSTEM - SERVICING**

*EFFECTIVITY: ALL*

1. General

- A. The procedures for the lubrication on the aileron disconnect system is given in [AMM TASK 27-15-02-600-801-A/300](#) and on the elevator disconnect system is given in [AMM TASK 27-35-00-600-801-A/300](#).

