UF_UDOP_ask_oper (view source)

Defined in: uf_udop.h

Overview

Returns an Operation Identifier for the input UF UDOP id t.

Environment

Internal and External

```
int UF_UDOP_ask_oper
(
    UF_UDOP_id_t udop_id,
    UF_OPER_id_t* oper_id
)
```

```
UF_UDOP_id_t udop_id Input The udop of requested oper

UF_OPER_id_t* oper_id Output The oper of this udop_id
```

UF_UDOP_ask_purpose (view source)

Defined in: uf_udop.h

Overview

Returns why the User Exit is being called. The purpose must be of type UF_UDOP_purpose_t.

Environment

Internal and External

See Also

```
See UF_UDOP_purpose_t
```

```
int UF_UDOP_ask_purpose
(
    UF_UDOP_id_t udop_id,
    UF_UDOP_purpose_t* purpose
)
```

	UF_UDOP_id_t	udop_id	Input	The udop of requested operation.
	UF_UDOP_purpose_t*	purpose	Output	The reason the User Exit was called

UF_UDOP_ask_udop (view source)

Defined in: uf_udop.h

Overview

Returns the UF_UDOP_id_t that corresponds to the UF_CAM_exit_id_t passed to the User Exit from NX.

Environment

Internal and External

```
int UF_UDOP_ask_udop
(
    UF_CAM_exit_id_t exit_id,
    UF_UDOP_id_t* udop_id
)
```

```
UF_CAM_exit_id_t exit_id Input exit_id passed to user exit from NX

UF_UDOP_id_t* udop_id Output The udop of this exit_id
```