

ESC 29h	F1 3Ah	F2 3Bh	F3 3Ch	F4 3Dh	F5 3Eh	F6 3Fh	F7 40h	F8 41h	F9 42h	F10 43h	F11 44h	F12 45h	Print 46h	Scrl 47h	Pau 48h		
^ 35h	1 1Eh	2 1Fh	3 20h	4 21h	5 22h	6 23h	7 24h	8 25h	9 26h	0 27h	ß 2Dh	‘ 2Eh	Backspace 2Ah	Einf 49h	Pos 4Ah	Up 4Bh	
Tab 2Bh	Q 14h	W 1Ah	E 08h	R 15h	T 17h	Z 1Ch	U 18h	I 0Ch	O 12h	P 13h	Ü 2Fh	+ 30h	Enter 28h	Entf 4Ch	End 4Dh	Dwn 4Eh	
Caps 39h	A 04h	S 16h	D 07h	F 09h	G 0Ah	H 0Bh	J 0Dh	K 0Eh	L 0Fh	Ö 33h	Ä 34h	# 31h 32h		7 5Fh	8 60h	9 61h	+ 57h
LShift E1h	< 64h	Y 1Dh	X 1Bh	C 06h	V 19h	B 05h	N 11h	M 10h	, 36h	. 37h	- 38h	RShift E5h	up 52h	1 59h	2 5Ah	3 5Bh	Ent 58h
LCtrl E0h	LWin E3h	LAlt E2h	Space 2Ch			RAlt E6h	RWin E7h	Menu 65h	RCtrl E4h	left 50h	dwn 51h	right 4Fh		0 62h	,	63h	