Solovia Smart Toilet User Guide

B0H9YM92NL - Get to know your controls in one glance

Remote Control Guide


Front of the Remote Control	
Stop	While the rear wash, feminine wash, drying, oscillating wash, or child mode is running, press the button once to stop the current function immediately.
Rear/Move	**(1) Sit Down:** Sit securely on the toilet seat. The wash function will not activate unless you are seated. **(2) Press Once:** Starts rear washing, and the nozzle extends to spray. **(3) Press Twice:** Switches to oscillating wash, moving the nozzle back and forth automatically. Press again to continue cycling through the wash modes. **(4) Adjust Settings:** While washing, use MASSAGE to activate massage mode, −/＋ to adjust water pressure, ◁/▷ to adjust nozzle position, and WATER TEMP to adjust water temperature. **(5) Stop:** The wash cycle ends automatically after 90 seconds. Press STOP to end it manually, or stand up to exit the mode automatically. **(6) After Washing:** The toilet automatically flushes once and starts the drying function.
Front/Move	Water sprays from the front nozzle. All other steps are the same as Rear/Move mode.
Massage	**(1) Prerequisite:** Rear Wash or Feminine Wash must already be running. Massage Mode cannot be started independently or used during drying. **(2) Press Once:** Alternates the water pressure between high and low for a pulsing massage effect. **(3) Press Again:** Turns off Massage Mode and restores steady water pressure. **Note: Massage Mode varies water pressure, not nozzle movement.**
Dryer	**(1)** Remain seated and press once to start warm air drying. **(2) Adjust Temperature:** Press DRY TEMP to cycle through 4 air temperature settings. The LED fan icon displays the selected level. **(3) Stop:** Drying stops automatically after 240 seconds. Press STOP to stop it earlier, or stand up to stop it immediately. **(4) Alternative Start:** While seated, press and hold the 3-in-1 side control button to start drying **(5) Automatic Drying：** After a rear wash or feminine wash cycle started while seated ends, the toilet automatically starts drying. No additional button press is needed.
Flush	**Press Once:** Activates one flush cycle at any time, whether seated or not. **(1) Automatic Flush After Leaving：** If you remain seated for more than 10 seconds, the toilet automatically flushes once when you stand up. **(2) After Seated Washing:** Rear Wash or Feminine Wash started while seated is followed by an automatic flush and automatic drying cycle.

	(3) Remote-Activated Washing: If washing is started using the remote, flushing occurs only after you stand up. If you remain seated, neither flushing nor drying starts automatically; press FLUSH manually as needed. **(4)** When both the seat and lid close simultaneously, the toilet automatically flushes once.



Back of the Remote Control	
Perfume	**(1) Manual Spray:** Press once to spray fragrance for 5 seconds, then it stops automatically. **(2) Enable Automatic Fragrance:** Press and hold for 3 seconds. One beep confirms activation. The toilet will automatically spray fragrance each time you sit down. **(3) Disable Automatic Fragrance:** Press and hold again for 3 seconds. Two beeps confirm deactivation. **Note: The fragrance bottle is included. Fragrance liquid is not included.**
Bubble	This product does not include this feature.
Child	**No Sitting Required：** **(1) Start:** Press once to automatically start rear washing, drying, and flushing, with no further operation required. **(2) Water Temperature:** Automatically set to the medium temperature of 98.6°F (37°C). The temperature is preset and cannot be adjusted in this mode. **(3) Stop:** Press STOP at any time to immediately stop the entire sequence.
Water Temp	**(1) Operation:** Press once to cycle through 4 temperature settings: Room Temperature → 93.2°F (34°C) → 98.6°F (37°C) → 104°F (40°C) → Room Temperature. **(2) Temperature Indicator:** Check the water droplet icon and bars on the LED display. More bars indicate a higher temperature.
Seat Temp	**(1) Operation:** Press once to cycle through 4 temperature settings: Room Temperature → 93.2°F (34°C) → 98.6°F (37°C) → 104°F (40°C) → Room Temperature. **(2) Temperature Indicator:** The LED seat icon displays the selected level. No bars indicate room temperature (no heating).
Dry Temp	**(1) Operation:** Press once to cycle through 4 temperature settings: Room Temperature → 113°F (45°C) → 122°F (50°C) → 131°F (55°C) → Room Temperature. **(2) Temperature Indicator:** The LED fan icon and bars show the selected level. No bars indicate room temperature. **(3) Settings:** Changes apply to the next drying cycle, including automatic drying after washing.

Top of the Remote Control	
	
Lift Lid · Lift/Lower Seat	Press once to open the lid. Press again to raise or lower the seat.
Lower Lid ·Lower Seat	Press once to lower the seat and lid. If both are open, the toilet flushes first, then lowers both.

Power ON / OFF	Press once to turn on; press again to turn off.
Night Light	Control of interior night light & exterior ambient light strip.
Nozzle Position ◁/▷	During rear wash, feminine wash, or child mode, press ◁ or ▷ to move the nozzle back or forth. Press the same button again to stop the nozzle at the desired position.
Adjust -/+	Adjust nozzle water pressure.

Remote Control Pairing & Troubleshooting

1.Remote Control Is Unresponsive

Replace the batteries and turn on the remote control.

2. Remote Control Lights Up, but the Toilet Does Not Respond

The remote may need to be paired with the toilet again. Follow these steps:

(1) Disconnect power to the toilet by switching off the GFCI or unplugging the power cord.

(2) Press and hold the FRONT/MOVE button on the remote while watching the display.

(3) When the display shows two dashes (--) , keep holding the button and reconnect the toilet to a 110–120V AC power supply.

(4) Pairing is complete once the toilet powers on.

(5) Release the FRONT/MOVE button and press any button, such as FLUSH, to verify the connection.

If Pairing Fails

Ensure the remote batteries are sufficiently charged. Disconnect the toilet from power for 30 seconds, then repeat all pairing steps.

Level	Water Temp	Seat Temp	Wind Temp （Dryer）
1	Room	Room	Room
2	93.2 °F (34 °C)	93.2 °F (34 °C)	113 °F (45 °C)
3	98.6 °F (37 °C)	98.6 °F (37 °C)	122 °F (50 °C)
4	104 °F (40 °C)	104 °F (40 °C)	131 °F (55 °C)

Temperature Guide (°F)

Side Control Buttons



Rear/Pulsate	**When Seated:** 1.Press once to start a 90-second rear wash. 2.Press again to switch to moving wash. 3.Press again to repeat the current mode. After washing is complete, the toilet automatically flushes once, then starts a 240-second drying cycle. The drying time is adjustable. Press STOP at any time to stop the function. **When Not Seated:** Press once to activate nozzle self-cleaning.
Front/Pulsate	**When Seated:** 1.Press once to start a 90-second feminine wash. 2.Press again to switch to moving wash.

	3.Press again to repeat the current mode. After washing is complete, the toilet automatically flushes once, then starts a 240-second drying cycle. The drying time is adjustable. Press STOP at any time to stop the function.
Stop·Flush·Dryer	**When Seated:** (1) During washing or drying: Press once to stop the current function. (2) When washing or drying is inactive: Press once to flush. (3) Press and hold to start drying. **When Not Seated:** (1) Press once to flush. (2) Press and hold to enable or disable smart functions. (3) When power is off: Press once to flush using the backup battery.

Nozzle Cleaning	
Rear Wash	(1) Sit Down Securely (2) Press REAR/MOVE on the remote control or press Rear/Pulsate on the side button once to extend the nozzle and start rear washing. (3) Adjust Settings During Operation: WATER TEMP: Adjust water temperature. −/+: Adjust water pressure. ◁/▷: Adjust nozzle position. MASSAGE: Activate massage mode. (3) Automatic Stop: The wash cycle ends automatically after 90 seconds. Press STOP to stop manually, or stand up to exit automatically. (4) After Washing: Automatic flushing and warm-air drying begin.
Female/Front Wash	The procedure is identical to rear wash, except that you press the FRONT/MOVE button or the side button labeled "Front/Pulsate" to use the front nozzle. The operation ends automatically after 90 seconds.
Massage/Pulsate Cleansing	During rear wash or front wash, press MASSAGE on the remote control to activate pulsating spray, alternating between high and low water pressure. Press MASSAGE again to turn it off and return to constant water pressure.
Moving Wash	Start rear wash or front wash. While washing is in progress, press the same button again to activate nozzle oscillation, moving the nozzle back and forth.
Children Clean	Press the "Child" button to automatically initiate a cleaning, warm-air drying, and rinsing cycle. There is no need to be seated. The water temperature is fixed at a medium setting of 37°C (98.6°F). During the child mode operation, the nozzle position can be adjusted (◁ / ▷).
Hygienic Mode	If seated for more than 1 minute, the lid will close upon departure and the hygienic function will activate for 1 minute.
Self-clean Nozzle	When not seated, press the side button to extend the nozzle for a 90-second cleaning cycle without water. The nozzle stays still for 70 seconds, then moves back and forth for 20 seconds before retracting. Wipe with a soft cloth or toothbrush during the cycle. Press “STOP” to stop. Do not pull, push, or bend the nozzle.
Stainless Steel Nozzle	Hygienic & Easy to Clean
Adjustable Water Temperature	Press the "Water Temp" button to cycle through 4 settings:

	Level 1 = Room temperature, Level 2 = 93.2°F, Level 3 = 98.6°F, Level 4 = 104°F The current setting can be identified by the number of bars displayed alongside the water drop icon on the LED screen.
Adjustable Water Pressure	In the rear wash/front wash mode, the water pressure can be adjusted using the -/+ buttons; the water flow rate ranges from 0.40–0.65 L/min (0.11–0.17 gal/min).
Adjustable Nozzle Position	During rear wash, front Wash, or child mode, press◁or ▷to move the nozzle backward or forward. Press the same button again to stop the nozzle movement.
LED Display	
Display	Shows temperature (°C), water temperature, seat temperature, air temperature, and ECO mode.