Idle XO Shutdown/VDD Minimization Overview


QIIALCOMM[®]

Qualcomm Technologies, Inc.

80-P0897-1 A

Confidential and Proprietary – Qualcomm Technologies, Inc.

Restricted Distribution: Not to be distributed to anyone who is not an employee of either Qualcomm Technologies, Inc. or its affiliated companies without the express approval of Qualcomm Configuration Management.



Confidential and Proprietary – Qualcomm Technologies, Inc.



NO PUBLIC DISCLOSURE PERMITTED: Please report postings of this document on public servers or websites to: DocCtrlAgent@qualcomm.com.

Not to be used, copied, reproduced, or modified in whole or in part, nor its contents revealed in any manner to others without the express written permission of Qualcomm Technologies, Inc.

Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries. All Qualcomm Incorporated trademarks are used with permission. Other product and brand names may be trademarks or registered trademarks of their respective owners.

This technical data may be subject to U.S. and international export, re-export, or transfer ("export") laws. Diversion contrary to U.S. and international law is strictly prohibited.

Qualcomm Technologies, Inc. 5775 Morehouse Drive San Diego, CA 92121 U.S.A.

© 2015 Qualcomm Technologies, Inc. and/or its affiliated companies. All rights reserved.

Revision History

Revision	Date		Description
А	May 2015	Initial release	



Contents


- Idle and Suspend
- GIC Interrupts vs. MPM Interrupts
- Linux IRQ Number vs. Hardware IRQ Number

Confidential and Proprietary - Qualcomm Technologies, Inc.

- Idle XO Shutdown/VDD Minimization Debug
- Acronyms
- Questions?



Idle and Suspend




Idle and Suspend Differences

Idle

- No user activity
- Display is on and static
- Device is capable of entering XO shutdown/VDD minimization if the device is equipped with a smart panel
- Suspend
 - Triggered by specific operations, e.g., pressing the power key and the screen off timer expired
 - Display is off
 - Device is capable of entering XO shutdown/VDD minimization

Idle and Suspend Process Flow



Confidential and Proprietary - Qualcomm Technologies, Inc.

Idle XO Shutdown Path – Check GIC/GPIO IRQs Prevent Sleep

- No task runs
- CPU idle duration longer than sleep+resume latency



lpm_cpuidle_enter()



msm_mpm_interrupts_detectable()

- Device cannot enter XO shutdown/VDD minimization if:
 - Any GIC/GPIO IRQ is enabled
 - The enabled IRQ is not in the bypass list (defined in DTSI)



Notify RPM

Handover MPM Configuration to RPM

lpm_cpuidle_enter() or lpm_suspend_enter



Write the intended MPM interrupt to the virtual MPM register in SMED



Notify RPM




RPM aggregates all subsystems' Virtual MSM Power Manager (VMPM) to write into the hardware MPM register




XO shutdown/VDD minimization

Handover MPM Configuration to RPM (cont.)






GIC Interrupts vs. MPM Interrupts



GIC Interrupts vs. MPM Interrupts


- GIC interrupts
 - Controlled by the APSS subsystem
 - Not capable of waking up the device from XO shutdown/VDD minimization



MSM8994 V2 Chip Block Diagram


GIC Interrupts vs. MPM Interrupts (cont.)

- MPM interrupts
 - Controlled by the RPM
 - Capable of waking up the device from XO shutdown/VDD minimization



Confidential and Proprietary - Qualcomm Technologies, Inc.

Linux IRQ Number vs. Hardware IRQ Number



Linux IRQ Number vs. Hardware IRQ Number Device Tree

```
#interrupt-cells = <1>;
interrupt-map-mask = <0xffffffff;
interrupt-map = <0 &intc 0 271 0
          1 &intd 0 272
                                     ■ 1 – Interrupt type
          2 &intd 0 273

    0 – SPI

          3 &into 0 274
                                      1 – PPI
          4 &intd 0 275

    2 – Interrupt number of interrupt type

          5 &into

    3 – Trigger type

                   0 277
          6 &into

    1 – Low-to-high edge triggered

          7 &into 0 278

    2 – High-to-low edge triggered

          8 &into 0 279


    4 – Active high-level sensitive

          9 &intd 0 280

    8 – Active low-level sensitive

          10 &intc
                        281
          11 &int
                                              ref: /LA.BR.1/kernel/arch/arm/mach-msm/include/mach/irgs.h
interrupt-names = "Int msi", "int a"
                                              Home | History | Annotate | Line# | Navigate | Raw | Download
                                                 only in /LA.BR.1/kernel/arch/arm/mach-msm/include/mach/
      hwirq = GIC_PPI_START/GIC_SPI_START + interrupt number
                                                          STI/SGI (software triggered/generated interrupts)
                                                   * 16-31: PPI (private peripheral interrupts)
                                                          SPI (shared peripheral interrupts)
                                                                               start index of PPI and SPI
                                                  #define GIC_PPI_START 16
                                                26 #define GIC_SPI_START 32
```

Idle XO Shutdown/VDD Minimization **Debug**




Handover MPM Configuration to RPM

Step 1 – Check current waveform Step 2 - Enable Power Management (PM) debug kernel log Step 3 – Determine which IRQs prevent system sleep Step 4 – Determine the specific hwird owner Step 5 – Determine which clocks stay on and prevent system sleep **Finish**

Step 1 – Check Current Waveform

- Rock bottom of VDD minimization should be 2 mA to 3 mA.
- Rock bottom of static display fails if it stays at around 20 mA; this indicates that something negates the XO shutdown and VDD minimization.



Step 2 – Enable PM Debug Kernel Log

echo 32 > /sys/module/msm_pm/parameters/debug_mask

```
enum {
    MSM PM DEBUG SUSPEND = BIT(0)
    MSM PM DEBUG POWER COLLAPSE = BIT(1),
    MSM PM DEBUG SUSPEND LIMITS = BIT(2),
    MSM_PM_DEBUG_CLOCK = BIT(3),
    MSM PM DEBUG RESET VECTOR = BIT(4),
    MSM PM DEBUG IDLE CLK = BIT(5),
    MSM PM DEBUG IDLE = BIT(6),
    MSM PM DEBUG IDLE LIMITS = BIT(7),
    MSM PM DEBUG HOTPLUG = BIT(8),
    };
```

echo 8 > /sys/module/mpm_of/parameters/debug_mask

```
enum
    MSM MPM DEBUG NON DETECTABLE IRO = BIT(0),
    MSM MPM DEBUG PENDING IRO = BIT(1),
    MSM MPM DEBUG WRITE = BIT(2),
    MSM MPM DEBUG NON DETECTABLE IRQ IDLE = BIT(3),
    };
```

Step 3 – Determine Which IRQs Prevent System Sleep

Log example

```
<6>[ 1695.567203] [0: kworker/u:0: 6] msm mpm interrupts detectable(): gic
preventing system sleep modes during idle
<6>[ 1695.567252] [0: kworker/u:0: 6] hwirg: 65 -> kgsl-3d0
<6>[ 1695.567277] [0: kworker/u:0: 6] hwirg: 157 -> mmc1
<6>[ 1695.567303] [0: kworker/u:0: 6] hwirg: 159 -> mmc2
<6>[ 1695.567328] [0: kworker/u:0: 6] hwirg: 253 -> msm_sdcc.2
<6>[ 1695.567354] [0: kworker/u:0: 6] hwirg: 256 -> msm sdcc.3
```

- Analysis Search hwird to determine which IRQs prevent system sleep
- Solution 1 Drivers should disable the IRQ if it is not required
- Solution 2 Add the IRQ to the bypass list in DTSI

```
gcom,gic-parent = <&intc>;
gcom,gic-map = <2 216>, /* tsens upper lower int */
               <47 165>, /* usb30_hs_phy_irq */
               <50 172>, /* usb1 hs async wakeup irg */
               <53 104>, /* mdss_irq */
               <62 222>, /* ee0 krait hlos spmi periph irg */
               <0xff 57>, /* mss_to_apps_irq(0) */
               <0xff 58>, /* mss to apps irg(1) */
               <0xff 59>, /* mss_to_apps_irq(2) */
```

Step 4 – Determine the Specific hwird Owner

Cat/proc/interrupt

```
270:
                                                           GIC
273:
                                                                msm_iommu_nonsecure_irq
                                                           GIC
274:
                                                           GIC
                                                                msm_iommu_nonsecure_irq
                                                                mobicore
280:
                                       0
                                                           GIC
288:
                                       0
                                                           qpnp-int qpnp_kpdpwr_status
```

Determine which function enables the specific IRQ that causes sleep fail

```
--- a/arch/arm/mach-msm/mpm-of.c
+++ b/arch/arm/mach-msm/mpm-of.c
@@ -252,6 +252,11 @@ static int msm_mpm_enable_irq_exclusive(
irq_apps = wakeset ? unlisted_irqs[i].wakeup_irqs :
unlisted irgs[i].enabled irgs;
+ \text{ if } (d->h\text{wirg} == 280 \&\& enable)  {
+ pr err ("!!!hwirq 280 registered, wakeset %d\n", wakeset);
+ dump stack();
if (enable)
   __set_bit(d->hwirq, irq_apps);
  else
```

Step 4 – Determine the Specific hwird Owner (cont.)

Confidential and Proprietary – Qualcomm Technologies, Inc.

Dump result sample

```
[<c017ccd8>] msm_mpm_enable_irq_exclusive+0x164
[<c017cdcc>] __msm_mpm_enable_irq+0x38
[<c0115600>] gic_unmask_irq+0x38
[<c01f6fb8>] irg enable+0x28
[<c01f59f4>] __enable_irq+0x9c
[<c01f5a78>] enable_irq+0x60
[<c05a5258>] qup_i2c_xfer+0x28c
[<c05a0ea0>] i2c transfer+0xb8
[<c05948c4>] gtp_i2c_read+0x60
```

Step 5 – Determine Which Clocks Stay On and Prevent System Sleep

Log example

```
<6>[ 1353.995631] c0 0 Enabled clock count: 32
<6>[ 1353.996721] c0 0 Enabled clocks:
<6>[ 1353.996731] c0 0 cxo_clk_src:1:1 [19200000]
<6>[ 1353.996743] c0 0 pnoc_clk:1:1 [9600000]
<6>[ 1353.996756] c0 0 pnoc_a_clk:1:1 [19200000]
<6>[ 1353.996767] c0 0 bimc_clk:1:1 [9600000]
<6>[ 1353.996778] c0 0 bimc_a_clk:1:1 [459931648]
<6>[ 1353.996789] c0 0 snoc_clk:1:1 [9600000]
<6>[ 1353.996799] c0 0 snoc_a_clk:1:1 [100000000]
<6>[ 1353.996812] c0 0 bimc_msmbus clk:1:1 [9600000] -> bimc_clk:1:1 [9600000]
```

- Search "Enabled clocks" to determine which clocks prevent XO shutdown and VDD minimization
- The serial console is enabled by default in the engineering build; if the engineering build causes an idle XO shutdown fail, disable the serial console to fix it

```
kernel/arch/arm/configs/msm8994_defconfig
#CONFIG_SERIAL_MSM_HSL=y
#CONFIG_SERIAL_MSM_HSL_CONSOLE=y
```

Acronyms

Acronyms			
Term	Definition		
hwirq	Hardware Interrupt Request		
PM	Power Management		
VMPM	Virtual MSM Power Manager		



Questions?

https://support.cdmatech.com

