Number: SOP-RHR-OPS	Use Category: CONTINUOUS	Major Rev: 001
Title: Residual Heat Removal Operations (NOT OFFICIAL)		Minor Rev: 001 Page: 1 of 27

1.0 RHR SYSTEM OPERATIONS

CAUTION

The following steps describe lining up RHR for LPCI. If the pump suction for the selected pump is <u>NOT</u> open, the pump will not initiate automatically on receipt of an injection signal.

CAUTION

RHR-V-3A/B NOT full open makes LPCI inoperable.

CAUTION

If power for the selected RHR system is <u>NOT</u> available, some valves will lose indications. If indications of either the injection valve or suction valve are lost, then the RHR train is considered inoperable.

NOTE: All equipment for this document is located on P601 unless stated otherwise.

1.1 RHR SYSTEM 'A'

- CLOSE RHR-V-53A "SHUTDOWN COOLING RETURN"
- 2. CLOSE RHR-V-6A "SHUTDOWN COOLING SUCTION"
- 3. IF RHR-P-2A is RUNNING,
 - THEN stop RHR-P-2A.
- 4. OPEN RHR-V-4A "PUMP SUCTION FROM SUPP POOL"
- OPEN RHR-V-48A "HX SHELL SIDE BYPASS"

1.2 RHR SYSTEM 'B'

- CLOSE RHR-V-53B "SHUTDOWN COOLING RETURN"
- 2. CLOSE RHR-V-6B "SHUTDOWN COOLING SUCTION"
- 3. IF RHR-P-2B is RUNNING,
 - THEN stop RHR-P-2B.
- 4. OPEN RHR-V-4B "PUMP SUCTION FROM SUPP POOL"
- 5. OPEN RHR-V-48B "HX SHELL SIDE BYPASS"

1.2 RHR SYSTEM 'C'

1. IF RHR-P-2C is RUNNING,

Number: SOP-RHR-OPS	Use Category: CONTINUOUS	Major Rev: 001
Title: Residual Heat Removal Operations (NOT OFFICIAL)		Minor Rev: 001 Page: 2 of 27

THEN stop RHR-P-2C.

2. OPEN RHR-V-4C "PUMP SUCTION FROM SUPP POOL"