Comelit Dooropener

Android app user guide - version 0.1.118

Comelit Dooropener is an Android app for controlling a Simplebus2 Bridge through Home Assistant. It provides entrance door opening, optional parking garage control, doorbell notifications, automatic opening modes, bridge configuration, bus monitor information and update checks through GitHub.

This guide is generic. It does not contain private Home Assistant URLs, tokens, WiFi passwords, bridge proxy tokens or personal network settings.

Requirements

- Android phone or tablet with notification permission enabled.
- Home Assistant with the Simplebus2 Bridge exposed through MQTT entities.
- A long-lived Home Assistant access token.
- Optional: Home Assistant Cloud/Nabu Casa or another secure HTTPS external URL.
- Optional: a secure bridge proxy if the Simplebus2 Bridge web/API must be reached from outside the local network.
- Optional: a Home Assistant switch entity for extra controls, for example a parking garage door.

Installation

- Download the APK from the GitHub release page.
- Install the APK on the Android device.
- Allow installation from the selected source if Android asks for permission.
- Allow notifications when Android asks. Without this, doorbell alerts may not appear correctly.
- Open the app, go to Settings, and configure Home Assistant before using the controls.

Main Screen

Area	Description
Header	Shows the app name, connection state and compact status line for entrance ring, bridge state and auto-o
Entry door open	Large primary button for opening the main entrance door.
Extra control	Optional section for additional Home Assistant controls, such as a parking garage door.
Auto-open	Lets the administrator choose one-time, timed, permanent or disabled automatic opening.
Doorbell notifications	Starts or stops the persistent monitor service for doorbell alerts.
Doorbell history	Opens the complete local history of rings and actions.
Footer	Shows author and app version.

User Mode and Admin Mode

The app can run in a simple user mode or in administrator mode. User mode is intended for normal residents and shows only the safe daily controls, such as opening the entrance door and optional parking garage. Administrator

mode gives access to settings, monitoring, bridge configuration, tokens and advanced options.

Mode	Visible controls
User mode	Entrance door open and optional parking garage. Advanced controls and settings are hidden.
Admin mode	All controls, settings, monitoring, bridge configuration and update options.
PIN protection	Settings and administrator-only screens can be protected with a PIN of up to 8 digits.

Home Assistant Settings

Setting	Purpose
Internal URL	Local Home Assistant address, for example http://homeassistant.local:8123.
External URL	Home Assistant Cloud/Nabu Casa URL or another secure HTTPS address for use outside the home netw
Connection mode	Automatic, Internal or External. Automatic switches between configured addresses.
Long-lived access token	Created in Home Assistant under the user profile. Keep it private.
App name	Name shown in the app header and notifications.
Language	Dutch, English or German.
Admin/User mode	Chooses whether the app exposes administrator controls or only the simplified user interface.

Doorbell Notifications

Setting	Purpose
Doorbell ringtone	Selects an Android ringtone or audio file for the doorbell alert.
Ringtone repeat count	Number of times the ringtone is played for one doorbell event.
Notification duration	How long the doorbell notification stays available for quick action.
Open from notification	The notification can open the app or send an open-door command, depending on the action chosen.
Persistent monitor	The app uses a foreground monitor service so doorbell alerts can work while the app is not in the foregro

Doorbell History

The main screen shows a compact history preview. The full history screen shows recent doorbell events and actions, including rings, manual open commands, automatic open attempts, failed automatic opens and parking garage events. The history is stored locally on the phone.

Automatic Opening Modes

Automatic opening is powerful and should be used deliberately. One-time mode is designed for situations where somebody must be able to enter after the next ring, for example emergency assistance. Timed and permanent modes should only be used when the access risk is understood.

Mode	Behavior
Off	No automatic door opening.
One-time	The next valid ring opens the door once, then auto-open turns itself off.
Timed	Rings open the door until the selected time expires. The app shows the active timed state.
Permanent	Rings keep opening the door until manually disabled. This is the highest-risk mode.
Repeat count	Auto-open can repeat the open command up to a limited number of attempts for reliability.

Parking Garage Control

An optional parking garage button can be shown on the main screen. It calls a configured Home Assistant entity, for example a Tasmota switch entity. This feature is optional and can be hidden for users who do not have a garage.

Setting	Purpose
Show parking garage	Shows or hides the parking garage button.
Garage entity ID	Home Assistant entity to trigger, for example switch.tasmota_2.
Action behavior	The app sends the service call and records the action in local history.
Notification sound	The app can use a notification sound for garage actions separately from the main doorbell ringtone.

Bridge Web/API Settings

Bridge Web/API settings are for configuring the ESP32 Simplebus2 Bridge itself. These settings are separate from Home Assistant. If the phone can reach the bridge directly on the local network, the proxy fields can stay empty.

Setting	Purpose
Bridge web/API URL	Local bridge address, for example http://simplebus2-bridge.local or the bridge IP address.
Bridge proxy URL	Optional secure remote proxy endpoint for reaching the bridge from outside the local network.
Bridge proxy token	Optional token used by your own bridge proxy.
WiFi SSID/password	Bridge WiFi configuration fields.
MQTT host/user/password/prefix	MQTT connection settings used by the bridge.
Intercom address	Simplebus address used by the bridge.
Gain and threshold	Receiver tuning values for the Simplebus signal.
Ring-to-open minutes	Bridge firmware setting for its own ring-to-open behavior.

Bridge Actions

Action	Description
Save WiFi	Sends WiFi settings to the bridge.

Action	Description
Save MQTT	Sends MQTT settings to the bridge.
Save bus settings	Saves address, gain, threshold and ring-to-open values.
Start config mode	Starts the bridge configuration portal if supported by the firmware.
Learn address	Attempts to start or assist address learning if supported by the firmware.
Factory reset	Resets bridge settings. Use only when you really intend to reconfigure the bridge.

Bus Monitor

The bus monitor reads the debug/status information exposed by the Simplebus2 Bridge API. It is not a complete packet analyzer, but it helps show whether the bridge sees bus activity and whether decoding errors occur.

Field	Meaning
Last bus activity	Timestamp of the most recent bus code/address combination remembered by the app.
Last bus code/address	Latest decoded code and address reported or remembered.
Previous bus activities	The app remembers the previous two bus activities for comparison.
Decode OK	Counter for successfully decoded telegrams reported by the bridge.
Checksum errors	Counter for checksum failures reported by the bridge.
Address mismatch	Counter for telegrams not matching the configured address, if reported by the bridge.
ISR count	Low-level interrupt/debug count, useful for seeing if the receiver still sees signal edges.

Security Notes

- Keep the Home Assistant long-lived token private.
- Use HTTPS for external Home Assistant access, preferably Home Assistant Cloud/Nabu Casa.
- Do not publish personal URLs, tokens, WiFi passwords or bridge proxy tokens.
- Use user mode for residents who only need the entrance and garage controls.
- Protect administrator screens with a PIN.
- Use permanent auto-open only when you fully understand the access risk.

Updates Through GitHub

The app checks a public version metadata file on GitHub. When a newer version is available, it can show an update dialog that points to the release page or APK download.

File	Purpose
version.json	Public metadata file containing versionCode, versionName, APK URL, guide URL and release notes.
Signed APK	The installable Android package uploaded to the GitHub Release.
User guide PDF	This document, uploaded to the same GitHub Release.
README.md	Repository overview and current release links.

Release Files

- Comelit-dooropener-0.1.118-release.apk
- Comelit-dooropener-0.1.118-user-guide.pdf
- version.json in the repository root

Troubleshooting

- No ringtone: check Android notification permission, notification volume, selected ringtone and app notification settings.
- Notification disappears too quickly: increase the notification duration setting.
- No Home Assistant connection: check internal/external URL, token, WiFi/mobile data and Home Assistant availability.
- External Home Assistant works but bridge config does not: configure a secure bridge proxy or use the local network.
- Auto-open failed: check the history entry, Home Assistant connection and whether the selected mode was active.
- Garage button does nothing: verify the configured Home Assistant entity ID and whether the entity can be controlled from Home Assistant.
- Bridge config unavailable: verify bridge web/API URL, proxy URL, proxy token and bridge firmware support.
- Bus monitor shows no new data: verify the bridge is connected, powered correctly and exposing status through the API.