

KLARSTEIN

Gas Hob — Safety Leaflet

Read the safety instructions for your language before using this appliance. Keep this leaflet. It does not replace the instruction manual supplied with the appliance, which contains the installation, ventilation and burner heat input information your installer needs.

Find your language / Ihre Sprache / Votre langue

BG 8	CS 9	DA 10	DE 11	EL 12	EN 13
ES 14	ET 15	FI 16	FR 17	HR 18	HU 19
IT 20	LT 21	LV 22	NL 23	PL 24	PT 25
RO 26	SK 27	SL 28	SV 29		

What the signal words mean

DANGER

Will cause death or serious injury if ignored.

WARNING

Could cause death or serious injury.

CAUTION

Could cause minor injury or damage the appliance.

NOTICE

Information you need for correct use.

NOTICE — gas type This leaflet is common to all Klarstein gas hobs. The gas type, supply pressure and appliance category for your model are stated on the rating plate and on the packaging. Check them against your gas supply before installation.

Layout example only — 7 pt Inter on 8.4 pt leading, two columns, ~50 characters per line. A5 (148 × 210 mm), saddle-stitched, 30 pages = 8 A4 sheets.

Gas Hob Safety Leaflet

Read these safety instructions carefully before using this appliance and keep them for future reference. Scan the QR code on the back cover for the complete user manual, additional product information and the applicable Declaration of Conformity. **This appliance must be installed by a qualified gas installer.**

DANGER



Fire, explosion and asphyxiation

Escaping gas kills Gas that flows without igniting collects in the room and can explode. Turn every control knob fully off when the appliance is not in use, and close the gas supply valve if it will be unused for a long period.

If you smell gas No flame, no smoking, no electrical switch, doorbell or phone — any spark can ignite the gas. Open doors and windows, close the appliance and meter valves, leave the building, warn the neighbours, and call the gas emergency service and a qualified installer from outside. Do not go back in until told it is safe.

Failed ignition or a flame going out Gas keeps flowing. Turn the knob fully off, open a window or door, and wait at least one minute before trying again. Do not operate the hob in a draught from a window, door or fan.

Gas connection Never connect the appliance yourself. Connection, leak testing, conversion and any change of injectors must be done by a person qualified under the gas installation rules of your country. Never test for leaks with a flame. Check that the gas family and pressure on the rating plate match your supply.

Cylinders Never store gas cylinders, full or empty, below ground level. Use them upright and away from ovens, heaters and other heat sources. Keep only the cylinder in use in the room.

Unattended cooking and burning fat Never leave the appliance unattended while a burner is lit. Never carry or move a pan of burning or hot fat, and never use water on it — turn the burner off and cover the pan if you can do so safely.

Flammable items Keep cloths, tea towels, oven gloves, paper, packaging, curtains and aerosols well clear of the burners. Do not store flammable liquids, cleaning products, plastics or aerosols in the cabinet above or below.

WARNING



Poisoning, burns and electric shock

Carbon monoxide Incomplete combustion produces carbon monoxide — invisible, odourless and lethal in small amounts. Keep the flame ports clean; flames must burn blue and steady. If flames are yellow, if pans soot, or if anyone suffers unexplained headaches, nausea or drowsiness, stop using the hob, ventilate and call a qualified installer.

Room ventilation Using a gas cooking appliance produces heat, moisture and products of combustion in the room in which it is installed. Ensure that the

kitchen is well ventilated, especially when the appliance is in use. Prolonged intensive use may require additional ventilation, for example increasing mechanical ventilation where present. Consult a professional before installing additional ventilation.

Children and supervision This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision. Never leave a child alone in the room while the appliance is in use or connected to the gas supply.

Hot surfaces and pans Burners, caps, pan supports and the surrounding surface stay hot long after use. Use dry, heat-resistant pan holders. Use the rear burners where you can and turn pan handles inwards. Use flat-based pans placed centrally and sized to the burner; never use plastic or foil dishes and never heat an empty pan.

Broken glass surface Shut off all burners and any electrical heating element immediately, isolate the appliance from the power supply, do not touch the surface, do not use the appliance.

Flame supervision device Not fitted to every model. It does not prevent a fire and does not detect gas escaping from the connection. Do not rely on it — check your manual.

Installation Only by a person qualified under the gas installation rules in force in your country, in a well ventilated space, and in a worktop and cabinet meeting the clearances in the installation instructions. Never in a bathroom or shower room. Do not install or connect it yourself.

Intended use For domestic cooking only. Never use it to heat a room, and never to heat the space in a caravan, motorhome, leisure home or boat.

Electrical If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. Do not open or repair the appliance yourself and do not modify it or fit unapproved parts.

CAUTION



Fitting and removal Heavy and awkward — use two people. Wear gloves: the worktop cut-out, pan supports and burner parts have sharp edges. Fit only a hob guard or pan-support cover supplied with the appliance or declared suitable by its manufacturer.

Cleaning Clean only once cold, with warm water and a soft cloth — no abrasive pads, scouring powders, oven sprays or caustic products. Keep the flame ports and injectors clear. Never pour cold liquid on a hot pot.

Disposal · Manufacturer · Conformity

EN If there is a legal provision for the disposal of electrical and electronic devices in your country, this symbol on the product or on the packaging indicates that this product must not be disposed of with household waste. It must instead be taken to a collection point for the recycling of electrical and electronic equipment. The symbol shown indicates that this appliance must be disposed of separately from unsorted municipal waste.

DE Besteht in Ihrem Land eine gesetzliche Regelung zur Entsorgung von Elektro- und Elektronikgeräten, weist dieses Symbol auf dem Produkt oder auf der Verpackung darauf hin, dass dieses Produkt nicht im Hausmüll entsorgt werden darf.

FR Si votre pays dispose d'une réglementation relative à l'élimination des appareils électriques et électroniques, ce symbole apposé sur le produit ou sur son emballage indique que ce produit ne doit pas être jeté avec les ordures ménagères.

[19 further language versions of this block follow — printed once here, not once per language page. In the current 65-page leaflet this block is repeated 22 times.]

Manufacturer and importer

Chal-Tec GmbH, Mühlenstrasse 25, 10243 Berlin, Germany
Contact: info@klarstein.com

Declaration of Conformity

Chal-Tec GmbH hereby declares that this equipment complies with the applicable statutory requirements. The full text of the declaration of conformity and the statement of compliance are available at:

<http://use.berlin>

Layout example — not for print. Body text 7 pt Inter / 8.4 pt leading (1.2×), two columns at ~50 characters per line.

Compare: the current leaflet is 4.75 pt / 5.2 pt leading (1.09×) at ~137 characters per line.