HastaDAQ

Net labels connect everything: same name = same net. +3V3 / GND are plain labels, not power symbols.

Pimoroni Pico Plus 2 (+ RM2 on SP/CE): same 40-pin header as Pico 2 W. I2C0 = GP4/GP5 (header pins 6/7), to the IMU Qwiic-breakout header and to the 4-wire loom for the strain-gauge board. Crossed-out pins are intentionally unused.

J1
IMU via Qwiic breakout (The Pi Hut 106676)

GND	1	GND
+3V3	2	3V3
SDA	3	SDA
SCL	4	SCL

J2
GAUGE BOARD LOOM (J_I2C): GND, +5V, SDA, SCL

GND	1	GND
+5V	2	5V
SDA	3	SDA
SCL	4	SCL

Strain-gauge board: 4-wire I2C loom. Pin 2 is +5V, NOT 3V3 -- use a keyed plug, never a Qwiic cable. Pull-ups live on the ADS122C04 breakouts on that board.

U1
Pimoroni Pico Plus 2 (header pins)

SBUS_IN_GPIO	1	GP0_UART0-TX	VBUS	40	
	2	GP1_UART0-RX	VSYS	39	+5V_VSYS
GND	3	GND	GND	38	GND
	4	GP2	3V3_EN	37	
	5	GP3	3V3(OUT)	36	+3V3
SDA	6	GP4_I2C0-SDA	ADC_VREF	35	
SCL	7	GP5_I2C0-SCL	GP28	34	
GND	8	GND	AGND	33	GND
	9	GP6	GP27	32	
ENC4_CS	10	GP7	GP26	31	
ENC3_CS	11	GP8	RUN	30	
ENC2_CS	12	GP9	GP22	29	
GND	13	GND	GND	28	GND
SPI_SCK	14	GP10_SPI1-SCK	GP21_UART1-RX	27	SBUS
SPI_MOSI	15	GP11_SPI1-TX	GP20_UART1-TX	26	SBUS
SPI_MISO	16	GP12_SPI1-RX	GP19	25	
ENC1_CS	17	GP13_SPI1-CSn	GP18	24	
GND	18	GND	GND	23	GND
TRIG_IN_GPIO	19	GP14	GP17	22	
TRIG_OUT_GPIO	20	GP15	GP16	21	SOFTSTOP_IN

J3
ENC1 SPI port: MT6835 (pitch) / Orbis

GND	1	GND
ENC1_CS	2	CS
SPI_SCK	3	SCK
SPI_MOSI	4	MOSI
SPI_MISO	5	MISO
+3V3	6	3V3
+5V	7	5V
GND	8	GND

J4
ENC2 SPI port: MT6835 / Orbis

GND	1	GND
ENC2_CS	2	CS
SPI_SCK	3	SCK
SPI_MOSI	4	MOSI
SPI_MISO	5	MISO
+3V3	6	3V3
+5V	7	5V
GND	8	GND

J5
ENC3 SPI port: MT6835 / Orbis

GND	1	GND
ENC3_CS	2	CS
SPI_SCK	3	SCK
SPI_MOSI	4	MOSI
SPI_MISO	5	MISO
+3V3	6	3V3
+5V	7	5V
GND	8	GND

J6
ENC4 SPI port: generic SPI device

GND	1	GND
ENC4_CS	2	CS
SPI_SCK	3	SCK
SPI_MOSI	4	MOSI
SPI_MISO	5	MISO
+3V3	6	3V3
+5V	7	5V
GND	8	GND

CS pull-ups (10k)

+3V3	R1	10k → ENC1_CS
+3V3	R2	10k → ENC2_CS
+3V3	R3	10k → ENC3_CS
+3V3	R4	10k → ENC4_CS

U2
Pololu D42V55F8 8.4V 5A buck (servo rail)

VSERVO	1	VOUT	VOUT	2	VSERVO
GND	3	GND	GND	4	GND
GND	5	GND	GND	6	GND
+12V	7	VIN	VIN	8	+12V
	9	VRP	VRP	10	
	11	PG	EN	12	

U3
SparkFun BabyBuck 5V (AP63357) (Pico VSYS, Orbis)

+12V	3	VIN	VOUT_5V	1	+5V
GND	2	GND			
	4	EN			

D1
Schottky (e.g. 1N5822, 3A)
+5V → +5V_VSYS

+12V_IN → F1 Fuse T3.15A 5x20mm time-delay → +12V
+12V → C1 100uF input bulk (>=25V) → GND
VSERVO → C2 470–1000uF servo bulk (>=16V) → GND
+5V → C3 100uF 5V bulk (>=10V) → GND

J7
SBUS servo header 3x6 (6 plugs: GND, V, SIG)

GND	1	S1_GND
VSERVO	2	S1_V
SBUS	3	S1_SIG
GND	4	S2_GND
VSERVO	5	S2_V
SBUS	6	S2_SIG
GND	7	S3_GND
VSERVO	8	S3_V
SBUS	9	S3_SIG
GND	10	S4_GND
VSERVO	11	S4_V
SBUS	12	S4_SIG
GND	13	S5_GND
VSERVO	14	S5_V
SBUS	15	S5_SIG
GND	16	S6_GND
VSERVO	17	S6_V
SBUS	18	S6_SIG

TEST POINTS (2.0 mm through-hole pads): two GND pads for a scope clip (near the supply and near the Pico). Rails and signals are probed at component leads and header pins (fuse clips, C5/C6/C7, D1, Pico pins 36/39).

GND → TP1 TP
GND → TP2 TP

PWR_FLAG: marks nets supplied through the supply connector (+12V_IN, GND), the fuse (+12V) and the Schottky (+5V_VSYS)

#FLG1 PWR_FLAG	+12V_IN	
#FLG2 PWR_FLAG	+12V	
#FLG3 PWR_FLAG	GND	
#FLG4 PWR_FLAG	+5V_VSYS	

J10
SBUS IN (RC receiver): GND, V, SIG

GND	1	GND
VSERVO	2	V
SBUS_IN	3	SIG

SBUS_IN → R13 1k series → SBUS_IN_GPIO
SBUS_IN_GPIO → R14 10k pull-down → GND

SBUS IN: RC-receiver pass-through (plug order GND, V, SIG). V = VSERVO 8.4 V -- check the receiver's max supply. SIG -> 1k -> GP1 (UART0 RX), 10k to GND.

J8
Main supply cable (2x4): VSUPPLY, VGND, TRIG, SOFTSTOP

+12V_IN	1	VSUPPLY
GND	2	VGND
TRIG_IN	3	TRIG_IN
SOFTSTOP_CABLE	4	SOFTSTOP+
GND	5	SOFTSTOP-
TRIG_OUT	6	TRIG_OUT
GND	7	VGND
+12V_IN	8	VSUPPLY

SOFTSTOP_CABLE → R5 1k (soft-stop series) → SOFTSTOP_IN
+3V3 → R6 10k (soft-stop pull-up) → SOFTSTOP_IN

D2
5.1V zener (BZX55C5V1) soft-stop clamp
GND → SOFTSTOP_IN

TRIGGER IN: any 3.3 V .. 24 V level, opto input

TRIG_IN → R7 10k pull-down → GND
TRIG_IN → R8 1k 1W → TRIG_IN_LED
U4 PC817 opto (TRIG_IN): TRIG_IN_LED → A; K → GND; C → TRIG_IN_GPIO; E → GND
+3V3 → R9 10k pull-up → TRIG_IN_GPIO
D3 1N4148 (LED reverse protect): GND → A; K → TRIG_IN_LED

TRIGGER OUT: open-collector NPN, pull-up rail chosen by jumper

TRIG_OUT_GPIO → R10 2.2k (base) → TRIG_OUT_BASE
TRIG_OUT_BASE → R11 10k (base-emitter) → GND
Q1 2N3904 NPN (TO-92, pin 1 E, 2 B, 3 C): B ← TRIG_OUT_BASE; C → TRIG_OUT; E → GND
TRIG_PU → R12 1.5k pull-up → TRIG_OUT
J9 TRIG_OUT pull-up sel.: 3V3, TRIG_PU, +5V, TRIG_PU, +12V, TRIG_PU → 3V3 PU, 5V PU, 12V PU

Jumper a row (3V3 / 5V / 12V) to pull TRIG_OUT up to that rail; remove it if the receiver has its own pull-up.
Pull-up current: 3.3 V ~2 mA, 5 V ~3 mA, 12 V ~7 mA (enough for a 6.5 mA opto input such as MPS4200).
24 V receivers: no jumper, add an external 24 V pull-up in the harness. 3V3 for eSync 2 high-Z ports (3.3 V max).

NOTES
1. ONE common GND (Pico, sensors, servo PSU). SBUS needs a shared ground reference.
   RM2 WiFi breakout (off-board, cabled to the Pico Plus 2 SP/CE connector): uses GP32-GP36 only, no overlap with I2C (GP4/5) or any other signal.
2. Strain gauges: SEPARATE board (kicad/gaugeboard), reached by a 4-wire I2C loom (GND, +5V, SDA, SCL; 0.1in headers, keyed plugs).
   That board makes its own clean 3.3 V from +5V and holds both ADS122C04s, the gauge headers and the filtering.
   ADS #2 needs its address jumper bridged (resulting address unconfirmed; firmware scans at boot). I2C pull-ups come from the ADS122C04 breakouts on the gauge board and from the IMU breakout.
3. SBUS: GP20 (TX) and GP21 (RX) on one net (UART inverted in firmware). One 3x6 servo header (6 plugs of GND, V, SIG; footprint HastaDAQ:PinHeader_3x06): V = VSERVO (8.4 V), SIG = SBUS (all six in parallel), GND.
4. POWER: 12 V in -> fuse -> +12V rail -> (a) Pololu D42V55F8 = VSERVO 8.4 V (servos), (b) SparkFun BabyBuck 5V = +5V (Orbis, gauge-board loom, Schottky -> Pico VSYS). VSYS max is 5.5 V. USB (VBUS) is left for programming; with USB only, +5V is not live.
   BabyBuck EN is left open (its own divider enables it). 5V bulk: module has 2x22uF; 100uF added near the Pico/ports.
5. Triggers: TRIG_IN accepts 3.3–24 V (opto). TRIG_OUT is open collector with a jumper-selected pull-up. Pin order: see each symbol.
   Main supply cable (2x4, pins 1–8 row-major): 1.8 VSUPPLY (12 V) | 2.7 VGND | 3 TRIG_IN | 6 TRIG_OUT | 4 SOFTSTOP+ | 5 SOFTSTOP-.
   SOFTSTOP+ -> 1k -> GP16 (10k pull-up to 3V3, 5.1 V zener to GND). SOFTSTOP- = GND: loop closed = run, broken = stop.
   Keyed shrouded IDC box headers (cannot be mated rotated) are used for this connector and ENC1–4. Measured system current was <= 1 A at 8.4 V, well inside ~3 A per 0.1in pin.
6. Encoders: 4 x 2x4 headers (pins 1–8: GND, CS, SCK, MOSI, MISO, 3V3, 5V, GND) on one SPI1 bus; CS = GP13/GP9/GP8/GP7.
   MT6835 uses 3V3 (3.3 V logic); RLS Orbis uses 5V with 3.3 V logic. Check MISO tri-states when CS is high.
   The four ENC headers are a generic SPI port (SPI1: SCK GP10, MOSI GP11, MISO GP12, own CS each, 3V3 and 5V supply), so any 3.3 V SPI device can be plugged in, not just encoders. Each device needs its own CS and an MISO that tri-states when CS is high.

HastaArduino	
Sheet: /	
File: hastadaq.kicad_sch	
Title: HastaDAQ	
Size: A2	Date:
KiCad E.D.A. 10.0.6	Rev: A
	Id: 1/1