

POWER SYSTEM - OPERATOR QUICK REFERENCE

POWERING DOWN THE WHOLE SYSTEM

- 0 Have a flashlight ready.
 - 1 Move the **charge controller 0 (CC0, MidNite Classic) PV breaker** to **OFF**.
 - 2 Move the **CC0 battery breaker** to **OFF**.
 - 3 IF PV ARRAY 1 IS INSTALLED: move the **CC1 (Epever) PV breaker** to **OFF**.
 - 4 IF PV ARRAY 1 IS INSTALLED: move the **CC1 battery breaker** to **OFF**.
 - 5 Switch both **battery power pushbuttons** to **OFF**. Confirm all battery panel lights are off.
 - 6 Move the **main AC lever switch** below the AC distribution box to **OFF** (center position).
-

TURNING OFF AC ONLY

- 0 Have a flashlight ready.
 - 1 Press and release the **Inverter** button as needed until the display shows **Off**.
 - 2 Move the **main AC lever switch** below the AC distribution box to **OFF** (center position).
 - 3 If the house is being left unattended for any length of time, turn off the **water pump**.
-

POWERING UP THE WHOLE SYSTEM

- 1 Switch both **battery power pushbuttons** to **ON**. Confirm the battery panel status lights are on.
 - 2 IF PV ARRAY 1 IS INSTALLED: move the **CC1 battery breaker** to **ON**.
 - 3 IF PV ARRAY 1 IS INSTALLED: move the **CC1 PV breaker** to **ON**.
 - 4 Move the **CC0 battery breaker** to **ON**.
 - 5 Move the **CC0 PV breaker** to **ON**.
 - 6 Move the **main AC lever switch** below the AC distribution box to **ON** (top position).
 - 7 Press and release the **Inverter** button as needed until the display shows **Inverting**.
 - 8 Power on the **LCD monitor** temporarily and confirm the **supervisor program** is running and not showing error conditions.
-

RESTORING AC

- 1 Move the **main AC lever switch** below the AC distribution box to **ON** (top position).
 - 2 Press and release the **Inverter** button as needed until the display shows **Inverting**.
-