NEW hCRI Companion now supports the **TKLamp TK2303D** integrating-sphere tester through the ESP32 bridge: live lumens on your phone, recorded runtimes, and one-tap upload to Runtime on hCRI.io. Jump to Using a TKLamp tester · Bridge setup

hCRI Companion — User Manual

Covers iOS 2.0 and Android 2026.11.12.1 · Last updated November 12, 2026 · Source on GitHub ↗

01 Overview

hCRI Companion is an independent app for Android and iPhone that connects to a Hopoocolor HPCS-series spectrometer (or a Torch Bearer, via the ESP32 bridge) over Bluetooth Low Energy, reads the full spectrum off the sensor, computes the same colorimetric values hCRI.io itself computes, and uploads a reading to your hCRI.io account in one tap — no cable, no CSV export, no re-typing numbers off the meter's own tiny screen.

Every CCT, Duv, Ra, Rf, Rg, and R1–R15 value shown in the app is computed with the exact same algorithm hCRI.io's report page uses, so a reading never disagrees with itself between your phone and your account.

Supported meters

HPCS-310 **HPCS-310P** **HPCS-330** **HPCS-330P** **HPCS330Pro**

Torch Bearer (via ESP32 bridge) **TKLamp TK2303D tester (via ESP32 bridge)**

The app detects which model you're connected to from its advertised Bluetooth name and reads its data with that model's own field layout automatically — nothing to configure. The full, up-to-date list (including which models are independently verified against a real captured reading) is always on the app's own Settings → About tab.

> **The Torch Bearer, ColorMunki and TKLamp tester need the ESP32 bridge**
>
> The Torch Bearer, the X-Rite ColorMunki Photo / Design and the TKLamp TK2303D tester have no Bluetooth of their own. A LilyGO T-Display S3 (or S3 Pro) board running the open-source hCRI bridge firmware connects to them by USB and talks to the app over Bluetooth. The ESP32 bridge setup guide covers which board to buy, how to connect it and how to install the firmware. Hopoocolor HPCS meters connect directly and need no bridge. See Using a Torch Bearer.

What's new in the latest update (Android 2026.11.12.1, iOS 2.0)

- **Lights:** group several readings of the same flashlight into a *light*, kept in step with hCRI.io. `History → Lights` lists your lights with small trend charts; create one, add readings, categorize it (light brand and model, LED brand, model and CCT, optic) and tap `Sync`: the light is created on hCRI.io, every reading that was never uploaded is uploaded, and all of them are linked in your order. Lights you made on the website appear here too. See The Lights list.
- **To light:** select readings in History and tap `To light` to put them on an existing light or start a new one named after what the titles have in common.

- Opening Lights without a valid hCRI.io token asks you to sign in (or paste a token) first.

Android 2026.11.1.2, iOS 1.28

- **Categorize:** set a reading's LEDs and every hCRI.io category (light brand and model, optic, lumens, current) from one window. Use the tag icon on a History row or on a reading's page, the Categorize pill on Main, or select several readings in History and tap `Categorize` to do them all at once. Nothing is applied until you tap Categorize, and the window remembers what you applied last time. See Categorize.
- **Category lists** refresh each time the app starts (when you are online) and are kept for offline use.
- **LED suggestions are now off by default.** Turn them on in Settings → LED suggestions if you want them.

Android 2026.11.1.1, iOS 1.28

- **Live station (TKLamp):** a link that shows your run, or just the live reading, from any phone or computer, with email alerts. It sends every 5 seconds, says **Live run** during a run, and lets you type what you are testing. In the app: `Settings → Live station`, with round icon buttons to view, copy, share, open and renew the link. Also in the web logger and `tklamp_live.py` (which now updates itself). See Live station.

Android 2026.10.31.4, iOS 1.28

- **Fixed:** Show a test reading, copy link, replacing a report and attaching flicker all work again with the new report ids.
- **ColorMunki calibration limit is now in minutes** (default 30; an old 1 hour setting reads 60).
- **Names with accents** (like Kōsen) now work in usernames, folders and descriptions in the app and on the website.
- **Bridge:** shows "Bridge" until it knows which meter is plugged in; Take reading and pull-to-read are off when no meter is plugged in. The Main screen's measurement settings are collapsible, and TM-30 is hidden after a TKLamp run.

Android 2026.10.31.3, iOS 1.28

- Calibration limit in minutes, accents in names, Bridge naming and other fixes.

Android 2026.10.31.2, iOS 1.28

- **TKLamp: choose where a run starts.** `Settings → TKLamp tester` has `Start at the first reading` (on by default, no jump from 0) and `Start at the peak` (off by default). The web logger and `tklamp_live.py` have the same two options. After you stop a run you can also drag a red start line to exactly where it should begin: tap `Choose where the run`

`starts` in the app (the web logger shows the line in its Save dialog and in History → `Trim start...`); a label shows the seconds and lumens while you drag.

- **Settings is organised into collapsible sections** (tap a header to open it; pull down to close them all), the bridge firmware text is behind a ?, and on the Main screen pulling down takes a reading.
- **Torch Bearer:** pressing the bridge's Live button puts the app into Live too (needs the latest bridge firmware).

Android 2026.10.31.1, iOS 1.28

- **TKLamp: start a run at its peak** (replaced in the next update by the two start options above).

Android 2026.10.30.3, iOS 1.28

- **Update the ESP32 bridge from the app.** `Settings → Bridge → Update bridge firmware` downloads the newest firmware and sends it to the bridge over Bluetooth, with a progress bar on the bridge's screen. It works with no meter plugged in, and the bridge goes back to its old firmware by itself if the new one does not start. The bridge needs one USB flash with the latest firmware first (it changes how the bridge's memory is divided); after that, updates come from the phone. See the bridge guide.

Android 2026.10.28.3, iOS 1.28

- **Fix:** a Torch Bearer Live that times out on bridge firmware that is too old no longer makes the next scan appear to hang.
- **Live for the Torch Bearer** (needs the latest bridge firmware): continuous spectrum, stopped with `Stop`. See Using a Torch Bearer.

Android 2026.10.28.2, iOS 1.28

- **Live for the Torch Bearer** (needs the latest bridge firmware).

Android 2026.10.28.1, iOS 1.28

- **TKLamp run limits.** Start a run at a lumen level, stop below a level, stop after a set time, and stop automatically after no readings for 5 minutes (change or turn off each; they are remembered). See Using a TKLamp tester.
- **Runtime charts have a lumen grid:** faint dots every 50 lm, dotted every 100 and solid every 500, with ticks on the axis.
- **Update without leaving the app (Android).** Tap `Update` on the banner or `Update now` in Settings → Update, confirm once in Google Play's dialog, keep using the app while it downloads, then tap `Restart`.

Android 2026.10.27.1, iOS 1.28

- **TKLamp TK2303D integrating-sphere tester** through the ESP32 bridge: a live lumen reading, a chart with a fixed lumen scale and a time axis along the bottom, recorded runtimes, and upload to Runtime on hCRI.io. See Using a TKLamp tester. Needs the latest bridge firmware.
- **History → Runtime** keeps every recorded run on your phone; tap its chart to open it full size.
- **Settings → TKLamp tester** holds the counts-per-lumen scale and the chart width.

Android 2026.10.22.3

- **Share card.** A new card icon at the right end of the chart dots on Main (and a `Card` button on each History row, next to `TM-30`) makes the same one-page summary card as hCRI.io: Rf and Rg, CCT, Duv, Ra, R9, the spectrum, the color vector graphic (drawn like the TM-30 report's) and the local fidelity bars, using the numbers the app shows for the reading, in light or dark to match the app. `Save image` keeps it (Android: Pictures › hCRI; iPhone: choose Save Image in the share sheet) and `Copy image` puts it on the clipboard so you can paste it into a message. Long-press the icon for its tooltip.
- **iOS: update notice.** The iPhone app now tells you when a newer production version is available in TestFlight. A banner appears at the top, `Settings → Update` has a `Check for updates` button, and either one opens TestFlight so you can install it.
- **History is more reliable.** Readings and saved flickers are now stored one at a time instead of as a single large block, so a long History can no longer become unreadable or stop new readings from saving (the "Not saved to History" message). Your existing History is moved over automatically the first time you open the app.

Android 2026.10.18.1

- **Back up your readings to hCRI.io.** With your API token saved, the app now backs up your reading history and saved flickers to your own hCRI.io account after each change, so reinstalling the app or changing phones no longer loses them. Backed-up data is private to you: it is not a report and nobody else can see it. Readings taken before you sign in are sent once you do. Deleting a reading in the app removes it from the backup too. On a fresh install with your token already saved, the app offers to restore, and `Settings → Backup` has a `Restore readings from backup` button. There is a switch to turn backup off.
- **Flicker samples are kept.** A `New sample` on the Flicker page is now saved when it ends, so leaving the page no longer loses it. History has a new `Flicker` list (switch at the top: `Readings` / `Flicker`) where you can rename, view, upload or delete saved samples. A badge shows whether a flicker is *In report*, *In reading* or *Uploaded to hCRI.io*.

- **Add a saved flicker to a reading.** A reading in History that has no flicker gets a lightning-bolt button that lists the saved flickers not yet attached to a reading. Pick one and it is copied into the reading (and sent to the report if the reading was already uploaded).
- **Flicker page fix.** The “Ready” message no longer covers the flicker controls when there is no spectrum reading.

Android 2026.10.17.1

- **Calmer start screen.** Only one spinner now shows while connecting, in the middle of the empty chart. The status line above it is just text, and the chart no longer shows a spinner while measuring or calibrating. The `Last reading` link is now `View last reading` with an eye icon, so the title is never cut off.

Android 2026.10.16.4

- **The Switch meter list shows what is plugged into each bridge.** With the latest bridge firmware, a bridge says whether a Torch Bearer or a ColorMunki is attached, so the list reads `hCRI Bridge · Torch Bearer` or `hCRI Bridge · ColorMunki` before you connect. A bridge with nothing plugged in is left out of the list. If the only bridge in range has nothing plugged in, the app says so instead of reporting that no meter was found. Bridges on older firmware are still listed as before.

Android 2026.10.16.3

- **Two meters, you choose.** When you open the app fresh and two meters are switched on, it now offers the Switch meter list instead of quietly reconnecting to the last one. Coming back to the app after leaving it still reconnects to the meter you were using.

Android 2026.10.16.2

- **Clearer meter names.** Hopoocolor meters show just the model (for example `HPCS-330P`) on Main and in the Switch meter list, without the serial number. A bridge is always listed as `hCRI Bridge`, followed by what is plugged into it when known (`hCRI Bridge · ColorMunki`), so it reads the same whether or not it is the connected one.

Android 2026.10.16.1

- **Meter data as the makers intend.** The Torch Bearer and the ColorMunki now show the spectrum exactly as the meter reports it, with no correction fitted by us. The Torch Bearer spectrum matches what the open-source tobes-ui software shows (we checked an incandescent and an LED side by side: CCT within 1 K, same Ra and R9), and the ColorMunki uses the Argyll / X-Rite factory calibration. Expect CCT, Duv and CRI to differ a little from an HPCS, especially on the Torch Bearer at high CCT. Shared CSVs say `SpectralCorrection,none (raw)`. Needs the latest bridge firmware; older firmware still applies its old correction and says so.

- **Main button caption.** The text under the main button stays one fixed height, so the chart no longer stretches when you take a reading.

Android 2026.10.15.2

- **ColorMunki: high resolution.** With the latest bridge firmware the ColorMunki reports its spectrum in 3.3 nm bands instead of 10 nm, so narrow peaks (blue LED, phosphor) come out sharper and closer to the HPCS. It is used automatically in normal light; in very dim light the bridge falls back to the steadier 10 nm spectrum. The Logs tab notes `high resolution`, and a shared CSV's Instrument line says `3.3 nm high resolution` or `10 nm`.
- **A message instead of a blank chart.** Before the first reading the Main chart tells you what to do next: connect, calibrate, turn the dial, or take a reading, and shows progress while connecting, calibrating or measuring. The measurement tiles show a dash until there is a reading, and a `View last reading` link opens the most recent one from History.

Android 2026.10.15.1

- **Tap again to cancel a reading.** While a reading or a ColorMunki calibration runs, the main button reads `Measuring… Tap to cancel` (or `Calibrating…`); tapping it stops it and nothing is saved. With the latest bridge firmware the ColorMunki stops at its next step.
- **ColorMunki: closer to the HPCS.** The latest bridge firmware applies a correction fitted against an HPCS, which halved the CCT error on lamps it was not fitted on (about 40 K to 20 K), and shared CSVs say `SpectralCorrection,applied`. Dim light is handled better: up to 4.5 s per integration, several integrations averaged, and the sensor's high-gain mode in near darkness, so dim readings take longer (about 10–15 s) but are steadier.
- **The ColorMunki dial stays current.** When you come back to the app it reads the dial again, and a calibration started with the ColorMunki's own button shows `Calibrating…`.
- The Logs tab says `Bridge` instead of `Torch Bearer` for the bridge connection, notes when the ColorMunki calibration set up high gain, and records the ColorMunki's raw sensor data with each reading (for developing its high-resolution mode).

Android 2026.10.14.5

- **Selecting in History works like other apps.** Hold a reading's title (or any part of the row that isn't a button) to start selecting, with that reading already checked and a firm haptic. A `Select all` checkbox appears at the top, and the X cancels. Unchecking the last reading ends selecting. The old Select button is gone.
- **TM-30 and the photo tool are one screen.** Swipe left on the TM-30 report, or tap `Photo` at the top right, to see the light on a photo; swipe right below the photo, or

tap `TM-30` at the top left, to go back. The X closes it and returns you to Home or History. The bottom bar holds `Save image` and `Share PDF`.

- **A cleaner look.** History has round selection marks, plain titles and soft Copy / Report / TM-30 buttons. Icons across the app are one consistent line style (no more emoji), and every X to close looks the same.
- **Android, light mode:** switches that are off are now clearly visible in Settings.
- **Fix: uploading a second reading no longer overwrites the first.** Taking a new reading and uploading it right after uploading the previous one replaced the earlier report on hCRI.io. Each new reading now gets its own report; uploading the same reading again still updates its report.
- **Settings → Bridge.** The Torch Bearer section is now called Bridge and holds `Flip screen`, which works for both a Torch Bearer and a ColorMunki. The spectrum-correction switch is gone: newer bridge firmware applies the correction itself (older firmware still gets it from the app), so readings always match the HPCS.
- **Colour spectrum on the bridge's own screen.** The T-Display S3 draws the spectrum in wavelength colours, and with the correction built in it shows corrected CCT, Duv, Ra and R9 without the app. Needs the latest bridge firmware.
- **ColorMunki Photo / Design support** through the ESP32 bridge: ambient readings of the full spectrum, with CCT, Duv, CRI and lux. Calibrate with the dial in the calibration position, then measure in ambient. See Using a Torch Bearer.
- **Calibration limit** (Settings → ColorMunki): the app asks for a fresh calibration after a set number of minutes (default 30, 0 turns it off; an older 1 hour setting becomes 60), because the sensor's dark reference drifts.
- **Settings reorganised** into sections, with each explanation behind a `?` button next to the setting.
- **The bridge is now called hCRI Bridge.** Newer bridge firmware advertises as `hCRI Bridge` instead of Torch Bearer, and its screen says HCRI BRIDGE until an instrument is plugged in. Once connected, the app shows the instrument, Torch Bearer or ColorMunki. Older firmware still works. The no-instrument message is now generic.
- **Galaxy Z Fold8 and other 4:3 unfolded foldables** get the same charts-left, History-and-Data-right layout as the nearly square Fold Ultra, in both orientations.
- **TM-30 report: Save image** makes a PNG of the whole report page, and the three action buttons (On a photo, Save image, Share PDF) are now icons with captions. On iPhone the PDF now fills the whole page instead of leaving blank margins.
- **Reading names stay in sync:** renaming a reading on Main updates it in History straight away, and renaming it in History updates Main.
- The meter list and header show `ColorMunki` or `Torch Bearer` to match the instrument on the bridge, and calibration problems now say "Calibration failed".

What's new in 1.28

- **iPad and tablet layouts.** On a tablet every chart is shown at once: the spectrum, CIE, R1–R15 and (when the reading has one) flicker. In landscape the big chart sits on the left with the others beside it and History, Data and Settings are a tap away; in portrait the charts sit on top (swipe between them) with History bottom-left and Data bottom-right. There is no tab bar on a tablet: Settings is the cog next to the `?`.
- **Drag a chart to make it big** (landscape tablets): hold the handle on a chart and drop it on the large one, or tap the handle. The choice is remembered for the Main page. Readings opened from History always start in the standard order.
- **Windows with an X.** On a tablet Settings, the TM-30 report, a reading opened from History, Compare and the photo tool open as windows over a dimmed page, closed with the X. Settings uses two or three columns, with About as the third column in landscape.
- **Compare shows each reading as its own card** with its stats and a switch between its SPD and Flicker chart, then an overlay of all of them (SPD, or flicker with Wave / Risk views and zoom) and the metrics table. Cards run three across in landscape, two in portrait, one on a phone.
- **See it on a photo (iPad).** A new button next to TM-30 opens the hCRI.io photo tool in a large centred window.
- **The CIE chart keeps its true shape** wherever it is shown, as on hCRI.io. Tablets also show flicker for any reading that has it.

What's new in 1.27

- **Auto-connect to meter can be turned off.** Settings → `Auto-connect to meter` (on by default). When it is off the app only connects when you tap `Connect to Meter`, not when it opens or when you switch back to it.
- **No connection attempts while Bluetooth is off.** The app now checks Bluetooth first. If it is off, or (iPhone) the app has not been allowed to use it, nothing is attempted when you open or return to the app and the Main status line says *Bluetooth is off* or *Bluetooth access is off*. Tapping `Connect to Meter` explains the problem, with an `Open Settings` button.
- **Friendlier network messages.** Uploads and other hCRI.io requests give up after a short time with a clear "can't reach hCRI.io" or "took too long" message. When History is full, readings you have not uploaded are kept and the oldest uploaded ones are dropped first; the app tells you if a reading or its LED details could not be saved.
- **Accessibility and small fixes.** Screen reader labels on switches and tabs, the update notice fades out cleanly and names the right store, the keyboard no longer covers fields on scrolling screens, and incomplete Settings fields now say "Missing information".

What's new in 1.26

- **LED suggestions can be turned off.** Settings → `LED suggestions` (on by default). When it is off the app stops asking hCRI.io to suggest an LED and hides the suggestion cards on Main and in History; you can still add LED details yourself with the 💡 button. Switching it back on brings the suggestions back.
- **A new update notice.** When a newer version is available, a small grey *Update available* capsule slides down from the top of the screen and hovers there with a blue `Update` button and a × to hide it until the next launch. It replaces the full-width blue bar.

What's new in 1.25

- **Generate API Token** now works on the first tap with the keyboard open (it used to take a second tap, the first only closed the keyboard), and the password box has an **eye button** to show or hide what you type. The password is always hidden when the window opens; hold the eye to see its label. The same first-tap fix applies to `Save` and `Forget Credentials` in Settings.
- **Main follows LED changes made in History:** if you edit the current reading's LEDs from History, the LED button, the Data tab and the TM-30 report on Main show the new LEDs when you come back.

What's new in 1.24

- **More than one LED per light.** Many lights have two or more different LEDs (for example a 1800K Nichia plus a red Luminus). The LED window now holds a list: each LED has its own brand, model and CCT, kept together, with `+ Add another LED`. Finished LEDs collapse into a Brand / LED / CCT list with an `Edit` button, and the new LED opens and scrolls into view. You can remove any LED, or all of them, and Save. All LEDs go up to the hCRI.io report and appear on the TM-30 report. See LED details.
- **Uploading a reading again updates its report** instead of creating a duplicate: the report keeps its link, visibility, notes and LEDs, and gets the new title and spectrum.
- **Long-press labels:** hold any icon-only button (History row icons, the battery, flicker chart controls, the `?` and `×` buttons, page dots) to see what it is.
- **Connecting no longer blocks the app.** The main button reads `Tap to cancel` while connecting, the status shows the current step (scanning, connecting, setting up), and History, Settings and Logs stay usable.
- **Password managers and passkey autofill** now work on the username, password and token fields in Settings (iCloud Keychain / Passwords, Google Password Manager, 1Password, Bitwarden and others).
- **iPhone haptics:** button taps are now a light tap and a finished reading or upload uses the system success / error feedback (iOS can't shorten the old vibration, which felt like a long buzz).
- **Test readings include flicker** when the public report has a flicker reading: the Flicker page and button appear (view only) and show the report's first flicker

capture.

- History now shows `✎ Edit` beside a reading's LED line so it's clear you can tap it to change the LEDs.

What's new in 1.23

- Layout fixes: the `💡 Add LED` button no longer overlaps the reading title on Main, History rows have more room between the CCT/Ra values and the icons, and the Generate API Token window stays above the keyboard on iPhone and Android.
- On iPhone the app is named `hCRI` under its home-screen icon (the full name did not fit).

What's new in 1.22

- The LED details window now stays above the keyboard on Android, so the last field and the `Save` button are no longer covered.

What's new in 1.21

- LED details: the app suggests the LED (brand, model and CCT) from the shape of the spectrum and the reading's title, and asks you to confirm it. You can also add or edit the LED yourself with `💡 Add LED details` on Main, in History, and on the Data tab. Confirmed LED details go up to the hCRI.io report and appear on the TM-30 report.
- The TM-30 PDF now matches the Color Rendition Report you get from hCRI.io.

What's new in 1.20

- In-app TM-30 report: after any reading (including a test reading) a `TM-30` button opens the full IES TM-30-18 Color Rendition Report on your phone — scroll through it, or tap `Share PDF` at the bottom to send it as a PDF. It is calculated in the app, so it works offline and for readings that were never uploaded. The `TM-30` button in History now opens this report too.
- Fixed the drag and drop in Settings → Main Screen Measurements (rows no longer jump around), and `Reset to Default` now moves the rows back.

What's new in 1.19

- More reliable update checks: the app re-checks Google Play each time you return to it, and Settings → Update shows what Play reported (the newest and installed version codes), which is also written to the Logs tab.

What's new in 1.18

- Layout fix for the Galaxy Z Fold 8 Ultra: the bottom tab labels (Home, History, Settings) and the action-bar labels above them are no longer cut off at the bottom of

the screen.

What's new in 1.17

- Updates now come from Google Play. The app checks Play for a newer version when it opens, and the banner (and Settings → Update) has a button that opens the app's Play Store page, where you install the update. The old in-app update screen is gone.

What's new in 1.16

- Flicker readings now upload to hCRI.io: with a reading (attached to its report) or on their own, with a title and notes.
- A redesigned Flicker tab: `New sample`, `Add to reading` / `Redo for reading`, one shared `Stop`, a `?` help button and the flicker settings gear in the top-right of the chart.
- The bottom Flicker button only opens the Flicker tab; Flicker is hidden while Live is running.
- History and Data actions are now icons with captions (cloud = upload to hCRI.io, tray = share, eye = view, trash = delete); readings that include flicker show a small waveform icon.
- On the T-Display-S3 Pro, the bridge firmware shows battery percentage and can power a Torch Bearer from its own battery.

What's new in 1.15

- Torch Bearer support, with a built-in spectral correction.
- Continuous (Live) readings and Flicker on meters that support them.
- Device scanning, connecting and switching between meters refined a lot.
- History: Share selected readings, a restyled top bar, and a title editor whose Save works on the first tap.
- Shared CSV files now end with a short summary of the computed values.
- Flicker readings can now be uploaded to hCRI.io (see 1.16 above).

02 Requirements

- Android 7.0 (Nougat) or newer, or iOS 15.1 or newer on iPhone
- Bluetooth Low Energy (BLE) support
- A Hopoocolor HPCS-series meter, powered on and in range — or a Torch Bearer connected to the hCRI ESP32 bridge (see Using a Torch Bearer)
- An hCRI.io account, if you want to upload readings (not required just to take and view them)

03 Installing the app

hCRI Companion is on Google Play for Android. iPhone and iPad are in open testing through TestFlight: email fizzgig@hcri.io from the Companion page and you'll be added as a tester.

1. **Android**
   Open the hCRI Companion page on Google Play and install it like any other app. If you were sent an APK instead, open the downloaded file and allow installs from your browser or Files app when Android asks.

2. **iPhone**
   iPhone builds are being prepared for TestFlight. Once you're added as a tester, install Apple's free TestFlight app, accept the invitation and install hCRI Companion from there.

3. **Open the app**
   Open hCRI Companion and allow Bluetooth when asked. It needs Bluetooth to find your meter.

Updating later

If you installed from Google Play, the app checks Play for a newer version each time it opens. When one is available, a small grey *Update available* capsule slides down from the top of the screen and hovers there with an `Update` button (opens the Play Store page) and a × to hide it until the next launch; Settings → Update shows `Open in Play Store`; the update itself is installed from the Play Store page. If you installed the APK directly, there's no automatic check: re-download and install the APK the same way to get a newer build — it installs over the existing app and keeps your saved readings, account, and settings. On iPhone, a production TestFlight build shows the same *Update available* capsule, and Settings → Update has a `Check for updates` button that opens TestFlight; TestFlight itself also tells you when a new build is ready.

04 Connecting your hCRI.io account

You only need to do this once. From the `Settings` tab, there are two ways to get a token into the app.

Option A: Generate a token in the app

1. **Tap the key button next to Save**
   Opens the Generate API Token dialog.

2. **Enter your hCRI.io username or email, and your password**
   Used once to sign in — your password is never stored on the device and never sent anywhere else. The password is hidden as you type; tap the eye at the right of the box to check it, and tap again to hide it.

3. **Review the token name**
   Defaults to "hCRI Companion Data Upload Token" — this is the name you'll see later if you list or revoke tokens from Profile → API on the website. Change it if you'd like something more specific.

4. **Tap Generate & Save**
   The app signs in, creates a brand-new token under that name, and saves it — same as entering one by hand (Option B, step 3 below).

Option B: Paste in an existing token

1. **Enter your hCRI.io username**
   The same username you sign in with at hcri.io.

2. **Enter your hCRI.io API token**
   Find or generate this from Profile → API on hcri.io. The field is masked while typing.

3. **Tap Save**
   The token is stored in your device's secure keychain (Android Keystore or the iOS Keychain) — not in plain text, and not readable by any other app.

The username, password and token fields work with your phone's password manager and passkeys — iCloud Keychain / Passwords on iPhone, Google Password Manager on Android, or an app such as 1Password or Bitwarden — so you can fill them in with one tap instead of typing or pasting.

Either way, once saved, the fields switch to a locked, read-only view with a `Forget Credentials` button — a deliberate extra step before replacing a saved key, so a stray keystroke can't silently overwrite a working token.

Why generate instead of paste?

It skips a trip to the website — sign in once in the app and you're done. Each token you generate (in the app or on the website) is independent and can be revoked on its own from Profile → API without affecting any other device or token.

05 Pairing with your meter

The app looks for your meter automatically when it opens. You can also go to the `Main` tab and tap `Connect to Meter`. The app scans for a few seconds and connects automatically if exactly one supported meter is in range.

If Bluetooth is turned off on your phone, a message tells you that Bluetooth is required to take readings, with an `Open Settings` button that jumps to your phone's Bluetooth settings and an `OK` button that simply closes it. This message appears when the app opens and when you tap `Connect to Meter` — not every time you switch back to the app. On iPhone, if you have not allowed hCRI Companion to use Bluetooth, a similar message (*Bluetooth access is off*) sends you to the app's settings. While Bluetooth is off or blocked the app does not try to connect on its own, and the Main status line says why.

Prefer to connect only when you choose to? Turn off `Auto-connect to meter` in Settings.

If more than one matching meter is found, a picker appears so you choose which one — look for its advertised name and signal strength. A small `Switch meter` button (two arrows) next to the status row lets you reopen that same list later without a fresh scan. Device switching has been refined a lot in 1.15: the list stays current while you look at it, a meter that is momentarily busy is retried automatically, and switching to another meter no longer needs a reset.

Connecting happens in the background, so the rest of the app stays usable while it works. The status line shows the current step (*Scanning for meter…*, *Connecting to meter…*, *Setting up meter…*), and the main button changes to `Tap to cancel` if you want to stop. History, Settings and Logs can be used the whole time.

No meter handy? See Try it without a meter.

Meter won't connect?

Tap `Meter won't connect? Reset connection`, underneath the Connect button. This clears a stale Bluetooth connection left over from a previous session — the most common reason a meter seems stuck, and something that used to require power-cycling the meter itself.

06 Using a Torch Bearer, ColorMunki or TKLamp

The Torch Bearer (and the X-Rite ColorMunki Photo / Design) reaches the app through the hCRI ESP32 bridge, a small LilyGO ESP32-S3 board. You need:

- a LilyGO T-Display-S3 (16 MB flash) or T-Display-S3 Pro ("Without Camera")
- a USB-C OTG adapter with a USB-A socket for the instrument plus a USB-C socket for power
- a power bank (optional on the Pro, which has its own battery)
- the instrument, and this app on your phone

Where to buy the board, how to connect it and how to install the firmware are covered step by step in the ESP32 bridge setup guide. Once the bridge is flashed and powered, it is listed in the meter picker as `hCRI Bridge` (older firmware: `Torch Bearer`) and connects like any other meter; once connected, the header shows `Torch Bearer` or `ColorMunki` depending on what is plugged in.

Live (Torch Bearer only). Tap `Live` to keep scanning: the spectrum refreshes continuously until you tap `Stop` (or press a button on the bridge). It needs the latest bridge firmware; if no readings arrive within about 25 seconds the app says so. The ColorMunki takes one measurement at a time and has no Live mode. Live for the Torch Bearer is new and has not been tested on a Torch Bearer by the developer, so please report anything odd.

ColorMunki

Turn the dial to calibration and tap Calibrate, then turn to ambient and measure. The app asks for a fresh calibration after the time set in Settings (default 1 hour), because the dark reference drifts. Lux is approximate.

With the latest bridge firmware a calibration takes about 6 seconds, because it also prepares the sensor's high-gain mode for near darkness. Normal readings take a second or two; in dim light the bridge integrates for up to 4.5 s and averages several integrations, so a reading can take 10–15 s. Tap the main button again to cancel. The spectrum is the ColorMunki's own (Argyll / X-Rite factory calibration), with no correction of ours. In normal light it uses the ColorMunki's high-resolution mode (3.3 nm bands, an effective resolution of about 4 nm instead of 11 nm); in very dim light it uses the standard 10 nm spectrum.

Using a TKLamp tester

The TKLamp TK2303D is an integrating-sphere tester that measures a light's total output in lumens. It has no Bluetooth, so it plugs into the bridge with the tester's own USB

cable. The app then shows its reading live and can record how the output changes over time.

1. **Connect.** Plug the tester into the bridge (see the bridge guide), switch the tester on, and connect from the meter picker as usual. The bridge recognises the tester because it is sending readings, so it must be on. The bridge's screen header says `TKLAMP` and the app shows `TKLamp`.
2. **Read.** The Main tab shows the output in lumens (a one second average, updating several times a second) and a chart. The chart's vertical scale starts at 0 and only grows, so a slow fade looks like a slow fade. Time labels run along the bottom. The chart shows the width set in Settings (default 120 s); swipe it sideways to look back, and tap `Latest` to jump to now.
3. **Clear screen.** The `Clear screen` button wipes the number and the chart so you can start fresh. It is not available while recording.
4. **Record.** Tap `Start run` on the bottom bar and `Stop run` when done. The run is saved on your phone straight away, in History → Runtime. Give it a name and tap `Upload to Runtime` to send it to your Runtime list on hCRI.io (the same name replaces an earlier run). The dark readings before the light came on are trimmed automatically (see Settings).
5. **Run limits.** Under the chart, `Run limits` lets the test start and stop by itself. `Start at (lumens)`: Start run then waits until the light reaches that level and starts recording on its own (the bar button says `Cancel` while it waits). `Stop below (lumens)`: ends the run when the output stays below that level for 3 seconds, but only after it has been above it, so a run started before the light is on does not end at once. `Stop after (minutes)`: ends the run after that long. `Stop if no readings (min)`: ends the run when the tester has been silent that long (default 5 minutes; 0 or blank turns it off). A blank box means that limit is off. The values are kept between runs and when the app restarts. A run that stops by itself is saved to History → Runtime with a note saying why, and ends at the last reading received.
6. **Review.** History → Runtime lists your runs with length, start and end lumens and the percent left. Tap a run's chart to open it full size, tap its name to rename it, and use the cloud icon to upload it later.

The scale (counts per lumen)

The tester sends a raw sensor count and the app divides it by *counts per lumen* to show lumens. The default, 313.2, was measured on a calibrated tester against its 2150 lm calibration lamp. If the app and the tester's own screen disagree (for example after you recalibrate the tester), put a lamp of known output in the sphere, wait for a steady number, tap the `Scale:` line under the chart, enter the lamp's lumens and tap `Set scale`. You can also type the number in Settings → TKLamp tester. A bigger number shows fewer lumens.

Good to know

- The TKLamp gives lumens only: there is no spectrum, CCT or CRI, and Live spectrum and Flicker are not available.
- Runs are stored at one point per second, so a 24 hour run is 86,400 points. hCRI.io accepts up to 100,000 points per curve; a run longer than about 27 hours is stored with wider spacing to fit. The website's list and shared pages average very long curves down for drawing (to a few thousand points), while the stored curve keeps every point.
- If readings stop for 5 seconds the app says so. Check that the tester is on and the cable is seated.

Live station: watch a TKLamp run from anywhere

Turn on `Settings → Live station → Share TKLamp runs live` (you need to be signed in to hCRI.io). While you record a run, the app sends it to hCRI.io every 5 seconds. When no run is recording but the tester is connected, the link still shows the live reading, marked **Live**; during a run it says **Live run** at the top. You get one link, `hcri.io/?live=...`, that always shows what is running now (or the last run) with a live chart, the current lumens, how long it has run and when the last reading arrived. Anyone with the link can watch without an account. The same switch, link and settings are on the website (and the web logger and `tklamp_live.py` can switch it on and off too) under `Explore → Runtime → Live station`, and the eye button in the app shows the same screen on any phone that is signed in. **Remote control:** from the website (Runtime → Live station, *Control the run*) or the app's Live view you can *Start run*, *Stop run* and *Clear*. They are carried out within about 5 seconds by whichever app or web logger is connected to the tester with Live on (a remote Stop saves the run on that device under its suggested name). The app's Live view also lets you edit the name and details. The row of round buttons under the link is: eye (view live), copy, share, open in browser, and make a new link.

You can type what you are testing (a name and details, for example “Olight Warrior 3, turbo, fresh cell”) on the website, in the app's Live settings, in the web logger, or with `--live-title` / `--live-details` (or the `Live note...` button) in `tklamp_live.py`; it appears on the live page and can be changed mid-run. Link previews (chat apps, social sites) show a snapshot of the name and the lumens at the moment they fetched the link, and cannot update live; the page itself is live. `tklamp_live.py` checks for a newer version when it starts and updates itself (use `--no-update` to skip).

hCRI.io can also email you (to your account address, at most one email of each kind per run): when a run **finishes**, when there is a **problem** (the tester or bridge stops sending), when **no data** arrives for a set number of minutes (default 5; the phone may be off or out of signal), and when the **output falls below a limit** you set. If the phone loses signal, it keeps the readings and sends them when it is back. Simulated runs from the app are never sent. The web logger and `tklamp_live.py` send their runs too while you are signed in to hCRI.io (in that browser, or with the script's saved token) (their simulated runs

are sent as "Simulated: ...", so you can try the feature without a tester). `Make a new link` stops the old link working; turning the switch off hides the run.

Good to know (bridge)

- The bridge allows one Bluetooth connection at a time and stops advertising while connected — close other Bluetooth tools (such as nRF Connect) if the app can't see it.
- Its exposure adapts automatically. Hold the sensor about 25 cm from the lamp, ideally behind a diffuser; very close to a bright source it can saturate.
- **No spectral correction.** The spectrum is shown as the Torch Bearer reports it, the same as the open-source tobes-ui software. It reads a few percent high in CCT next to an HPCS, more so at higher CCT (in our checks up to about 550 K at 6700 K). Older bridge firmware still applies a fitted correction. Every shared CSV records whether one was applied.
- Lux and PAR are not calibrated yet — treat them as approximate (within about 15 percent of an HPCS).
- The Torch Bearer takes single readings; Live and Flicker are not available on it.

07 Live readings & Flicker

On meters that support them, the action bar shows a `Live` button and a `Flicker` button. `Live` keeps measuring and updates the spectrum and values continuously until you tap `Stop`. Buttons for modes your meter doesn't support simply don't appear. While Live is running the Flicker button and the Flicker chart page are hidden; they return when you stop Live.

The Flicker tab

The `Flicker` button on the action bar only takes you to the Flicker tab (the fourth chart page on Main); it never starts anything. The tab shows the flicker frequency (Hz), percent flicker, flicker index, cycle time and duty, the captured waveform (or a risk chart, with the Wave / Risk switch) and a risk tip. The `?` in a circle at the top right explains the options below, and the gear next to it sets the meter's flicker range and sample rate.

There are two kinds of flicker sample, each started with its own button under the chart:

- **New sample** measures flicker on its own, continuously. It *clears the current reading* from Main — a reading that was saved stays in History, a live reading you had not saved is gone. When you tap `Stop` you can `Share` the sample or `Upload flicker` it to hCRI.io (see below). When it ends, a New sample is saved to the `Flicker` list in History (see The History tab), where you can attach it to a reading later.
- **Add to reading** (shown as **Redo for reading** when the reading already has a sample) measures flicker for the reading you just took. The last frame when you tap `Stop` becomes that reading's flicker sample: it is saved with the reading, shown in History, and uploaded together with the reading. It therefore has no Share or Upload of its own.

While a sample runs, its button pulses and says *Sampling…*, the other button dims, and one red `Stop` sits between them. A counter shows how many updates have arrived and the elapsed time.

When each option is available

- After a reading that has not been uploaded: both `Add to reading` / `Redo for reading` and `New sample`.
- After the reading has been uploaded: only `New sample`, because an uploaded report can't change.
- No reading on screen (or after a New sample): only `New sample`, with Share and Upload flicker once a sample exists.
- Imported or test readings: only `New sample`.

- Flicker that came with a reading never shows Share or Upload flicker, and the readings you open from History show their flicker without any controls.
- A note under the buttons reminds you that New sample clears the current reading, and whether it is saved to History.

Auto-connect to meter

On by default. The app looks for your meter when it opens and when you switch back to it (and skips the attempt while Bluetooth is off or blocked). Turn it off to connect only when you tap `Connect to Meter`. See Pairing with your meter.

Capture flicker with each reading

Settings → *Capture flicker with each reading* (off by default) takes a one-shot flicker snapshot automatically after every reading. It adds a few seconds per reading. Even when it is off you can add a sample to a reading yourself with `Add to reading`, before you upload it.

Uploading flicker to hCRI.io

- **With a reading:** when you upload a reading that has a flicker sample, the report goes up first and the flicker is then attached to it automatically. It appears in the flicker section at the bottom of the report on hCRI.io.
- **On its own:** after a New sample, `Upload flicker` (cloud icon) opens a small window for a title (up to two lines) and optional notes. Both are remembered and pre-filled next time. The flicker then appears under Explore → Flicker on hCRI.io, where it can be viewed, compared with other flicker readings, and attached to a report.
- The flicker upload is best-effort: if hCRI.io can't take it, the report upload is not affected, and the Logs tab says what happened.

Flicker readings are also included at the end of shared CSV files.

---

08 Taking a reading

Once connected, tap `Take Reading`. The meter takes its exposure, and a short haptic tick confirms the moment it lands (a different pattern if it fails; see Feedback (haptics) in Settings) — handy when you're not looking directly at the screen. The spectrum, CCT, Duv, Ra, and the rest of your chosen measurements appear immediately after.

Every completed reading is saved automatically to History — there's nothing extra to do to keep it.

09 The Main tab

Main is where you connect, take readings, and review the latest one. Its result card always shows the same layout — a grid of measurements, the three swipeable charts, and the action button directly underneath them — whether or not a reading has happened yet (before your first reading, everything just reads zero/blank, so nothing jumps around once real numbers appear).

A small `?` button beside the Main / Data / Logs tabs opens a short overview of what the app does. Tapping the `Home` tab at the bottom of the screen always brings you back to Main, even from Data or Logs. On Android, the phone's bottom navigation bar is hidden to give the app more room; swipe up from the bottom edge to bring it back for a moment. While the keyboard is open the bar stays visible, so Back and Home remain reachable.

Icon labels

Buttons that show only an icon have a label: touch and hold one for about half a second and a small tooltip names it (a normal tap still does what it always did). This works on the History row icons, the battery indicator, the flicker chart controls (help, settings, pan and zoom), the `?` help buttons, the close `×` buttons and the page dots.

Try it without a meter

While no meter is connected, a `Show a test reading` button appears under `Connect to Meter`. It loads the spectrum from a random public report on hCRI.io, so you can explore the measurements and charts before you own a meter. Tap `What's this?` under the button for a short explanation.

A test reading is sample data, not yours: it is not saved to History, and Upload (on both Main and Data) is disabled while one is showing. Its title is read-only, and a note under the buttons names the report it came from. Connect a meter and take a real reading to replace it. The button disappears as soon as a meter is connected.

If that public report has a flicker reading on hCRI.io, the test reading also gets the Flicker page and a `Flicker` button, showing the first (oldest) flicker capture. It is view-only: sampling, sharing and uploading flicker need a meter and a reading of your own.

Measurement grid

Shows CCT, Ra (CRI), Duv, Lux, Rf, R9, and Rg by default. Which measurements appear here, and in what order, is fully customizable from Settings — including any individual R1–R15 sample and the raw CIE x/y coordinates.

Spectrum / Chrom / R-Values

Swipe (or tap the dots) between three views of the same reading:

- **Spectrum** — the full wavelength-by-wavelength power distribution, colored by wavelength, plus a collapsible list of every raw nm/value pair.
- **Chrom** — the CIE 1931 chromaticity diagram, with your reading's x/y point plotted against the real spectral locus and the Planckian (blackbody) curve.
- **R-Values** — the full CRI R1–R15 breakdown as a color-coded bar chart, the same chart hCRI.io's own report page uses.

The TM-30 report

Once a reading is on screen — including a test reading — a `TM-30` button appears at the right of the bottom bar (and on every History row). It opens the full IES TM-30-18 Color Rendition Report: Rf and Rg, CCT, Duv, Ra, R9 and chromaticity, the color vector graphic, the spectrum against its reference illuminant, local chroma shift, hue shift and fidelity for the 16 hue bins, and the fidelity of all 99 color samples. Scroll the page (pinch to zoom). Swipe left, or tap `Photo` at the top right, to see the light on a photo; swipe right below the photo, or tap `TM-30` at the top left, to come back. The X closes the report and returns you to Home or History. Two buttons are docked at the bottom: `Save image` makes a PNG of the full report page (on iPhone choose Save Image in the share sheet to put it in Photos; on Android choose Photos or Files), and `Share PDF` creates a PDF of the same report and opens your share sheet. The report is calculated on your phone with the same math hCRI.io uses, so it needs no upload and no connection.

Uploading

Tap `Upload to hCRI.io` to send the current reading. A small green checkmark appears next to the button once it succeeds — there's no popup to dismiss on a routine upload. If an upload fails, an alert explains what happened; check the Logs tab for the server's own response if you need more detail.

Uploading a reading that was already uploaded **updates that report** rather than creating a second copy. The report keeps its ID and link, who can see it, its notes and its LEDs, and takes the new title and spectrum. If you deleted the report on hCRI.io, the next upload creates a new one. (A flicker reading attached on the first upload is left as it was.) A new reading always uploads as a new report of its own; it never replaces the one before it.

LED details

Tell hCRI.io which LED(s) a light uses so the report can be found and compared. LEDs are set in the Categorize window, together with the other categories: tap the `Categorize` pill (a tag) beside the reading's title on Main (it reads `LED`, `2 LEDs` or `Categories` with a tick once set), `Categorize` on the Data tab, the tag icon on a History row, or the tag line at the top of a reading's page, then tap `Edit` beside LEDs. If you turn on

Settings → LED suggestions, the app may also suggest an LED from the shape of the spectrum; tap `Yes` to accept it or `Other` to choose yourself.

- Each LED has a **brand**, a **model** and a **CCT**. Start typing or tap a match from the hCRI.io lists; models seen with the brand you chose are listed first. Leave CCT blank for a deep-red LED.
- For a light with more than one LED, tap `+ Add another LED`. The new LED opens at the bottom and the window scrolls to it. LEDs you've finished collapse into a Brand / LED / CCT list at the top; tap `Edit` on a row to reopen it, `Done` to collapse it again, and `Remove` to delete it. Keeping each LED's brand, model and CCT together means two different LEDs are never mixed up.
- To remove the LED details completely, press `Remove` on each LED and tap `Save`. The LEDs are cleared on the reading and on its hCRI.io report, and the app won't suggest one again for that reading.
- Values that aren't in the lists yet are sent to hCRI.io for review rather than added straight away.
- LED details are saved with the reading and sent to its hCRI.io report as soon as it has been uploaded. They also appear on the TM-30 report, one line per LED.

Categorize

Categorize sets everything hCRI.io files a report under: the LEDs plus **light brand**, **light model**, **optic**, **lumens** and **current**. It works on one reading or on many at once.

- **One reading:** tap the tag icon on a History row (beside upload and share), the tag line at the top of a reading's page, or the `Categorize` pill on Main or the Categories block on the Data tab. The window opens with the reading's own values.
- **Several readings:** in History, hold a reading to start selecting, check the readings, and tap `Categorize`. Choose whether a reading that already has a value *keeps its value* (only gaps are filled) or *replaces it*.
- Each field is a text box with matches from the hCRI.io lists underneath. Lumens and current are numbers you type. Blank fields are left as they are; `Clear fields` empties the window. Values that aren't in the lists yet are sent to hCRI.io for review.
- **Nothing is applied until you tap `Categorize`.** The window remembers what you applied last time and opens with those values filled in for any field the reading has nothing for, so repeating a category is quick, but new readings are never categorized automatically.
- Categories are saved on your phone straight away and sent to the report on hCRI.io when the reading has been uploaded (or at its next upload). The category lists refresh each time the app starts, when you are online, and are kept for offline use.

10 The Data tab

A closer look at the current reading, plus the controls for naming and sending it:

- **Upload Title** — type a custom title, or leave it blank to use the auto-generated username + timestamp + device label.
- **Categories** — the brand, model and CCT of each LED in this reading's light (one block per LED), plus its light, optic, lumens and current, with `Edit` (or `Categorize`) to set them. Available once the reading is saved to History. See LED details.
- **Upload Preview** — the exact wavelength/value payload about to be sent, so you can eyeball the range and point count before it goes anywhere.
- **R1–R15**, **Chromaticity**, and **Device Info** — full numeric detail, including the meter's own firmware version and integration time.
- **Upload to hCRI.io** and **Share CSV** — the same upload button as Main (with the same inline checkmark), plus exporting this one reading as a CSV file through your phone's share sheet.

11 The History tab

A switch at the top chooses between four lists: `Readings`, `Flicker` (saved flicker samples, described below), `Runtime` (runs recorded with a TKLamp tester; see Using a TKLamp tester) and `Lights` (readings grouped by flashlight; see The Lights list).

Your most recent readings (up to 100), grouped by day, newest first. From here you can:

- **View** a past reading's full measurement grid, spectrum, chromaticity, and R-values exactly as they looked when it was taken.
- **Rename** a reading — renaming before upload sends it to hCRI.io under that new title.
- **Re-upload** a reading at any time, including ones already sent — an already-uploaded reading updates its existing hCRI.io report instead of creating a duplicate (a confirmation says *Updated*). Tap a reading's LED line (marked `Edit`) to change its LEDs. Row actions are icons: cloud (upload to hCRI.io), tray (share CSV), eye (view) and trash (delete). A small waveform icon next to the CCT/Ra marks a reading that includes a flicker sample, which goes up with it.
- **TM-30, Copy, Report** — every reading has a `TM-30` button that opens its TM-30 report in the app (see The TM-30 report), whether or not it was ever uploaded. For a reading that has been uploaded, `Copy` puts its hCRI.io link on the clipboard and `Report` opens the report in your browser. For a private report, the first tap creates its share link, which anyone holding the link can open.
- **Select** multiple readings: hold a reading's title to start, with that reading checked. Tap more rows to add them, use `Select all` at the top, and tap the X to stop. Then upload them to hCRI.io in one batch, categorize, share, compare, put them `To light` or delete them.
- **Share** a single reading, the readings you have selected, or your entire history, as CSV. Shared files end with a short summary of the computed values.
- **Add a saved flicker** to a reading that has none: the lightning-bolt button lists your saved flickers that aren't attached to a reading yet. Pick one and it is copied into the reading, so it is saved and uploaded with it. If the reading was already uploaded, the flicker is also added to its report on hCRI.io. The button only appears when the reading has no flicker and a free saved flicker exists. A reading that has a flicker shows a small waveform icon next to its date; its hint says when the flicker went up with the report.
- **Delete** a reading you no longer want — this only removes it from your phone (and from your cloud backup, if backup is on); a copy already uploaded to hCRI.io as a report stays there until you delete it from your account separately.

The Lights list

A *light* groups several readings of the same flashlight (for example one reading per mode, or one per week as the battery ages) so you can follow how it changes. A light is kept on your phone and on hCRI.io: the website's `Explore → Lights` shows the same lights, with trend charts, a spectra overlay, comparison and a share link.

- **Sign in first.** Lights live on hCRI.io, so the tab needs your API token. If none is saved, or hCRI.io no longer accepts it, the tab asks you to sign in with your username and password (this creates a token) or to paste one. Without a connection you can still work on lights; Sync waits until you are online.
- **Create** a light with `+ New light`, or select readings in the Readings list and tap `To light`. Add more later with `+ Add readings` (a searchable list of your History readings). Use the arrows to put the readings in order: that order is the trend order on hCRI.io as well. The cross takes a reading off the light; it never deletes the reading.
- **Categorize** a light with the same window as a reading: light brand and model, LED brand, model and CCT, and optic. A light keeps only values that are already in hCRI.io's lists.
- **Sync** (the large button on a light, or `Sync all`) creates the light on hCRI.io if it is new, uploads every reading of the light that was never uploaded (readings already uploaded are left as they are), links them all in your order, takes off the ones you removed, and brings back the latest numbers and trend charts. If a reading cannot be uploaded the light stays marked *Unsent changes*; sync again to retry.
- **Refresh** brings down the lights on your account, including ones made on the website. Readings of a light that are not on this phone show as *On hCRI.io only*.
- **Delete light** removes the light here and on hCRI.io. The readings are kept (in History and as reports); only the grouping goes.

The Flicker list

Each `New sample` from the Flicker page is saved here automatically when it ends (up to 100, newest first). A row shows the date, the meter model, the frequency, percent flicker and flicker index. Tap the title to rename it, the eye to view the waveform, the cloud to upload it to hCRI.io on its own, or the bin to delete it. A badge says where it belongs:

- **In report** — it is attached to a reading that has been uploaded as an hCRI.io report.
- **In reading** — it is attached to a reading that hasn't been uploaded yet; it will go up with that reading. If that reading is deleted, the flicker becomes free again.
- **Uploaded to hCRI.io** — it was sent on its own (a standalone flicker reading on hCRI.io).
- No badge — it is free, and can be attached to a reading with the lightning-bolt button on the Readings list.

Flickers that were taken for a reading (`Add to reading`, or `Capture flicker with each reading`) live inside that reading and aren't listed here.

> **How many readings are kept**
>
> History holds your most recent 100 readings. When it is full, the oldest *uploaded* readings are removed first, so a reading you haven't uploaded yet is kept (up to 200 in total). From 90 readings on, a note at the top of History reminds you. Readings you've uploaded stay safe on hCRI.io after they leave History.

---

12 The Logs tab

A running debug log of connect/disconnect/measure/upload activity, each line timestamped in your phone's own local time. Useful for troubleshooting, or to attach to a bug report.

- **Share Debug Log** — sends the current log through your phone's share sheet (email, messaging, wherever you'd like to send it).
- **Clear** — empties the log.

Turning on `Verbose logging` in Settings adds the low-level Bluetooth hex traffic and the full raw result body to this log — off by default, since the standard log already covers ordinary connection and measurement status.

13 Settings

Settings are grouped into sections. Tap the `?` in a circle beside any setting for a short explanation of it.

hCRI.io account

Your username and API token — see Connecting your hCRI.io account above.

Display

Light, Dark, or System (the default), which follows your phone's own light/dark setting. Also holds the Main Screen Measurements picker (below) and, on Android, LED suggestions and flicker options.

Connection

`Auto-connect to meter` and `Stay connected in background` are on by default; `Keep screen awake` is off by default and uses more battery. See Background & reconnect behavior.

Backup

`Back up readings to hCRI.io` (on by default) saves your reading history and your saved flickers to your own hCRI.io account a few seconds after each change, and again when you come back to the app. It needs your API token (see Connecting your hCRI.io account); with no token saved nothing is sent, and everything not yet backed up goes up once you sign in. Backed-up data is private to you: it is stored apart from your reports and is never shown on any public page. Deleting a reading or a saved flicker in the app removes it from the backup, while readings that only drop off the end of History stay in the backup.

`Restore readings from backup` (shown once a token is saved) adds back any readings and saved flickers the app doesn't have, newest first, and never removes or changes anything. History still keeps its usual 100 readings (up to 200 if unuploaded), so a very large backup restores only the most recent. On a fresh install with your token already saved, the app also offers to restore once.

Bridge

`Flip screen` turns the hCRI Bridge's screen 180° (for a Torch Bearer or a ColorMunki), so it reads upright the other way round. It takes effect right away while the bridge is connected and needs the latest bridge firmware. It does not affect HPCS meters. The Torch Bearer spectrum is sent exactly as the meter reports it, so there is no correction setting.

TKLamp tester

`Counts per lumen` (default 313.2) is the scale from the tester's raw count to lumens; `Chart width (seconds)` (default 120) is how much time the live and saved charts show across the screen before you swipe. `Start at the first reading` (on by default) drops the dark readings before the light came on when you stop a run, so the saved and uploaded curve starts at its first lit reading with no jump from 0. `Start at the peak` (off by default) instead drops everything before the highest reading; only one of the two can be on. See Using a TKLamp tester.

ColorMunki

`Calibration limit (minutes)`: how old the ColorMunki's calibration may be before the app asks you to calibrate again. The default is 30 minutes; 0 turns the check off. The bridge itself still needs one calibration after it powers up.

Readings

`LED suggestions` (off by default): when on, hCRI.io suggests the LED after a reading, from the shape of the spectrum and the reading's title, and you confirm it with one tap. See LED details. `Capture flicker with each reading` (off by default) takes one flicker sample with every reading on meters that support it; see Live readings & Flicker.

Feedback

Two switches, both on by default: `Button taps` (a short tick when you press a button in the bottom bar) and `Reading and upload results` (a distinct vibration when a reading or upload finishes, and a different one when it fails). On iPhone these use the Taptic Engine.

Troubleshooting

`Verbose logging` adds the full wavelength-by-wavelength and Bluetooth hex detail to the debug log; see The Logs tab.

Main Screen Measurements

Check which measurements show on the Main tab's result card, and hold the dotted handle to drag a row and reorder it. `Reset to Default` restores CCT, Ra, Duv, Lux, Rf, R9, Rg in that order.

On Android, Settings has three tabs at the top: `Settings`, `Update` and `About`, so About is one tap away instead of at the bottom of a long scroll. `Update` shows what Google Play reports about newer versions. Tap `Update now` (or `Update` on the banner), confirm once in Google Play's small dialog, and the update downloads in the background while you keep using the app. When it is ready the button changes to `Restart to finish updating`; tapping it installs the update and reopens the app. It carries a dot when an update is

waiting. If Google Play can't run the update in the app, the button opens the app's Play Store page instead. On iPhone there is no Update tab (updates come through the App Store / TestFlight), so Settings has just `Settings` and `About`.

About

The current list of supported meter models (and which are independently verified), a `Send Feedback` button that opens a pre-addressed email, and a link back to this Companion page.

---

14 Background & reconnect behavior

By default, switching away from hCRI Companion — the app switcher, locking your screen, a phone call — leaves the meter connected (`Stay connected in background`, on by default in Settings). Coming back to the app picks up right where you left off, with no reconnect delay.

If you'd rather the app disconnect the meter whenever it isn't the one on screen (trading a short reconnect delay for a little extra meter battery life), turn that setting off. Either way, coming back to the foreground with nothing connected always tries to reconnect automatically — you shouldn't need to tap Connect yourself just because the meter dropped on its own while you were away. (Not when `Auto-connect to meter` is turned off in Settings, and not while Bluetooth is off or blocked — the Main status line says so.)

Sharing a CSV or the debug log briefly hands control to your phone's own share sheet, which looks like backgrounding the app — this is recognized and never triggers a disconnect either way, since you're still right there using the app.

15 Troubleshooting

Meter won't connect, or seems stuck

Tap `Meter won't connect? Reset connection` on the Main tab (shown while disconnected). This clears a leftover Bluetooth connection from a previous session — by far the most common cause, and something that used to require power-cycling the meter.

Main says "Bluetooth is off" or "Bluetooth access is off"

The app does not try to connect until Bluetooth is usable. Turn Bluetooth on in your phone's settings; on iPhone, if it says *access* is off, open Settings → hCRI Companion and allow Bluetooth. Then tap `Connect to Meter` (or switch away and back to the app).

The app doesn't connect by itself any more

Check Settings → `Auto-connect to meter`; when it is off, connect with the button on Main.

App crashed, or won't open

A crash lands on a "Try Again" screen rather than kicking you back to your home screen. If the app won't stay open at all, force-close it from your phone's app switcher and reopen it — this app recovers from a mid-session crash cleanly.

Upload says it can't reach hCRI.io, or took too long

Uploads, token creation and link requests give up after about 25 seconds (a minute for uploads) instead of waiting forever. "Can't reach hCRI.io" means the phone has no working internet connection; "took too long" means the connection is there but slow or the site didn't answer. Check your signal or Wi-Fi and tap Upload again — the reading is still on your phone. If a reading could not be added to History, or LED details could not be saved, the app tells you.

Too many sign-in attempts

For security, hCRI.io limits repeated failed sign-ins and password-reset requests. If you see "Too many attempts", wait about 15 minutes and try again; if you use a saved token, signing in is not needed.

ColorMunki: "Calibrate first", "Calibration failed" or wrong dial

Turn the ColorMunki's dial to the calibration position, keep it still and tap Calibrate. After calibrating, turn the dial to ambient. The app asks again once the time in Settings → ColorMunki has passed. Repeated communication errors usually mean weak USB power: use a power bank on the standard T-Display S3. More in the bridge setup guide.

A reading looks wrong

Double-check the correct meter model connected (shown next to the status dot on Main) — each model has its own field layout, and the wrong one can occasionally still connect if its advertised name happens to be ambiguous. If a value still looks off, check Settings → About for whether that model is marked independently verified.

Still stuck?

From the Logs tab, tap `Share Debug Log` and send it along with a description of what happened to fizzgig@hcri.io, or use `Send Feedback` on the About tab of Settings.

---

16 Privacy

hCRI Companion doesn't collect, store, or transmit anything about you on its own — no analytics, no tracking, no third-party server in the loop. A reading lives on your device until you tap Upload, which sends it straight to your own hCRI.io account over an encrypted connection and nowhere else. If you have saved an API token, the optional `Back up readings to hCRI.io` setting (on by default, see Settings) also keeps a private copy of your reading history and saved flickers in your own hCRI.io account; it isn't a report and nobody else can see it. Turn the setting off and nothing is backed up. If you use `Generate Token` in Settings, your password is sent once, over that same encrypted connection, to sign in and create the token — it's never stored on the device. Full details are in the Privacy Policy on the Companion page.

---

17 Feedback & support

Questions, bug reports, or feature requests are always welcome at fizzgig@hcri.io — the same address the app's own `Send Feedback` button (Settings → About) opens for you.

© 2026 fizzgig · hCRI Companion is free software under the GNU GPL v3, with an App Store distribution exception · Source ↗