

# Esc、Fn功能

## Esc、Fn Functions

|       | 按键组合          | 功能              |
|-------|---------------|-----------------|
| Esc功能 | Shift+Esc     | ~               |
|       | Fn+Esc        | `               |
| Fn功能  | Fn+数字行(1至=)   | F行(F1至F12)      |
|       | Fn+F行(F1至F12) | 数字行(1至=)        |
|       | Fn+J          | Print Screen    |
|       | Fn+K          | Scroll Lock     |
|       | Fn+L          | Pause           |
|       | Fn+<          | Home            |
|       | Fn+>          | End             |
|       | Fn+Ctrl(右)    | Application Key |

|               | Key Combinations | Functions       |
|---------------|------------------|-----------------|
| Esc Functions | Shift + Esc      | ~               |
|               | Fn + Esc         | `               |
| Fn Functions  | Fn + Number Line | F Line          |
|               | Fn + F Line      | Number Line     |
|               | Fn + J           | Print Screen    |
|               | Fn + K           | Scroll Lock     |
|               | Fn + L           | Pause           |
|               | Fn + <           | Home            |
|               | Fn + >           | End             |
|               | Fn + Ctrl(Right) | Application Key |

