



Customer : ETD
Type : A380
Rev. Date : Jan 01, 2016

Manual : TSM
Selected applicability : ALL

36-22-11-991-03300-00-B / SHEET 2/2 - Right Wing, Loop 'A' -
Fault Location Zone and Access Table (Short Circuit/Overheat)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
053	2.91	9.55	332HF	0.63	2.07	333HF	1.46	4.79	333HF	622CB/622EB
054	0.17	0.56	333HF	1.00	3.28	333HF	1.82	5.97	333HF	622CB/622EB
055	0.54	1.77	333HF	1.36	4.46	333HF	0.08	0.26	334HF	622CB/622EB
056	0.90	2.95	333HF	1.73	5.68	333HF	0.44	1.44	334HF	622CB/622EB
057	1.27	4.17	333HF	2.09	6.86	333HF	0.81	2.66	334HF	622CB/622EB
058	1.63	5.35	333HF	0.35	1.15	334HF	1.17	3.84	334HF	622GB/622HB
059	2.00	6.56	333HF	0.71	2.33	334HF	1.54	5.05	334HF	622GB/622HB
060	0.25	0.82	334HF	1.08	3.54	334HF	1.90	6.23	334HF	622GB/622HB
061	0.62	2.03	334HF	1.44	4.72	334HF	2.27	7.45	334HF	622GB/622HB
062	0.98	3.22	334HF	1.81	5.94	334HF	2.63	8.63	334HF	622GB/622HB
063	1.35	4.43	334HF	2.17	7.12	334HF	0.26	0.85	335HF	622GB/622HB
064	1.71	5.61	334HF	2.54	8.33	334HF	0.62	2.03	335HF	622GB/622HB
065	2.08	6.82	334HF	0.16	0.52	335HF	0.99	3.25	335HF	622JB/622LB/622NB
066	2.45	8.04	334HF	0.53	1.74	335HF	1.36	4.46	335HF	622JB/622LB/622NB
067	0.07	0.23	335HF	0.90	2.95	335HF	1.72	5.64	335HF	622JB/622LB/622NB
068	0.44	1.44	335HF	1.26	4.13	335HF	2.09	6.86	335HF	622JB/622LB/622NB
069	0.80	2.62	335HF	1.63	5.35	335HF	0.27	0.89	336HF	622JB/622LB/622NB
070	1.17	3.84	335HF	1.99	6.53	335HF	0.64	2.10	336HF	622JB/622LB/622NB
071	1.53	5.02	335HF	0.18	0.59	336HF	1.00	3.28	336HF	622PB/622QB/622RB
072	1.90	6.23	335HF	0.54	1.77	336HF	1.37	4.49	336HF	622PB/622QB/622RB
073	0.08	0.26	336HF	0.91	2.99	336HF	1.73	5.68	336HF	622PB/622QB/622RB
074	0.45	1.48	336HF	1.27	4.17	336HF	2.10	6.89	336HF	622PB/622QB/622RB
075	0.81	2.66	336HF	1.64	5.38	336HF	2.46	8.07	336HF	622PB/622QB/622RB
076	1.18	3.87	336HF	2.00	6.56	336HF	0.26	0.85	337HF	622PB/622QB/622RB
077	1.54	5.05	336HF	2.37	7.78	336HF	0.62	2.03	337HF	622PB/622QB/622RB
078	1.91	6.27	336HF	0.16	0.52	337HF	0.99	3.25	337HF	622TB/622VB
079	2.27	7.45	336HF	0.53	1.74	337HF	1.35	4.43	337HF	622TB/622VB
080	0.07	0.23	337HF	0.89	2.92	337HF	1.72	5.64	337HF	622TB/622VB
081	0.43	1.41	337HF	1.26	4.13	337HF	2.08	6.82	337HF	622TB/622VB
082	0.80	2.62	337HF	1.62	5.31	337HF	2.45	8.04	337HF	622TB/622VB
083	1.16	3.81	337HF	1.99	6.53	337HF	0.23	0.75	338HF	622TB/622VB
084	1.53	5.02	337HF	2.35	7.71	337HF	0.60	1.97	338HF	622TB/622VB
085	1.89	6.20	337HF	0.14	0.46	338HF	0.96	3.15	338HF	623AT
086	2.26	7.41	337HF	0.50	1.64	338HF	1.33	4.36	338HF	623AT
087	0.04	0.13	338HF	0.87	2.85	338HF	1.69	5.54	338HF	623AT
088	0.41	1.35	338HF	1.23	4.04	338HF	0.23	0.75	339HF	623AT
089	0.77	2.53	338HF	1.60	5.25	338HF	0.59	1.94	339HF	623AT
090	1.14	3.74	338HF	0.13	0.43	339HF	0.96	3.15	339HF	483AL/483BL/483CL/483DL
091	1.50	4.92	338HF	0.50	1.64	339HF	1.32	4.33	339HF	483AL/483BL/483CL/483DL
092	0.04	0.13	339HF	0.86	2.82	339HF	0.19	0.62	324HF	483AL/483BL/483CL/483DL
093	0.40	1.31	339HF	1.23	4.04	339HF	0.55	1.80	324HF	483AL/483BL/483CL/483DL
094				5.35	17.55	747				483AL/483BL/483CL/483DL
095				5.56	18.24	4037				
096				16.48	54.07	4037				
097				27.40	89.90	4037				
098				7.56	24.80	7514				
099				3.29	10.79	108				
100				3.39	11.12	102				

NOTE: THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN).
ALL THE WIRE IDENTS ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING.
THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L_TS_362211_2_ENAA_02_00

Figure 36-22-11-991-03300-B- / SHEET 2/2 - Right Wing, Loop 'A'
- Fault Location Zone and Access Table (Short Circuit/Overheat)
** ON A/C ALL