



Customer : ETD  
Type : A380  
Rev. Date : Jan 01, 2016

Manual : TSM  
Selected applicability : ALL

36-22-11-991-03000-00-B / SHEET 1/2 - Left Wing, Loop 'B' -  
Fault Location Zone and Access Table (Short Circuit/Overheat)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
001				7.46	24.48	146				
002				7.50	24.61	7547				
003				10.82	35.50	248HF				521EB/521FB
004	13.48	44.23	248HF	0.31	1.02	226HF	1.13	3.71	226HF	521EB/521FB
005	13.85	45.44	248HF	0.67	2.20	226HF	1.49	4.89	226HF	521EB/521FB
006	0.21	0.69	226HF	1.03	3.38	226HF	1.85	6.07	226HF	521EB/521FB
007	0.57	1.87	226HF	1.39	4.56	226HF	2.22	7.28	226HF	521EB/521FB
008	0.93	3.05	226HF	1.76	5.77	226HF	2.58	8.46	226HF	521EB/521FB
009	1.30	4.27	226HF	2.12	6.96	226HF	2.94	9.65	226HF	521EB/521FB
010	1.66	5.45	226HF	2.48	8.14	226HF	0.02	0.07	227HF	521EB/521FB
011	2.02	6.63	226HF	2.84	9.32	226HF	0.39	1.28	227HF	521EB/521FB
012	2.38	7.81	226HF	3.21	10.53	226HF	0.75	2.46	227HF	521EB/521FB
013	2.75	9.02	226HF	0.29	0.95	227HF	1.11	3.64	227HF	521FB
014	3.11	10.20	226HF	0.65	2.13	227HF	0.05	0.16	228HF	521FB
015	0.19	0.62	227HF	1.01	3.31	227HF	0.41	1.35	228HF	521FB
016	0.55	1.80	227HF	1.38	4.53	227HF	0.77	2.53	228HF	521FB
017	0.92	3.02	227HF	0.31	1.02	228HF	1.13	3.71	228HF	521GB/521HB/521SB/521TB
018	1.28	4.20	227HF	0.67	2.20	228HF	1.50	4.92	228HF	521GB/521HB/521SB/521TB
019	0.21	0.69	228HF	1.04	3.41	228HF	1.86	6.10	228HF	521GB/521HB/521SB/521TB
020	0.57	1.87	228HF	1.40	4.59	228HF	2.22	7.28	228HF	521GB/521HB/521SB/521TB
021	0.94	3.08	228HF	1.76	5.77	228HF	2.58	8.46	228HF	521GB/521HB/521SB/521TB
022	1.30	4.27	228HF	2.12	6.96	228HF	0.21	0.69	229HF	521GB/521HB/521SB/521TB
023	1.66	5.45	228HF	2.49	8.17	228HF	0.57	1.87	229HF	521GB/521HB/521SB/521TB
024	2.03	6.66	228HF	0.11	0.36	229HF	0.93	3.05	229HF	521JB/521KB/521UB/521VB
025	2.39	7.84	228HF	0.47	1.54	229HF	1.29	4.23	229HF	521JB/521KB/521UB/521VB
026	0.01	0.03	229HF	0.83	2.72	229HF	1.66	5.45	229HF	521JB/521KB/521UB/521VB
027	0.37	1.21	229HF	1.20	3.94	229HF	2.02	6.63	229HF	521JB/521KB/521UB/521VB
028	0.74	2.43	229HF	1.56	5.12	229HF	2.38	7.81	229HF	521JB/521KB/521UB/521VB
029	1.10	3.61	229HF	1.92	6.30	229HF	2.74	8.99	229HF	521JB/521KB/521UB/521VB
030	1.46	4.79	229HF	2.28	7.48	229HF	3.11	10.20	229HF	521JB/521KB/521UB/521VB
031	1.82	5.97	229HF	2.65	8.69	229HF	0.22	0.72	230HF	521JB/521KB/521UB/521VB
032	2.19	7.19	229HF	3.01	9.88	229HF	0.58	1.90	230HF	521JB/521KB/521UB/521VB
033	2.55	8.37	229HF	0.12	0.39	230HF	0.94	3.08	230HF	521LB
034	2.91	9.55	229HF	0.48	1.57	230HF	1.31	4.30	230HF	521LB
035	0.02	0.07	230HF	0.85	2.79	230HF	1.67	5.48	230HF	521LB
036	0.39	1.28	230HF	1.21	3.97	230HF	2.03	6.66	230HF	521LB
037	0.75	2.46	230HF	1.57	5.15	230HF	0.28	0.92	231HF	521LB
038	1.11	3.64	230HF	1.93	6.33	230HF	0.65	2.13	231HF	521LB
039	1.47	4.82	230HF	0.19	0.62	231HF	1.01	3.31	231HF	521MB
040	1.84	6.04	230HF	0.55	1.80	231HF	1.37	4.49	231HF	521MB
041	0.09	0.30	231HF	0.91	2.99	231HF	0.08	0.26	232HF	521MB
042	0.45	1.48	231HF	1.27	4.17	231HF	0.45	1.48	232HF	521MB
043	0.81	2.66	231HF	1.64	5.38	231HF	0.81	2.66	232HF	521MB
044	1.18	3.87	231HF	0.35	1.15	232HF	1.17	3.84	232HF	522AT/522BT
045	1.54	5.05	231HF	0.71	2.33	232HF	1.53	5.02	232HF	522AT/522BT
046	0.25	0.82	232HF	1.07	3.51	232HF	1.90	6.23	232HF	522AT/522BT
047	0.61	2.00	232HF	1.44	4.72	232HF	2.26	7.41	232HF	522AT/522BT
048	0.98	3.22	232HF	1.80	5.91	232HF	2.62	8.60	232HF	522AT/522BT
049	1.34	4.40	232HF	2.16	7.09	232HF	2.98	9.78	232HF	522AT/522BT
050	1.70	5.58	232HF	2.52	8.27	232HF	0.25	0.82	233HF	522AT/522BT
051	2.06	6.76	232HF	2.89	9.48	232HF	0.61	2.00	233HF	522AT/522BT
052	2.43	7.97	232HF	0.15	0.49	233HF	0.97	3.18	233HF	522CB/522EB

L\_TS\_362211\_2\_EKAA\_01\_00

Figure 36-22-11-991-03000-B- / SHEET 1/2 - Left Wing, Loop 'B'  
- Fault Location Zone and Access Table (Short Circuit/Overheat)

\*\* ON A/C ALL